

OPERATIONS MANAGER 24.11.5

USER GUIDE

CONTENTS

CONTENTS	2
COPYRIGHT ©	16
DOCUMENT REVISION HISTORY	17
SAFETY & FCC STATEMENT	19
Safety Statement	19
FCC Warning Statement	19
ABOUT THIS USER GUIDE	21
INSTALLATION AND CONNECTION	22
Power Connection	23
DC Powered OM1200	24
Dual Power Supply	25
LED Power Status Indicator	25
SNMP Alerts for Power-related Events	26
Device Status LEDs	26
Connecting to the Network	28
Serial Connection	29
Cellular Connectivity	30
Cellular Modem Antenna Gain Specifications	30
MPE Safe Distance Statement	30
OM1200 antenna gain and collocated radio transmitter specifications	31
Device Reboot	32

INITIAL SETTINGS	33
Default Settings	33
Serial Port Settings	33
Browser WebUI	33
Using the WebUI	34
Management Console Connection via CLI	35
Accessing the WebUI CLI Terminal	35
Change the Root Password	36
Disable a Root User	38
Change Network Settings	39
Add a New Connection	39
Change the Ethernet Media Type	41
MONITOR MENU	43
System Log	43
LLDP CDP Neighbors	44
Triggered Playbooks	44
ACCESS MENU	45
Local Terminal	45
Serial Ports	46
Quick Search	47
Access Using Web Terminal or SSH	47
Serial Port Logging	48
Display Port Logs	48

CONFIGURE MENU	50
Serial Ports	50
Edit Serial Ports	50
Assigning Unique IP Addresses for Each Console Port	52
Configure Single Sessions for Ports	52
Single Session Enabled In the WebUI	53
In Config Shell	54
Single Session Behavior	56
Configure Raw TCP Access for Serial Ports	57
Service Implementation	57
WebUI Configuration	58
Config CLI Configuration	59
ogcli Configuration	61
Autodiscovery	61
Autodiscovery Enhancements	62
Cancel Autodiscovery	63
Schedule Autodiscovery	63
Retrieve Port Discovery Logs	64
Local Management Consoles	65
Lighthouse Enrollment	66
Manual Enrollment Using UI	67
Manual Enrollment Using the CLI	68
Automatic Enrollment By Lighthouse Service Portal (LSP)	68

LSP Service Initialization.....	69
LSP Commands.....	70
Restarting The Service.....	70
LSP Errors and Exit Codes.....	70
Accessing Lighthouse Service Portal.....	73
Register an account / log in to Lighthouse Service Portal.....	73
Dashboard.....	73
Permissions.....	73
ENROLLMENT SETTINGS.....	74
ASSETS.....	76
USER MANAGEMENT.....	76
Playbooks.....	79
Create Or Edit a Playbook.....	79
Monitor a current Playbook.....	83
PDU.....	84
Add and Configure a PDU.....	84
System Alerts.....	87
System Alerts - General.....	88
Authentication.....	88
Configuration Change.....	88
System Alerts - Power.....	88
Enable Power Supply Syslog Alerts.....	89
System Alerts - Temperature.....	90

Configure SNMP System Temperature Alerts.....	90
System Alerts - Networking (Connection Status).....	92
Configure Signal Strength Alerts.....	92
Network Connections.....	93
Network Interfaces.....	93
Dual SIM.....	94
Cellular Modem Firmware Upgrade.....	104
Bonds and Bridges.....	112
Spanning Tree Protocol.....	117
Configure a VLAN.....	120
IPsec Tunnels.....	123
Create, Add or Edit IPsec Tunnels.....	124
Static Routes.....	128
Configure Static Routes.....	129
Manage Static Routes via Command Line.....	131
Network Resilience.....	132
Out-Of-Band Failover.....	133
Enable Out-Of-Band Failover.....	133
DNS Queries on a Dormant Failover Interface.....	135
OOB Failover Types & Failover Behavior.....	136
IP Passthrough.....	137
User Management.....	139
Groups.....	140

Permission Changes in the Web UI.....	140
Understanding Access Rights.....	140
Understanding Serial Port Access.....	144
Create a New Group.....	147
Edit an Existing Group.....	149
Local Users.....	149
Create a New User With Password.....	150
Create a New User With No Password (Remote Authentication).....	151
Modify An Existing User Account With Password.....	152
Manage SSH Authorized Keys for a User Account.....	152
Delete a User Account.....	153
Remote Authentication.....	153
Configure RADIUS Authentication.....	155
Configure TACACS+ Authentication.....	156
Configure LDAP Authentication.....	158
Configure LDAP over SSL.....	160
LDAP and LDAPS Port Settings.....	161
Limitations for LDAPS Implementation.....	162
Local Password Policy.....	162
Set Password Complexity Requirements.....	162
Set Password Expiration Interval.....	164
Password Policy Implementation Rules.....	164
Services.....	166

FIPS Compliance.....	166
Configure FIPS.....	166
Considerations for Using the FIPS Feature.....	169
Brute Force Protection.....	171
Configure Brute Force Protection.....	172
Viewing Current Bans.....	173
Managing Brute Force Protection via Command Line.....	173
HTTPS Certificate.....	175
Network Discovery Protocols.....	177
Routing.....	179
Dynamic Routing.....	179
Static Routing (via the ogcli).....	180
OSPF Configuration.....	181
Wireguard Configuration.....	189
SSH.....	196
Unauthenticated SSH to Serial Ports.....	197
Syslog.....	202
Add a New Syslog Server.....	202
Global Serial Port Settings.....	203
Edit or Delete an Existing Syslog Server.....	205
Session Settings.....	206
File Server.....	207
Enable TFTP Service.....	208

Modify Firewall Zones to Allow the TFTP Service to be Used.....	208
Update the TFTP Service Storage Location.....	209
SNMP Service.....	210
SNMP Alert Managers.....	211
Multiple SNMP Alert Managers.....	212
Firewall.....	214
Firewall Guide.....	215
Introduction.....	215
Firewall Rules.....	216
Firewall Policies.....	216
Example WebUI Configuration.....	216
Custom Rules (firewalld “rich-rules”).....	218
Useful Templates for use in WebUI or CLI.....	219
Firewall Management.....	222
Firewall Zone Settings.....	222
Firewall Source Address Filtering.....	225
Firewall Source Address Bulk Services.....	226
Firewall Policies.....	227
Logging and Debugging Firewall Policies.....	233
Firewall Services.....	233
Adding WireGuard Zones to a Firewall.....	234
System.....	235
Administration.....	235

Date and Time Setting.....	237
Time Setting by NTP.....	237
Time Setting Manually.....	239
Factory Reset.....	240
Reset FROM THE WEBUI.....	240
Reset at the External Erase Button.....	241
Reset from the CLI Terminal.....	242
Reboot.....	242
Export/Restore Configuration.....	243
Export Configuration.....	243
Restore Configuration.....	245
Automated Rollback To Working Configuration.....	247
Lighthouse Node Backup.....	249
System Upgrade.....	250
Perform a System Upgrade.....	250
ADVANCED OPTIONS.....	252
Communicating With The Cellular or POTS Modem.....	252
Internal Modem (POTS).....	254
Configuring the POTS Modem (OM2200-10G-M-L).....	255
	256
Config CLI GUIDE.....	258
Navigation in Config CLI.....	259
Starting a Session in Config CLI.....	259

Exiting a Config CLI Session.....	259
Navigating the Config CLI.....	259
Understanding Fields, Entities and Contexts.....	260
Global & Entity-Context Commands.....	262
Global Context Commands.....	262
Entity Context Commands.....	263
Config CLI Entities.....	263
Supported Entities.....	264
Config CLI Commands.....	270
add.....	271
apply.....	271
changes.....	274
delete.....	275
diff.....	276
discard.....	278
edit.....	281
exit.....	282
help (or ?).....	282
import/export.....	284
show.....	287
up / exit /	291
Config CLI Use Case Examples.....	292
Adding a User.....	292

Configuring a Port.....	295
Configure a Single Session on a Port.....	296
Create or Configure a Loopback Interface.....	297
Configure NET1 Static IPV4.....	301
Configure NET2 Static IPV4.....	301
Configure NET3 Static IPV4 for OM2224-24e units.....	302
Configure WireGuard through Config Shell.....	302
Root User Password - cleartext.....	303
Root User Password = password via SHA256.....	303
Define Password Complexity Rules.....	304
Hostname.....	304
Contact Info.....	304
Time Zone and NTP.....	304
Create Admin User.....	305
Create Breakglass User (belongs to netgrp).....	305
Enable netgrp - Set to ConsoleUser.....	306
Change SSH Delimiiter to : default is +.....	306
Change Port Labels.....	306
Enable Tacacs - Set Mode to remotelocal.....	307
Enable Ildp on Net1 & Net2.....	307
Enable tftp.....	307
Enable Boot Messages.....	307
Define Session Timeouts.....	308

Define MOTD.....	308
Enable SIMM 1 Enable and Add APN.....	308
Enable SIMM 1 Complete End Points.....	309
Enable Failover.....	310
Add a Syslog Server.....	310
Set Port Logging Remote Syslog Settings.....	311
Enable System Monitor SNMP Traps.....	311
Enable SNMP V2 Service for Polling.....	312
Enable 2 SNMP Traps and Trap Servers.....	312
Create a StaTic Route.....	313
Edit LAN (Net2) Firewall Zone.....	313
Edit WAN (Net1) Firewall Zone.....	313
Custom_rule Example for Port and Protocol.....	314
Enroll Into Lighthouse.....	314
How Changes Are Applied or Discarded.....	315
Applying or Discarding Changes.....	315
Multi-Field Updates.....	317
Description.....	317
Example.....	317
Error Messages.....	318
Error Messages.....	320
String Values In Config Commands.....	321
Description.....	321

Example.....	321
Error Messages.....	322
Opengear CLI Guide.....	323
Getting Started with ogcli.....	323
Access ogcli Help and Usage Information.....	324
Basic Syntax.....	325
ogcli Operations.....	325
Supplying Data To ogcli.....	326
Here Document.....	326
Inline Arguments.....	327
Pipes and Standard Input.....	327
Quoting String Values.....	327
Tab Completion.....	328
Displaying Secrets in ogcli.....	328
Common Configuration Examples.....	330
Compare Current Configuration with a Proposed Configuration.....	331
Using the diff Tool.....	331
Configure a DNS.....	339
Advanced Portmanager PMShell Guide.....	342
Running pmshell.....	342
pmshell Commands.....	342
Custom Control Codes for Serial Ports.....	343
Configure Custom Control Codes.....	344

Configure Control Codes for a Specified Port (CLI Examples).....	344
Configure a Control Code Value for All Ports.....	345
Control Codes for All Ports via CLI (Examples).....	345
Docker.....	346
Cron.....	346
Initial Provisioning via USB Key.....	348
EULA and GPL.....	349
UI BUTTON DEFINITIONS.....	350

COPYRIGHT ©

Opengear Inc. 2025. All Rights Reserved.

Information in this document is subject to change without notice and does not represent a commitment on the part of Opengear. Opengear provides this document “as is,” without warranty of any kind, expressed or implied, including, but not limited to, the implied warranties of fitness or merchantability for a particular purpose.

Opengear may make improvements and/or changes in this manual or in the product(s) and/or the program(s) described in this manual at any time. This product could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes may be incorporated in new editions of the publication.

DOCUMENT REVISION HISTORY

Release Date	Software Version	Description Of Changes
June 2025	24.11.5	<ul style="list-style-type: none"> Added note to the Connecting to the Network topic around not supporting Copper and SFP connections at the same time. Minor updates to the structure of the user guide to make content easier to find and more user friendly.
May 2025	24.11.4	<ul style="list-style-type: none"> Updates to style and format. The Configure Radius Authentication procedure in the Remote Authentication section is updated to include a new step for message authenticator. Updates to include information for serial SSH base ports has been added to SSH and Unauthenticated SSH to Serial Ports. A new Accessing Lighthouse Service Portal procedure is added to the Lighthouse Enrollment topic. The Installing a new SIM card procedure on the Cellular Connectivity and Dual SIM topics has had a minor update.
Feb 2025	24.11.3	<ul style="list-style-type: none"> Audit, review and update of main sections of the User Guide LDAP over SSH added to Remote Authentication

Release Date	Software Version	Description Of Changes
Dec 2024	24.11.2	<p>Updates to the following topics:</p> <ul style="list-style-type: none">• Interzone Policies• SNMP Service• Remote Authentication• SNMP Alert Managers• PDUs
Nov 2024	24.11.1	<ul style="list-style-type: none">• Config Diff tool updated in Ogcli Guide & Config CLI Guide• Config Rollback (automated) feature added• Factory Reset (Erase) procedure updated

SAFETY & FCC STATEMENT

SAFETY STATEMENT

Please take care to follow the safety precautions below when installing and operating the Operations Manager:

- Do not remove the metal covers. There are no operator serviceable components inside. Opening or removing the cover may expose you to dangerous voltage which may cause fire or electric shock. Refer all service to Opengear qualified personnel.
- To avoid electric shock the power cord protective grounding conductor must be connected through to ground.
- Always pull on the plug, not the cable, when disconnecting the power cord from the socket.

Do not connect or disconnect the appliance during an electrical storm. Also use a surge suppressor or UPS to protect the equipment from transients.

FCC WARNING STATEMENT

This device complies with Part 15 of the FCC rules. Operation of this device is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may cause undesired operation.



Proper back-up systems and necessary safety devices should be utilized to protect against injury, death, or property damage due to system failure. Such protection is the responsibility of the user.

This device is not approved for use as a life-support or medical system.

Any changes or modifications made to this device without the explicit approval or consent of Opengear will void Opengear of any liability or responsibility of injury or loss caused by any malfunction.

This equipment is for indoor use and all the communication wiring are limited to inside of the building.


ABOUT THIS USER GUIDE

This user guide is up to date for the 24.11.5 firmware release. When using a minor release there may or may not be a specific version of the user guide for that release.

INSTALLATION AND CONNECTION

This section describes how to install the appliance hardware and connect it to controlled devices.

The following example image shows an OM2200 Device.



Operations Manager Features:

- | | |
|---|--------------------------|
| 1. Serial ports
Number of serial ports varies per model. | 7. Config erase button |
| 2. RJ45 serial console | 8. SIM card slots |
| 3. Front USB ports | 9. Cell (main) |
| 4. NET1 and NET2 (1G SFP and Copper)
Combination network interfaces allow either SFP or Copper to be used. | 10. Cell (aux) |
| 5. LED indicators | 11. GPS |
| 6. USB serial console | 12. USB serial ports |
| | 13. Dual AC power supply |

POWER CONNECTION

Operations Manager devices may be powered by either AC or 12V DC power supply (DDC models have dual DC terminals).

The OM1200 is available with 12V DC power only.

Note: Dual DC Power Supply. DDC models have a dual DC power supply with screw-in DC terminals (supplied).

AC Powered Operations Manager have dual power inlets with auto failover built in. These power supplies each accept AC input voltage between 100 and 240 VAC with a frequency of 50 or 60 Hz. The OM2224-24E-10G-L draws a maximum of 48W, while non-24E are less than 30W.

Two IEC AC power sockets are located on the power side of the metal case, and these IEC power inlets use conventional IEC AC power cords.

Note: Country specific IEC power cords are included with the AC Operations Manager.

See also ["Dual Power Supply" on page 25](#) and ["System Alerts - Power" on page 88](#).

Operations Manager Platform (OM2200) Environmental And Power	
Power Supply	Dual AC or 12V DC
Power Draw	48 Watts for -24E, others <30W
Operating conditions	Temperature 5~50C, Rel Humidity 5~90%
Cooling	Passive

Environmental Sensors	Smart Controller with multi-zone temperature sensors.
	Supervisory environmental controller with safety power down.
Power Draw Sensors	Active multi-zone power draw monitoring.

DC POWERED OM1200

All OM1200 devices are shipped with a 12VDC to universal AC (multi-country clips) wall adapter and a barrel-jack connector. Additional AC to DC adapters may be ordered.

Operations Manager Platform (OM1200) Environmental And Power	
Power Supply	12V DC
Power Draw	< 25 Watts
Operating conditions	Temperature 5~50C, Rel Humidity 5~90%
Cooling	Passive
Environmental Sensors	Smart Controller with multi-zone temperature sensors.
	Auto-shutdown/re-boot on severe thermal events.
Power Draw Sensors	Active multi-zone power draw monitoring.

DUAL POWER SUPPLY


Dual Power Supply, including Dual DC (DDC) can provide power redundancy for devices, especially those that may operate in harsher environments. A secondary power supply provides redundancy for the device if one PSU is unplugged or in the event of a failure.

LED POWER STATUS INDICATOR

The power LED indicator requires no configuration and displays the dual power status on any Operations Manager device with a dual power supply.

Note: OM1200 and CM devices have displays with four LEDs. The OM2200 devices have displays with six LEDs that include Lighthouse (Cloud) and Network status. See ["Device Status LEDs" on the next page](#) for LED definitions.

On a device with a **single** PSU (power supply unit) *or*, a **dual** PSU device has power connected to *two* PSUs, the LED power status indicator should be green at all times.



If a **dual** PSU device has power connected to *one* PSU (power supply unit), the LED power status indicator is colored amber to indicate that the unit has no redundancy in the event of a power failure.



SNMP ALERTS FOR POWER-RELATED EVENTS





The System Voltage Range SNMP alert is:


- triggered when there is a change in power status such as a system reboot or when the voltage on either power supply leaves or enters the configured range of the System Voltage alert.
- configured in the Configure > SNMP Alerts page, see ["System Alerts - Power" on page 88](#).

DEVICE STATUS LEDS

The LED states shown in the following table are determined through user-configurable threshold values for the Cell LED Amber / Green light, and modem enabled / disabled information.

Status LEDs					
LED Condition					
	LED Off	Amber Flashing	Amber Solid	Green Flashing	Green Solid

Power 	Device is off.		On a dual power supply system: Only one PSU is connected.		On a single power supply system: The power is connected. On a dual power supply system: Redundant power is connected.
Heartbeat 	Device has halted.	Device is booting.		Normal operation.	Device is halted.
Network 	No active network connection	Device is failover starting.	Device is in failover.	Normal network connection is stopping, or normal network is up and failover is stopping.	Network is connected.
Cellular Interface 	Cellular is not in use.	Cell is starting and signal is below threshold. The LED signal threshold config is set to 50%.	Cell is connected and signal is below threshold. The LED signal threshold is set to 50%.	The cell is starting and signal is above, or equal to the threshold.	Cell is connected. and signal is above, or equal to the threshold.

<p>IOIO</p> <p>IOIO</p>				<p>Any serial activity is received, on either console/usb console or device serial ports.</p>	
<p>OM Devices</p> <p>Cloud / Internet</p> 	<p>LSP is disabled and there are no existing Lighthouse enrollments.</p>	<p>LSP is currently running on the device.</p>	<p>An error occurred while running LSP.</p>	<p>The device can reach the lighthouse instance and is attempting to enroll. If a lighthouse is unreachable the LED will not start.</p>	<p>The device is enrolled and connected to a lighthouse. There will be a short delay between the UI status reported and the LED changing to solid green.</p>

Note:

- The amber LED signal threshold configuration is set to 50%.of normal signal strength.
- OM1200 series devices do not have a cloud LED, therefore, no LED indication is available for LSP or Lighthouse.

For information on the setting of network and power alert thresholds, see:

- ["System Alerts - Networking \(Connection Status\)" on page 92](#)
- ["System Alerts - Power" on page 88](#)

CONNECTING TO THE NETWORK

All Operations Manager products have two network connections labeled NET1 and NET2. In the OM2200 there are options for copper wiring (on a standard RJ-45 connector) and fiber (through a standard SFP module).

The network connections on the OM2200 are located on the serial port side of the unit. Connect the provided shielded CAT5 cable to the NET1 to a computer or into your network for initial configuration. By default, NET1 and NET2 are enabled.

You can use either 10/100/1000BaseT over Cat5 or fiber-optical transceiver (1Gbps) in the SFP slot for NET1 or NET2 on OM2200 (non-10G) and OM1208-8E.

Note: We do not support connecting both copper (RJ-45) and fiber (SFP) at the same time on the same interface.

SERIAL CONNECTION

Note: X1 and X2 are Opendgear specific labels, where X2 = Cisco straight and X1 = Cisco reversed.

OM1200

Serial Ports: The serial connections feature RS-232 (Cisco straight -X2). Connect serial devices with the appropriate STP cables.

Console Ports: RJ45 RS232 Cisco straight X2 pinout serial ports

Local Console Port: Serial Port 1 is the default local console port.

OM2200

Serial Ports: RJ45 RS-232 Console Port (50 to 230,400 bps, software selectable Cisco-straight or Cisco-rolled pinout)

Local Console Ports: 1 x micro USB 2.0 Console Port and 1 x RJ45 Serial (Straight Pinout)

CELLULAR CONNECTIVITY

Operations Manager products offer an optional global cellular LTE interface (models with -L suffix). The cellular interface is certified for global deployments with most carriers and provides a CAT12 LTE interface supporting most frequencies in use. To activate the cellular interface, you should contact your local cellular carrier and activate a data plan associated to the SIM installed.

INSTALLING A NEW SIM CARD

When you install a new SIM card into its slot while the appliance is active (hot swapping), it may take a minute or two for the system to react and stabilize after the SIM card change.

Two SIM card slots are located on the rear face of the device, insert each SIM card(s) into its respective slot (marked 1 and 2) until you feel the card click into place.



CELLULAR MODEM ANTENNA GAIN SPECIFICATIONS

MPE SAFE DISTANCE STATEMENT

Opengear cellular products are intended for use 28cm or more from the body. This meets limits for Maximum Permissible Exposure (MPE) and is the minimum safe distance.

OM1200 ANTENNA GAIN AND COLLOCATED RADIO TRANSMITTER SPECIFICATIONS

OM1200 Cellular Modem Frequency

Antenna Gain and Collocated Radio Transmitter Specifications							
Note: The radiated power of a collocated transmitter must not exceed the EIRP limits stipulated in this table.							
	Operating mode	Tx Freq Range (MHz)		Max Time-Avg Cond. Power (dBm)	Antenna Gain Limit (dBi)		EIRP Limits (dBm)
					Standalone	Collocated	
EM7565 Embedded Module	WCDMA Band 2, LTE B2	1850	1910	24	6	4	30
	WCDMA Band 4, LTE B4	1710	1755	24	6	4	30
	WCDMA Band 5, LTE B5	824	849	24	6	4	30
	LTE B7	2500	2570	23.8 (a)	9	4	32.8
	LTE B12	699	716	24	6	4	30
	LTE B13	777	787	24	6	4	30
	LTE B26	814	849	24	6	4	30
	LTE B41	2496	2690	23.8 (a)	9	4	32.8
	LTE 848 (b)	3550	3700	23	0	0	23
	LTE B66	1710	1780	24	6	4	30
EU Band Support	WCDMA Band 1, LTE B1	1920	1980	24			24
	LTE B3	1710	1785	24			24
	LTE B7	2500	2570	23			24
	WDCMA band 8, LTE B8	880	915	24			24
	LTE B20	832	862	24			24
	LTE B28	703	748	24			24
Table Notes:							
(a) Includes 0.8 dB offset from single-cell tolerance for UL CA							
(b) Important. Airborne operations in LTE Band 48 are prohibited							
Additional Supported Bands Band 42 and 43 TDD							
NOTE: UMTS band III is disabled for this product							

OM2200 antenna gain and collocated radio transmitter specifications

OM2200 Cellular Modem Frequency							
Antenna Gain and Collocated Radio Transmitter Specifications							
Note: The radiated power of a collocated transmitter must not exceed the EIRP limits stipulated in this table.							
	Operating mode	Tx Freq Range (MHz)		Max Time-Avg Cond. Power (dBm)	Antenna Gain Limit (dBi)		EIRP Limits (dBm)
					Standalone	Collocated	
EM7565 Embedded Module	WCDMA Band 2, LTE B2	1850	1910	24	6	4	30
	WCDMA Band 4, LTE B4	1710	1755	24	6	4	30
	WCDMA Band 5, LTE B5	824	849	24	6	4	30
	LTE B7	2500	2570	23.8 (a)	9	4	32.8
	LTE B12	699	716	24	6	4	30
	LTE B13	777	787	24	6	4	30
	LTE B26	814	849	24	6	4	30
	LTE B41	2496	2690	23.8 (a)	9	4	32.8
	LTE 848 (b)	3550	3700	23	0	0	23
EU Band Support	LTE B66	1710	1780	24	6	4	30
	WCDMA Band 1, LTE B1	1920	1980	24			24
	LTE B3	1710	1785	24			24
	LTE B7	2500	2570	23			24
	WCDMA band 8, LTE B8	880	915	24			24
	LTE B20	832	862	24			24
Table Notes:							
(a) Includes 0.8 dB offset from single-cell tolerance for UL CA							
(b) Important. Airborne operations in LTE Band 48 are prohibited							
Additional Supported Bands Band 42 and 43 TDD							
NOTE: UMTS band III is disabled for this product							

DEVICE REBOOT

When the Operations Manager reboots, all settings (e.g. the assigned network IP address) are preserved.

To reboot the unit, select **CONFIGURE > System > Reboot**.

To conduct a full erase and factory reset, see ["Factory Reset" on page 240](#)

Note: Factory reset restores the appliance to its factory default settings. Any modified configuration information is erased.

INITIAL SETTINGS

This section provides step-by-step instructions for the initial settings on your Operations Manager. By default, all interfaces are enabled. The unit can be managed via Web UI or by command line interface (CLI).

Tip: There is also a Quick Start Guide to assist with easy setup of the Operations Manager. The QSG is available at: <https://opengear.com/support/documentation/>

Note: For Configure Serial Ports (see "[Serial Ports](#)" on page 50)

DEFAULT SETTINGS

Tip: See also the Quick Start Guide available at the Opengear documentation web page: <https://opengear.com/support/documentation/>

The Operations Manager comes configured with a default static IP Address for NET1 of 192.168.0.1 Subnet Mask 255.255.255.0.

SERIAL PORT SETTINGS

The default settings for the serial ports (1 up to 48) on a new device are:


The default settings for the serial ports (4 up to 8) on a new device are:

“Console server” mode, 9600, 8N1, X2 (Cisco straight) pinout; the escape character is “~”.

BROWSER WEBUI

The Operations Manager offers a WebUI via any web browser that supports HTML5.

1. Type `https://192.168.0.1` in the address bar.
HTTPS is enabled by default.
2. Enter the default username and password:
Username: root
Password: default
3. After the first successful log in, you are required to change the root password.
4. After log in the WebUI is available; check the system details in the top right-hand side of the WebUI.
5. In the Navigation Bar on the left side, navigate to the **ACCESS > Serial Ports** page.
The **Serial Ports** page displays a list of all the serial devices, including the links to a Web Terminal or SSH connection for each.



USING THE WEBUI


You can adjust the toggle on the bottom left to switch the WebUI between the following modes:

- **Light:** Changes the user interface to display mostly light colors. This is the default UI setting.
- **Dark:** Changes the user interface to display mostly dark colors, reducing the light emitted by device screens.



The WebUI has three menu options on the upper-right:

- **Help:** The **Help** menu contains a link to generate a **Technical Support Report** that can be used by Opengear Support for troubleshooting. It also contains a link to the latest User Guide.
- **System:** The System menu presents the **Current version**, **REST API version**, **Hostname**, **Serial Number**, **Model**, and **Current user**.



- **Log out**

MANAGEMENT CONSOLE CONNECTION VIA CLI

The Command Line Interface (CLI) is accessible using your preferred application to establish an SSH session.


1. Open a CLI terminal on your desktop.
2. Input the default IP Address of *192.168.0.1*.
SSH port 22 is enabled by default.
3. When prompted, enter the log in and password in the CLI.
After a successful log in, you'll see a command prompt.

ACCESSING THE WEBUI CLI TERMINAL

An alternative CLI terminal is provided within the WebUI.

To access this terminal, in the left-hand side **Navigation Bar**, navigate to the **ACCESS > Local Terminal** page.

You are required to submit your log in credentials.



CHANGE THE ROOT PASSWORD

For security reasons, only the root user can initially log in to the appliance. On initial login the default password must be changed.


Passwords must comply with your company's password complexity policy. See ["Local Password Policy" on page 162](#)

Note: Users are prevented from reusing the word “default” as their password. The factory default password automatically expires after a factory reset and users must choose a new password. This policy is applied through the WebUI, Config Shell and CLI.

Tip: Any other user's passwords may be changed using the same procedure by selecting the user's account name under the **Username** heading.

To change the password at any time:

1. Navigate to **CONFIGURE > User Management > Local Users**.
2. Under **Actions**, click the **Edit User** icon for the user.



3. In the **Edit User** page, if required:
 - Enter an optional description in the **Description** field.
 - Enter a new password in the **Password** field.
 - Re-enter the password in the **Confirm Password** field.

EDIT USER

☒ User Enabled

Username
 testuser1

Description
 Root password control

Password ⓘ

Confirm Password ⓘ

☒ SSH Password Enabled ⓘ

Cancel

Save User

- Click **Save User**.

A green banner confirms the password change is saved.

DISABLE A ROOT USER

Before you proceed, make sure that another user exists that has the Administrator role or is in a group with the Administrator role. For information on how to create, edit, and delete users, see ["Local Users" on page 149](#)

To disable a root user:

- Navigate to **CONFIGURE > User management > Local Users**.
- Under **Actions**, click the **Disable User** button next to the root user.
- Click **Yes** in the **Confirmation** dialog.

To enable root user, log in with another user that has the Administrator role and click the **Enable User** button in the **Actions** section next to the root user.


CHANGE NETWORK SETTINGS

The interface supports both IPv4 and IPv6 networks. The IP address of the unit can be setup for Static or DHCP. The following settings can be configured for network ports:


- IPv4, IPv6.
- Static and/or DHCP.
- Enabling or disabling network interfaces.
- Ethernet Media types.

ADD A NEW CONNECTION

1. Click **CONFIGURE > Network Connections > Network Interfaces**.



2. Click the **expand arrow** to the right of the required interface to view its details.
3. Click the **plus icon** to open the **New Connection** page.




4. Select the **Interface** and **Connection Type** for your new connection.
The form on the bottom part of the page changes based on the **Connection Type** you choose.
5. To disable or delete interfaces, use the controls on the expanded section on the **CONFIGURE > Network Connections > Network Interfaces** page.
6. Enter the necessary information and click **Apply**.


Note: If you experience packet loss or poor network performance with the default auto-negotiation setting, try changing the Ethernet Media settings on the Operations Manager and the device it is connected to. In most cases, select 100 megabits, full duplex. Make sure both sides are set identically.

CHANGE THE ETHERNET MEDIA TYPE

1. Click **CONFIGURE** > **Network Connections** > **Network Interfaces**.



2. Click the **expand arrow** to the right of the interface you want to modify.



3. Click **Enabled**.

4. To change the interface media setting, click the **Edit** button and edit the media settings as required, then click **Apply**.

EDIT NET1 - 1G COPPER/SFP

☒ Interface Enabled

Media (Copper only) ?

Automatic

Automatic
 10M Half Duplex
 10M Full Duplex
 100M Half Duplex
 100M Full Duplex
 1000M Half Duplex
 1000M Full Duplex

Name Server ?

No name servers have been set

+ Add Name Server

Search Domain ?

No search domains have been set

+ Add Search Domain

Cancel

Apply


MONITOR MENU

The MONITOR Menu is a relatively short section comprising only three topics.

SYSTEM LOG

The Operations Manager maintains a log of system activity, access, and communications events with the server and with attached serial, network and power devices.

To view the System Log, click **MONITOR > System Log**.



MONITOR

System Log

LLDP/CDP Neighbors

Triggered Playbooks

ACCESS

CONFIGURE

SYSTEM LOG

DISPLAY OPTIONS

Number of Log Lines

100

The number of log lines to display

Apply

LOG DATA

```

2020-04-17T02:06:25.791551+00:00 om2248-1 charon-systemd[1458]: sending packet: from 192.168.1.13[500] to 192.168.1.131[500] (792 bytes)
2020-04-17T02:06:25.791912+00:00 om2248-1 charon-systemd[1458]: error writing to socket: Network is unreachable
2020-04-17T02:06:25.881899+00:00 localhost [modem-watcher] Failed to get signal quality via QMI
2020-04-17T02:06:28.859107+00:00 localhost [modem-watcher] Failed to get signal quality via QMI
2020-04-17T02:06:31.867190+00:00 localhost [modem-watcher] Failed to get signal quality via QMI
2020-04-17T02:06:32.991608+00:00 om2248-1 charon-systemd[1458]: retransmit 2 of request with message ID 0
2020-04-17T02:06:32.992375+00:00 om2248-1 charon-systemd[1458]: sending packet: from 192.168.1.13[500] to 192.168.1.131[500] (792 bytes)
2020-04-17T02:06:32.992716+00:00 om2248-1 charon-systemd[1458]: error writing to socket: Network is unreachable
2020-04-17T02:06:34.874617+00:00 localhost [modem-watcher] Failed to get signal quality via QMI
2020-04-17T02:06:37.850348+00:00 localhost [modem-watcher] Failed to get signal quality via QMI
2020-04-17T02:06:40.858736+00:00 localhost [modem-watcher] Failed to get signal quality via QMI
2020-04-17T02:06:43.867096+00:00 localhost [modem-watcher] Failed to get signal quality via QMI
2020-04-17T02:06:45.952538+00:00 om2248-1 charon-systemd[1458]: retransmit 3 of request with message ID 0
2020-04-17T02:06:45.953146+00:00 om2248-1 charon-systemd[1458]: sending packet: from 192.168.1.13[500] to

```

The System Log page lets you change the Number of Log Lines displayed on the screen. The newest items appear on the bottom of the list. Click the **Refresh** button on the bottom right to see the latest entries.

LLDP CDP NEIGHBORS

The Operations Manager displays LLDP/CDP Neighbors when enabled for a connection. See ["Network Discovery Protocols" on page 177](#) to enable/disable.

The screenshot shows the 'MONITOR' tab selected in the left sidebar. The main content area is titled 'LLDP/CDP NEIGHBORS'. It contains two sections: 'LLDP/CDP NEIGHBORS' and 'LLDP/CDP SELF'. The 'LLDP/CDP NEIGHBORS' section displays a table with columns: Local Interface, Remote Name, Chassis Mac, Management IP, Remote Port Name, and Remote Port Mac. The table is currently empty, showing 'No Neighbors discovered'. The 'LLDP/CDP SELF' section displays a table with columns: Local Name, Chassis Mac, and Management IP. The table contains one entry: Local Name: om2248-l.fios-router.home, Chassis Mac: 00:13:c6:08:0e:37, and Management IP: 192.168.0.1. A refresh button is located at the bottom right of the 'LLDP/CDP SELF' section.

TRIGGERED PLAYBOOKS

For information on creating **Playbooks**, see the [Playbooks](#) topic in this User Guide.

To monitor current **Playbooks**, click on **Monitor > Triggered Playbooks**. Choose the time period if required, and filter by **Name** of **Playlist** to view any that have been triggered.

The screenshot shows the 'MONITOR' tab selected in the left sidebar. The main content area is titled 'TRIGGERED PLAYBOOKS'. It displays a list of triggered playbooks. One entry is visible: 'Login AR test' with a checkmark icon and the text 'Triggered: 14 hours ago'. A tooltip 'Filter the Playbook Log' is shown above the list. On the right side, there are two filter options: 'From Last' with a dropdown menu and 'Filter by Playbook Name' with a text input field. The 'Triggered Playbooks' option in the left sidebar is highlighted with a red box.


ACCESS MENU

The ACCESS menu provides access to Local Terminal of the Operations Manager. It also provides SSH and Web Terminal access to specific ports.

LOCAL TERMINAL

The Operations Manager includes a web-based terminal. To access this bash shell instance:

1. Select **ACCESS > Local Terminal**.



2. At the login prompt, enter a username and password.

A bash shell prompt displays.

This shell supports most standard bash commands and also supports copy-and-paste to and from the terminal.


To close a terminal session, close the tab, or type exit in the Web Terminal window. The session times out after 60 seconds.

Tip: The default for the CLI session timeout is “never” (value of 0), however, the Web session timeout defaults to 20 minutes. The web session time-out kills the CLI session even though the CLI session itself is set to “never”.

SERIAL PORTS

The **ACCESS > Serial Ports** page allows you to quickly locate and access specific ports via Web Terminal or SSH link shown in the following image.

Tip: Ensure you are on the **ACCESS > Serial Ports** page and not the similar **CONFIGURE > Serial Ports** page.



Callout #	Item Definition
1	Serial port edit button.
2	Counter reset.
3	Serial port Data, Rx & Tx counters. Signaling status (RTS, DTR, DSR, DCD), requires refresh.
4	Web terminal and SSH links.
5	Expand arrow to display logging status.

Click the **Expand arrow (5)** to the right of the port to see the Port Logging status or access the port **Edit** button, which is a link to the **CONFIGURE > Serial Ports** page (ogcli: `ogcli get ports/ports_status`).

The following information displays under **Access > Serial Ports** when the individual serial ports are expanded:

- Rx byte counter (counter reset requires 'Admin' or 'port config' rights)
- Tx byte counter (counter reset requires 'Admin' or 'port config' rights)
- Signaling information (DSR, DTR, CTS (see tip), RTS and DCD)

Tip: CTS information is not displayed in the UI but is available via the ogcli query `ogcli get ports/ports_status`.

- Logging information.

QUICK SEARCH

To find a specific port by its port label, use the **Quick Search** form at the top-right of the **ACCESS > Serial Ports** page.

Ports have default numbered labels. You can edit the port label for a given serial port under **CONFIGURE > Serial Ports**. Click the **Edit** button to open the **EDIT SERIAL PORT** page.

ACCESS USING WEB TERMINAL OR SSH

To access the console port via the Web Terminal or SSH:

1. Locate the particular port on the **ACCESS > Serial Ports** page and click the expand arrow.
2. Click the **Web Terminal** or **SSH** link for the particular port.
 - Choosing **Web Terminal** opens a new browser tab with the terminal.
 - Choosing **SSH** opens an application you have previously associated with SSH connections from your browser.


Note: MS Windows does not connect to puTTY by default. You may have to install the WinSCP program to launch puTTY from the Opengear WebUI SSH Serial Port button.

SERIAL PORT LOGGING

The port logging facility and severity associated with the serial port logs is controlled and set at the **Configure > Services > Syslog > Global Serial Port Settings** page.

There is a separate setting to enable sending of serial port logs to remote side.

Note: Serial port logging is disabled by default. The logging level for each serial port is set at Logging Settings in **Configure > Serial Ports > Edit** .




LOGGING SETTINGS


Logging Level

- ✓ Logging Disabled
- Events Only
- Events and Received Characters
- Events and All Characters

DISPLAY PORT LOGS

Tip: The log is accessed by clicking the **Port Log** link on the **ACCESS > Serial Ports** page. The link is only available when port logging is enabled.

 **Port-1**
Port-1, 9600-8-N-1-X2

 Edit

LOGGING LEVEL	ESCAPE CHARACTER
Events Only	~
Port Log	

Port Log Link

CONFIGURE MENU

This section provides step-by-step instructions for the menu items under the CONFIGURE menu.

SERIAL PORTS

Tip: Ensure you are on the **CONFIGURE > Serial Ports** page and not the similar **ACCESS > Serial Ports** page.

Navigate to **CONFIGURE > Serial Ports**; a list of serial ports displays. On this page you can configure and edit specific ports. Click the **Edit** button (pencil icon) to the right of the port to display the port editing page.

SERIAL PORTS Last Serial Port Autodiscovery run Nov 4, 2022 [Log file](#)

Perform Manual Autodiscovery

Schedule Autodiscovery

Edit Serial Port

<input type="checkbox"/>	Port #	Label	Mode	Parameters	Port Pinout
<input type="checkbox"/>	1	Port-1	Console Server	9600-8-N-1	X2
<input type="checkbox"/>	2	Port-2	Console Server	9600-8-N-1	X2
<input type="checkbox"/>	3	Port-3	Console Server	115200-8-N-1	X1
<input type="checkbox"/>	4	Port-4	Console Server	115200-8-N-1	X2
<input type="checkbox"/>	5	Port-5	Console Server	9600-8-N-1	X2
<input type="checkbox"/>	6	Port-6	Console Server	9600-8-N-1	X2

Note: In the original image, a red box highlights the 'Port-2' label, and a callout points to it with the text 'Edit Serial Port'.

EDIT SERIAL PORTS

From the **Configure > Serial Ports** page, click the **Port label** text in the Label column. The **Edit Serial Port** page displays.

Edit Serial Port Properties		
Field	Options	Definition
Label	Default or Custom	The serial port unique identifier. This can be used to locate this port using the Quick Search form on the ACCESS > Serial Ports page.
Mode	Disabled Console Server Local Console	Console Server mode allows access to a downstream device via its serial port. Local Console mode allows access to the OM device's console through a serial port.
Port Pinout	Cisco Rolled Cisco Straight	Select pin-out type depending on the type of device or host to be connected via the port.
Baud Rate	Baud rate	Select the Baud rate expected for this port. From 50 to 230,400 bps.
Data Bits	Integer	The data bit length for character.
Parity	None, Odd, Even, Mark, Space.	The parity type for character.
Stop Bits	1, 1.5, 2	The Stop bit length used in character.
Escape Character	~	The character used for sending OOB Shell commands.
LOGGING SETTINGS		

Logging Level	Disabled Events Only Events & Received Characters Events & All Characters	Specify the level of detail you require in the logs. Logs may also be sent to a Syslog server. Other settings to consider are: "GLOBAL SERIAL PORT SETTINGS" under Services > Syslog. "Send Serial Port Logs" under Services > Syslog > Add Syslog Server
PORT IP ALIASES		
IP Address	Alias IP Address and interface type.	Allocate an IP address for dedicated access to a specific serial port.

ASSIGNING UNIQUE IP ADDRESSES FOR EACH CONSOLE PORT

Note: For further information about assigning unique IP addresses for each console port see the Knowledge Base article [Configure IP alias for serial ports](#).


CONFIGURE SINGLE SESSIONS FOR PORTS

Single Session Port Config, or *Single Session* is a feature that can be enabled on a given port to prevent multiple users from connecting to that port or limit the port to a single concurrent connection. This feature is port-specific and is disabled by default. This feature must be enabled on a port-by-port basis. It can be enabled on all types of serial ports (including USB).


Similar to Config Shell, a single session must be enabled or disabled on a port-by-port basis, currently it cannot be enabled on all ports.

SINGLE SESSION ENABLED IN THE WEBUI

Single Session can be viewed and configured in the WebUI. It is enabled (or disabled) in the configure page for a given serial port. The buttons to connect to a serial port are automatically disabled when the feature is enabled and the session is in use.



You can also confirm the session in the **Access > Serial Ports** page to check if the feature is enabled.




When the Single Session feature is enabled and the port is in use, if a subsequent user attempts to connect to the port, the connection is declined, and the second user receives the following message:


```
Unable to connect. Another session is currently active.
Please disconnect from the current session before attempting to connect again.
```

The pmshell exits, and the user who tried to connect does not see the first user's session. Everything they have done remains confidential.

The single session is indicated next to the user



If necessary, a user's single session can be terminated with the **Terminate all sessions** button which is shown beside individual users. This re-enables the **Single Session** button and allows you to connect.



IN CONFIG SHELL

The Single Session feature can be enabled or disabled by editing the `single_session` field of a port. When a user port level Administrator access is logged in via pmshell, the port configuration menu can be accessed via any port by pressing the escape character (~ by default) followed by c (~c).

You can access a port with the following commands, the following example will access “Port 1”:

```
config: port
config(port): port01
```

The port configuration might look like the following example. You can see for this port, `single_session` is set to `false`, so the feature is disabled:

```
config(port port01): show
Entity port item port01
    baudrate 9600
    databits 8
    escape_char ~
    label Port-1
    logging_level disabled
    mode consoleServer
    parity none
    pinout X2
    portnum 1
    single_session false
    stopbits 1
    control_code (object)
        break ""
        chooser ""
        pmhelp ""
        portlog ""
        power ""
        quit ""
    ip_alias (array)
```

The feature is enabled by typing `single_session true`, then apply the change.

```
config(port port01): single_session true
config(port port01): apply
Updating entity port item port01.
config(port port01): show
Entity port item port01
```

```

    baudrate 9600

...

single_session true

...

ip_alias (array)

```

SINGLE SESSION BEHAVIOR

The following table describes single session feature behavior in various circumstances.

Q.	What occurs if users are connected to the port with the feature disabled, then the feature is enabled while users are still connected?
A.	Users who are already connected will continue to be able to use the port. If they leave, they will not be able to rejoin (unless there are no active sessions). Their current session will continue as normal, however, their session can be manually terminated from Config Shell (config(port_session):) or from the WebUI from the Access/Serial Ports page.
Q.	What if a user must be removed from a port?
A.	Administrators can remove the right for a given user to access a port. They can also manually remove them from the port in the Config Shell (config(port_session):) or the WebUI from the Access > Serial Ports page.
Q.	What if someone tries to join a port that is already in use?
A.	The user who tries to join is prevented from doing so and receive a notification. The person currently using the port is unaffected and not be aware of the attempt.
Q.	Is there a way to enable the feature for every port?
A.	Currently, the feature must be enabled or disabled on a port-by-port basis.
Q.	What if I enable this port on localConsole mode?
A.	The feature is ignored on local console mode and is only active for Console Server mode. It also remains ignored if the port mode is set to disabled.

CONFIGURE RAW TCP ACCESS FOR SERIAL PORTS

The Raw TCP Access feature is an option under the ports endpoint and provides a means of accessing serial ports directly through netcat (nc), or Telnet.

Note: Raw TCP can only be enabled when the port is in **consoleServer** mode.

Raw TCP is enabled or disabled through the WebUI, Config Shell, or through ogcli. When enabled, Raw TCP will open a TCP socket on a TCP port in the range of 40XX, where XX corresponds to the serial port number on which Raw TCP access is enabled. Any TCP messages sent to this port are relayed to the corresponding serial port.

The Operations Manager serial ports can be configured to operate in Raw TCP mode on a port-by-port basis.

Pre-defined firewall services allow Raw TCP connections through the firewall. These services correspond to each serial port on the device.

Caution: Raw TCP access bypasses any authentication methods. When Raw TCP access is enabled on a serial port, anyone with network access is able to access that serial port, and any devices connected serially to it. **This feature should only be used on a secure network.**

Note: Raw TCP access is disabled by default on Opengear devices. Users must enable Raw TCP access on a serial port through the WebUI, Config CLI or ogcli.

SERVICE IMPLEMENTATION

Raw TCP access allows you to access serial ports on a device directly by connecting to a TCP port in the range 40XX.

In order to achieve Raw TCP access, you must first allow TCP packets through port 4002 in the firewall:

1. Navigate to the **Firewall Management** page in the WebUI.
2. Add a `raw_tcp_serial02` service, which corresponds to serial port 2.
3. Add the service for the firewall zone the service will be connecting over; in the following example, it is the LAN zone. Check the service has been correctly added (as shown in the example).

LAN	
NET2 - 1G Copper/SFP	
Edit Zone Manage Port Forwarding Manage Custom Rules	
Trusted connections from the Local Area Network	
SERVICES IN ZONE	PORT FORWARDING CUSTOM RULES
ALLOWED IP ADDRESSES	SERVICES
0.0.0.0/0	ssh, https, dhcpv6-client, snmp, tftp-client, tftp, ssh_serial01, ssh_serial02, ssh_serial03, ssh_serial04, ssh_serial05, ssh_serial06, ssh_serial07, ssh_serial08, ssh_serial09, ssh_serial10 , ssh_serial11, ssh_serial12, ssh_serial13, ssh_serial14, ssh_serial15, ssh_serial16, ssh_serial17, ssh_serial18, ssh_serial19, ssh_serial20, ssh_serial21, ssh_serial22, ssh_serial23, ssh_serial24, ssh_serial25, ssh_serial26, raw_tcp_serial02
:::0	ssh, https, dhcpv6-client, snmp, tftp-client, tftp, ssh_serial01, ssh_serial02, ssh_serial03, ssh_serial04, ssh_serial05, ssh_serial06, ssh_serial07, ssh_serial08, ssh_serial09, ssh_serial10, ssh_serial11, ssh_serial12, ssh_serial13, ssh_serial14, ssh_serial15, ssh_serial16, ssh_serial17, ssh_serial18, ssh_serial19, ssh_serial20, ssh_serial21, ssh_serial22, ssh_serial23, ssh_serial24, ssh_serial25, ssh_serial26

When this service has been added to the correct firewall zone, you can create a Raw TCP connection to the target port.


Note: `tcp_serial` service must be manually added to relevant firewall zones after Raw TCP has been enabled on a port.

WEBUI CONFIGURATION

Raw TCP access can be enabled or disabled on a selected serial port through the WebUI. When looking at the serial port access page, the enabled/disabled status of Raw TCP access is visible under the **Other Settings** tab for each serial port.

1. In the WebUI, navigate to **Access > Serial Ports** and click the drop-down arrow to the right side of the target port. This displays the port settings, including the Raw TCP status.

- Click the **Edit** text to open the **Edit Serial Port** page:




Port-2
Port-2, 9600-8-N-1-X2

Edit

TRANSMISSIONS OTHER SETTINGS

SETTINGS	VALUE
Escape Character	~
Single Session	Disabled
Raw TCP	Enabled
Logging Level	Logging Disabled

- At the **Edit Serial Port** page, scroll down the page to see the Raw TCP settings:



Raw TCP ?

Enabled Disabled

LOGGING SETTINGS

Logging Level ?

Logging Disabled ▼

- To Enable Raw TCP, click the **Enabled** button then click **Apply** at the bottom of the page. A confirmation message is flagged when Raw TCP is successfully enabled.

CONFIG CLI CONFIGURATION

Raw TCP can be configured through the Config Shell. Navigate to the port endpoint and enter the context of the target serial port (for example, serial port 2 is used in the following procedure):

```
config: port port02
config(port port02): show
Entity port item port02
    baudrate 9600
    databits 8
    escape_char ~
    label Port-2
    logging_level disabled
    mode consoleServer
    parity none
    pinout X2
    portnum 2
    raw_tcp false
    single_session false
    stopbits 1
    control_code (object)
        break ""
        chooser ""
        pmhelp ""
        portlog ""
        power ""
        quit ""
    ip_alias (array)
```

To enable Raw TCP access:

```
config(port port02): raw_tcp true
config(port port02): apply
Updating entity port item port02.
```

To disable Raw TCP access:

```
config(port port02): raw_tcp false
config(port port02): apply
Updating entity port item port02.
```

OGCLI CONFIGURATION

To enable Raw TCP access on a port through ogcli, users can use ogcli update to set `raw_tcp` to **true** on the target port (the device information in the following ogcli command is shown as an example):

```
root@om2216-1-tp1-p3:~# ogcli update port port02 raw_tcp=true
```

To disable Raw TCP, set `raw_tcp` to **false** on the target port:

```
root@om2216-1-tp1-p3:~# ogcli update port port02 raw_tcp=false
```

You can check that the socket is active by running:

```
systemctl status raw-tcp-serial-port02.socket
```

AUTODISCOVERY

The Autodiscovery feature attempts to discover the host name of connected devices; this uses the hostname of the device to set the port label, and set the hostname as the port label of each serial port. This can save the requirement to manually provide hostnames during setup.

Autodiscovery will attempt to discover port settings even if the hostname discovery fails. The first discovery run uses currently configured port settings such as the current baud rate, etc.

Thereafter, it will fetch or use a single set of pre-configured credentials to log in and discover the hostname from e.g. the OS prompt, for devices that do not display hostname pre-authentication.

Syslogging enhancement assists in the diagnosis of common issues (for example, no communications or, hostname failed validation). Autodiscovery does not collect a hostname when there is a communication issue between the console server and the target device. The logs are saved for the last-run instance of autodiscovery.

The UI displays error messages and logs with the reason for auto-discovery failure, for example:

- Authentication failed.
- Communication issue with the target device.
- Password to renew before being able to authenticate to the target device.
- Abnormal characters or strings detected.

Autodiscovery has been enhanced to discover baud rate and pinout (X1 / X2). The UI has been updated to indicate if ports are scheduled for discovery.

Note: The OM1208 will only discover X2 connections.

The **Serial Ports** page also allows you perform an Autodiscovery on selected ports. Autodiscovery of console ports attempts to set the port label by setting the baud rate to various rates (in the following order): 9600, 115200, 38400, 19200, and 57600.

Tip: Autodiscovery on other Baud rates may be done by manually running the `port_discovery` script from the Web Terminal.

Autodiscovery may be done manually by clicking **Perform Autodiscovery**.

AUTODISCOVERY ENHANCEMENTS

From the 22.11 release, the following parameter enhancements have been added to the `port_discovery` script which can be configured via the REST API or CLI:

- `--username` and `--password`
- `--apply-config` and `--no-apply-config`

- `--auth-timeout`
- `--hostname-pattern`

The `--username` and `--password` options can also be configured via the WebUI under *Optional Credentials*.

If the values are provided (optional), they are used to attempt login to obtain the hostname to a downstream serial device. You can only specify a single username and/or password to try on all devices.


Optional Credentials ⓘ

Username

Password

CANCEL AUTODISCOVERY

Port Autodiscovery may be canceled *while running* by clicking on the **Cancel** button at the top-right of the Serial Ports window of the WebUI.



SCHEDULE AUTODISCOVERY

Autodiscovery can be scheduled periodically as required by clicking the **Schedule Autodiscovery** button in the **Serial Ports** window.



The **Schedule Autodiscovery** window allows you to select the ports and specify a time and period for port detection to run. Activate the schedule by clicking on the **Enabled** button.

The Serial Port Autodiscovery Page:

SCHEDULE SERIAL PORT AUTODISCOVERY

Status ⓘ

Enabled Disabled

CONFIGURE SCHEDULE

Repeat Daily at 12:00 AM ⌚

Advanced Configuration ▾



SELECT PORTS

ⓘ Serial Port Autodiscovery will be only performed on ports in Console Server Mode.

<input type="checkbox"/>	Port #	Label	Mode	Parameters	Port Pinout
<input checked="" type="checkbox"/>	1	Port-1	Console Server	9600-8-N-1	X2
<input checked="" type="checkbox"/>	2	Port-2	Console Server	9600-8-N-1	X2
<input checked="" type="checkbox"/>	3	Port-3	Console Server	115200-8-N-1	X1
<input checked="" type="checkbox"/>	4	Port-4	Console Server	115200-8-N-1	X2

RETRIEVE PORT DISCOVERY LOGS

At the top-right of the UI window, click on the **Log File** red text to retrieve the port discovery logs or by clicking on the **View Logs** red text in the autodiscovery running banner.



Port Discovery Log File Example:

SERIAL PORT AUTODISCOVERY LOGS - LAST COMPLETED RUN

```

[main] Starting discovery with 9600 baud and X2 pinout on preconfigured port 4
[port4] 2022-11-08T07:47:16+0000 Discovery starting
[port4] Checking port readiness
[port4] No device discovered
[main] Starting discovery with 9600 baud and X2 pinout
[main] Skipping duplicate test: port 4, baud 9600, pinout X2
[main] Starting discovery with 115200 baud and X2 pinout
[port4] 2022-11-08T07:48:09+0000 Discovery starting
[port4] Checking port readiness
[port4] No device discovered
[main] Starting discovery with 38400 baud and X2 pinout
[port4] 2022-11-08T07:49:00+0000 Discovery starting
[port4] Checking port readiness
[port4] No device discovered
[main] Starting discovery with 19200 baud and X2 pinout
[port4] 2022-11-08T07:49:51+0000 Discovery starting
[port4] Checking port readiness
[port4] No device discovered

```

DISPLAY OPTIONS

Number of Log Lines ?

100

Apply

LOCAL MANAGEMENT CONSOLES

Note: Applies to OM2200 Devices only. Not applicable to OM1200.

This feature allows Administrators to log in and configure the OM via the RJ-45 or USB ports on the device. You can edit settings or disable the local RJ45 serial console (Cisco straight -X2 pinout) and the USB serial console (requires user supplied micro-USB to USB-A cable).

This feature allows Administrators to log in and configure the OM via the RJ-45 or USB ports on the device. You can edit settings or disable the local RJ45 serial console (Cisco straight -X2 pinout) and the USB serial console (requires user supplied micro-USB to USB-A cable).

To edit the settings of a local management console:

1. Navigate to **CONFIGURE > Local Management Consoles**.
A list of consoles displays.
2. Locate the console you want to manage, then under **Actions**, click on the **Edit Management Console Port** button (pencil icon).

3. On the **Edit Local Management Console** page, you can set the parameters for:

- **Baud Rate**
- **Data Bits**
- **Parity**
- **Stop Bits**
- **Terminal Emulation**
- **Enable or disable Kernel Debug Messages**

Note: Enabling **Kernel Debug Messages** can only be applied to a single serial management console.

- **Enable or disable the selected Management Console**

To disable a local management console:

1. Click **CONFIGURE > Local Management Consoles**.
2. Locate the console you want to disable, then under **Actions**, click on the **Disable Management Console Port** button.

LIGHTHOUSE ENROLLMENT

Opengear appliances can be enrolled into a Lighthouse instance, providing centralized access to console ports, automation, and central configuration of Opengear devices.

Lighthouse central management uses a persistent, public key authenticated SSH tunnels to maintain connectivity to managed console servers.

All network communications between Lighthouse and each console server (e.g. access to the web UI), and the console server's managed devices (e.g. the serial consoles of network equipment), is tunneled through this SSH management tunnel.

The following articles and Lighthouse user guide contain further information about Lighthouse Enrollment:

Manual enrollment using UI or CLI

How do I add Nodes to Lighthouse

Lighthouse User Guide


MANUAL ENROLLMENT USING UI

Note: To enroll your Operations Manager to a Lighthouse instance, you must have Lighthouse installed and have an enrollment token set in Lighthouse.


1. In Lighthouse, set an OM enrollment token, click on **CONFIGURE > NODE ENROLLMENT > Enrollment Settings** page, and enter an **Enrollment Token**.

Tip: The same token is entered in the **NEW LIGHTHOUSE ENROLLMENT** page of the Operations Manager.

2. Enroll your Operations Manager in this Lighthouse instance:
Click **CONFIGURE > Lighthouse Enrollment**
3. Click on the **Add Lighthouse Enrollment** button on the top-right of the page.
The **New Lighthouse Enrollment** page opens.



4. Enter the IP address or fully qualified domain name of the Lighthouse instance and the **Enrollment Token** you created in Lighthouse.
Optionally enter a **Port** and an **Enrollment Bundle** (see the [Lighthouse User Guide](#) for more information about Bundling).



5. Click the **Apply** button.
A flag confirms the enrollment.

Note: Enrollment can also be done directly via Lighthouse using the Add Node function. See the [Lighthouse User Guide](#) for more instructions on enrolling Opengear devices into Lighthouse.

MANUAL ENROLLMENT USING THE CLI

For complete instructions on Lighthouse Enrollment via the CLI please refer to this link: [Manual enrollment using UI or CLI](#) .

AUTOMATIC ENROLLMENT BY LIGHTHOUSE SERVICE PORTAL (LSP)

Lighthouse Service Portal (LSP) is an Opengear solution that enables Operations Manager nodes (OM1200 and OM2200) to perform a zero touch call home and automatic enrollment into a customers Lighthouse instance of choice.

Note: LSP is not configurable and cannot be added in-field.

No User setup is required for LSP. LSP should begin working on boot or factory reset.


LSP SERVICE INITIALIZATION

When the node is initially powered-up or rebooted, ZTP begins to run and sees that device is LSP enabled and ZTP exits before applying any configuration. `Systemd` triggers the LSP.

The node connects to internet and adds an NTP server to ensure crypto is working. It then pulls an updated docker container which it runs, and waits while the docker container writes out the appropriate lighthouse bundle associated with the serial number, then exits.

Identity is verified by a TPM attestation key with the serial number encoded and signed by the attestation key and a CA running in AWS. An accompanying certificate is stored the secure Trusted Platform Module (TPM).

If there are no connectivity issues the LSP status LED (cloud on OM2200) state changes progressively from amber flashing (LSP is running), green flashing (Lighthouse is connecting) and green solid (Lighthouse connected successfully). See ["Device Status LEDs" on page 26](#).

	LED Off	Amber Flashing	Amber Solid	Green Flashing	Green Solid
OM Devices Cloud / Internet 	LSP is disabled and there are no existing Lighthouse enrollments.	LSP is currently running on the device.	An error occurred while running LSP.	The device can reach the lighthouse instance and is attempting to enroll. If a lighthouse is unreachable the LED will not start.	The device is enrolled and connected to a lighthouse. There will be a short delay between the UI status reported and the LED changing to solid green.

Note: OM1200 series devices do not have a cloud LED, therefore, no LED indication is available for LSP or Lighthouse.

LSP COMMANDS

LSP is run by a `systemd` service and can be controlled by `systemctl` commands which are self-explanatory:

```
systemctl start lsp
systemctl stop lsp
systemctl enable lsp
systemctl disable lsp
```

The `systemd` service also checks for the absence of a file `/var/lib/lsp/.lsp-disabled` before it will actually run the service.

RESTARTING THE SERVICE

If LSP has been disabled due to an error or a successful completion; to re-enable the service, remove the file `/var/lib/lsp/.lsp-disabled`, after which, LSP can be controlled via standard `systemctl` commands.

LSP ERRORS AND EXIT CODES

LSP initiation can sometimes encounter errors, for example, failure to communicate with the REST-API. In these situations, LSP attempts recovery by running from the start again after waiting for a short period.

Before LSP exits with one of these failures it sets the cloud Status LED to solid amber and it will remain solid amber until the process starts running again to try and recover. If a process error is repeated for an extended time then its likely that something is preventing LSP from completing properly.

LSP LOGGING & ERRORS

LSP logs from the `systemd` service and docker container are all stored in the system journal. The LSP service logs can be accessed with `journalctl -u lsp`, and the container logs can be viewed with `journalctl -b CONTAINER_NAME=LSP_AGENT`.

When the docker container runs, it will display the docker registry and digest hash of the running container.

Log Message/Error Code	Event/Definition
Device is LSP enabled.	The device supports LSP.
No logs, the LSP service should disabled without performing any operations. Disabling the LSP systemd service.	The device does not support LSP. No logs, the LSP service should disabled without performing any operations.
Key detected in the TPM without a certificate. Due to the missing certificate this device is unable to perform LSP. Opengear Support Required!	The device contains a key but no certificate. This should not happen in the field, and the device will require that the customer contact Opengear Support. It may require an RMA.
No existing Lighthouse enrollment found, proceeding with LSP.	No existing Lighthouse is configured, LSP is able to proceed.
Running LSP Docker container.	The docker container has started.
LSP Docker container has finished executing.	The docker container has finished.

Configuring Lighthouse enrollment.	Lighthouse enrollment configuration has started.
Lighthouse enrollment configuration applied successfully.	Lighthouse enrollment configuration has completed.
No Internet connectivity.	The device has no Internet connectivity and does not have a cellular modem, LSP will retry in 60s.
Could not confirm Internet connectivity. Enabling failover.	The device could not reach the Internet with the ethernet interfaces, failover will be enabled on the cellular interface.

EXIT CODES

The LSP process returns an exit code depending on the status of the process:

Code	Name	Definition
0	EXIT_SUCCESS	LSP completed successfully without error. Lighthouse is now enrolling, or Lighthouse is already configured and LSP doesn't have to run, or The device is not an LSP node.
151	EXIT_RETRY	LSP failed, but will retry.
152	EXIT_UNRECOVERABLE_ERROR	LSP failed but will not succeed, support is required.
153	EXIT_STOP	LSP has stopped during execution. It can be started manually.

ACCESSING LIGHTHOUSE SERVICE PORTAL

REGISTER AN ACCOUNT / LOG IN TO LIGHTHOUSE SERVICE PORTAL


Visit portal.opengear.com.

If not already registered, click the user icon and select Register to initiate the process.

Log in to the portal with your credentials.

DASHBOARD

The LSP Dashboard shows any assets with recent activities such as enrollment, call homes, enrollment package assignments, and more.




The screenshot shows the OpenGear Lighthouse Service Portal Dashboard. The top navigation bar includes links for Home, Cases, Knowledge Base, Resources, Products, Contact Us, and Lighthouse Service Portal. The main dashboard area is divided into four sections: Assets, Enrollment Settings, Users, and Account Settings. The Assets section is highlighted and shows a table of assets. The table has columns for Model, Serial Number, Enrollment Package Name, Call Home to LSP Date/Time, Status, and Last Enrollment Date/Time. The table contains three rows of data, all for the model CM1204-HE-L.

Model	Serial Number	Enrollment Package Name	Call Home to LSP Date/Time	Status	Last Enrollment Date/Time
CM1204-HE-L	1204-XXXXXX	Basic	2024-10-10 12:24:58	Pending for approval	2024-10-11 12:29:25
CM1204-HE-L	1204-XXXXXX	Basic	2024-10-10 12:24:58	Pending for approval	2024-10-11 12:29:25
CM1204-HE-L	1204-XXXXXX	Basic	2024-10-10 12:24:58	Pending for approval	2024-10-11 12:29:25

PERMISSIONS

Only the user who originally received the Lighthouse License Key initially has access to the full LSP menu. Other users can be promoted in two ways:

1. Navigate to the Access Request page and send a request to an LSP admin inside your organization.



2. Open a Support Case or reach out to your Sales Rep directly to request access.

There are three different roles inside LSP:

1. Account Admin

Account Admins have full administrative control. They can create and manage groups, invite new users, and assign roles. With the ability to adjust access and oversee packages, they have comprehensive visibility to steer team success.

2. LSP Admin

LSP Admins can create and distribute packages. The ability to set enrollment triggers helps automate workflows, keeping operations running smoothly and efficiently.

3. LSP View Only User

LSP View Only Users have a streamlined view of LSP. They can explore the platform, familiarize themselves with the landscape, and request elevated access when needed.

ENROLLMENT SETTINGS

This is where you create a new Enrollment Package and configure Enrollment preferences.

First, an admin should create at least one Enrollment Package. This package will include Lighthouse IP, Bundle/Token, and API Port to ensure your node can digest this info and enroll to the desired Lighthouse Instance.

New Enrollment Package

* Enrollment Package Name Identifier

Enrollment Bundle

* Token

* IP Address

* Port


Select Entity

There are the four possible enrollment preference scenarios:

1. **Both Automatic Enrollment Triggering and Default Enrollment Packages are Disabled**
Nodes must be manually assigned enrollment packages and approved before the system sends the enrollment package. Approval is only possible after nodes have performed a "call home" action.
2. **Both Automatic Enrollment Triggering and Default Enrollment Package are Enabled**
Nodes automatically receive a default enrollment package immediately upon calling home; no manual intervention is required.
3. **Automatic Enrollment Triggering is Enabled and the Default Enrollment Package is Disabled**
Nodes must have an enrollment package manually assigned after calling home, but do not require manual approval.
4. **Automatic Enrollment Triggering is Disabled and Default Enrollment Package is Enabled**
Nodes automatically inherit the default package upon calling home but require manual approval before the package details are sent.

ASSETS

The assets tab shows all available assets (LSP enabled or not). You can assign enrollment packages to specific assets.




Possible Actions for each asset:

1. **Approve:** You can approve a call home action (if using manual enrollment).
2. **Clear:** You can clear a node of previous enrollment package information.



USER MANAGEMENT

The User Management tab allows you to invite new users to the Opengear Customer Portal, Create new custom groups for permissions, and more.




Understanding the Roles inside LSP

Role	Account Admin	LSP Admin	LSP View Only User
Permission	<ul style="list-style-type: none"> Create Groups Invite/Create Users Promote Users Revoke Account/LSP Admin Set Enrollment Triggering Create Package Assign Packages Set Enrollment Triggering preferences 	<ul style="list-style-type: none"> Create Package Assign Packages Set Enrollment Triggering preferences 	<ul style="list-style-type: none"> View Only of LSP Request Account/LSP Admin permission

Role	Account Admin	LSP Admin	LSP View Only User
Visibility	<ul style="list-style-type: none"> • See Current Account and Child • Note: When Creating a Group, Can see the Entire Account Structure Including Parent/Child/Sibling 	See Current Account and Child	See Current Account and Child
Creation	License Key Owner	<ul style="list-style-type: none"> • Promoted by Account Admin • Promoted by Opengear Support or Sales team 	All Portal Users


LSP Admins can promote or demote users inside your organization.



PLAYBOOKS

Playbooks are configurable systems that periodically check if a user-defined **Trigger** condition has been met. Playbooks can be configured to perform one or more specified **Reactions** when a specific trigger event occurs.

The Playbook Landing Page:



CREATE OR EDIT A PLAYBOOK

1. Navigate to the **Configure > Playbooks** page.
2. Click the **Add Playbook** button (top-right) to create a new **Playbook**.
The **Edit Playbook** page displays.

3. In the **Trigger** section, complete the following fields as appropriate:

ADD PLAYBOOK

TRIGGER

Auto Response Playbooks are configurable systems that check periodically if a Trigger condition is met and may perform Reactions if configured.

Name ⓘ

TD-Test

1

Description ⓘ

Login Tech Test

2

Status

Enabled

Disabled

3

Interval (Seconds) ⓘ

2

4

Trigger Type ⓘ

CLI Login

5

CLI Login

Monitor the terminal and trigger on user login and logout events.

☒ Login ⓘ

6

☐ Logout ⓘ

ACTION

Actions are configurable actions taken when a Trigger condition is met.

Send SMS

Custom Command

Serial Text

Slack

SNMP

■

7


Callout #	Field	Required Information
-----------	-------	----------------------

1	Name	Enter a meaningful name that will help other users understand the purpose of this playbook instance.
2	Description	Enter a detailed description of the playbook to help others understand what it does.
3	Status	Enable or Disable this playbook instance. Select enabled to activate the playbook after you have created it.
4	Interval	Enter the interval, in seconds, of the frequency that this playbook is repeated.

5	Trigger Type	<p>From the drop-down, select the trigger type for this playbook instance:</p> <ul style="list-style-type: none"> • CLI Log in: Triggers upon Login or Logout events. Select either or both. • CLI Log in Failure: Monitor the terminal and trigger on failed user log in attempts. • Cell Connection: Triggered whenever the cellular connection state changes. This Trigger type is only compatible with cellular units. • Cell Message: Triggered when an SMS message that matches the user-defined message pattern. Cellular units only. • Cell Signal Strength: Triggered if the cellular signal strength moves below a user-defined percentage. • Curl: Periodically attempts to perform a HTTP request using curl and triggers the Playbook reaction based on the results. • Custom Command: Periodically runs a custom Shell command and triggers the Playbook reaction upon failure. • Load: Monitors the system load average and triggers the Playbook if it breaches the user-defined acceptable range. • Memory Usage: Triggered if the system memory usage exceeds the user-defined percentage threshold. • Network Settings: Monitors network interfaces for specific attributes and triggers a user-defined response when they change.
User Guide		<ul style="list-style-type: none"> • Ping: Periodically pings an address and triggers a user-defined response upon failure.

6	CLI Log in	Example of a Trigger Type .
7	Action	Follow-up action to be taken when a Playbook is triggered.


4. In the **Action** section, customize the response to the Trigger that you created:
 - a. Click each **Action** to open a custom screen to provide necessary information.
 - b. To create additional Actions, click the **Action** button.



5. When you are finished, click **Apply**.
A banner confirms that the Playbook settings are saved, if the Playbook is **Enabled** it is activated.


MONITOR A CURRENT PLAYBOOK

1. Click on the **Monitor > Triggered Playbooks** menu (shown in the following image).
2. Select the time period if required.
3. Filter by **Name of Playlist** to view any that have been triggered.



PDUS

One or more Power Distribution Units (**PDUs**), both **Local** and **Remote** can be monitored. To add information for a **PDU**, select **Configure > PDUs**.



ADD AND CONFIGURE A PDU


1. In the PDU List page, click the **Add New PDU** button.
The **Edit** page displays.

2. Complete the fields as appropriate:

Field	Decription
Label	Enter a meaningful label to easily identify the individual PDU.
Monitor	Select this check box to monitor the outlet's status.
Mode	Select the mode from Local or Remote . Different fields display depending on the selection.
Driver	Select the appropriate driver compatible with this PDU.
Port	The serial port to which the PDU is connected. This field is available only when Mode is set to Local .
Username	Enter the Username to use when connecting. This field is available only when Mode is set to Local .
Password	User password to use when connecting to the device. This field is available only when Mode is set to Local .
Address	The remote address of the PDU. This field is available only when Mode is set to Remote .

SNMP Protocol	Click the drop-down arrow and select the correct transport protocol used to communicate with the PDU. The default value is UDP. This field is available only when Mode is set to Remote .
Version	The version of SNMP to use, V1, V2c and V3 are supported. The default value is V1. This field is available only when Mode is set to Remote .
Community	Enter a group name authorized to communicate with the device for SNMP versions 1 and 2c. This field is available only when Mode is set to Remote .
Authentication Protocol	Click the drop-down arrow and select the authentication protocol used for authenticated SNMP v3 messages. Only available when the Version is set to v3 . This field is available only when Mode is set to Remote .


- Click on the **Configure Outlets** link, assign a port for each of the PDUs' ports and enter a meaningful name for each outlet.



- When you are finished, click **Apply**.
A green banner confirms your settings.

After you have created (and configured) PDUs:

- you can **Edit** or **Delete** them from the **Configure > PDUs** page.
- operation is simple. For any PDU that has Monitoring set to **Enabled**, the **Toggle** on/off switch powers-on or powers-off the PDU, and the **Cycle** button cycles the PDU through a power-down and power-up cycle.



SYSTEM ALERTS

Tip: For more detailed information about configuring SNMP Alerts, see the individual topic pages that follow.

You can add or delete System Alert Managers under **Configure > System Alerts** for the following:

- **"System Alerts - General" on the next page:** Covers notification for the following:
 - **Configuration Change:** For changes that occur to the system configuration.
- **"System Alerts - Power" on the next page:** When voltage SNMP alerts are enabled, network operators are immediately notified should the PSU begin operating outside design tolerances.
- **"System Alerts - Temperature" on page 90:** When system temperature alerts are enabled, network operators are immediately notified should the system begin operating outside user-defined tolerances.

- "System Alerts - Networking (Connection Status)" on page 92 (**Cell Signal Strength**): Be notified when cell signal strength leaves or re-enters the selected range, or when the network link state changes. A slider adjusts the upper and lower signal strength.

SYSTEM ALERTS - GENERAL

AUTHENTICATION

Provides notification when a user attempts to log in via SSH, REST API, or, the device's serial ports. An alert is sent regardless of whether the log in has succeeded or failed.

1. Navigate to **Configure > System Alerts > General > Authentication**.
2. Click on the **Enabled** button to activate the function.
3. Click **Apply**.

The **Details Saved** banner confirms your settings.

CONFIGURATION CHANGE

Notifies of changes that occur to the system configuration.

1. Navigate to **Configure > System Alerts > General > Configuration Change**.
2. Click on the **Enabled** button to activate the function.
3. Click **Apply**.

The **Details Saved** banner confirms your settings.

SYSTEM ALERTS - POWER

The PSU is one of the most critical parts of the Operations Manager, so it is essential to ensure that the PSU is operating within its design tolerances.

When voltage SNMP alerts are enabled, network operators are immediately notified of PSU failures (subject to network connectivity and latency). Should the PSU begin operating outside design tolerances, PSU-related SNMP Alerts will trigger an alert for the following conditions:

- Output DC voltage of both PSUs

If the voltage drops too low, it risks the Operations Manager going into brown-out state. If it gets too high, it can damage components.

System generated SNMP Alerts send SNMP traps to a remote SNMP manager which alerts the user of system events. The Operations Manager can send network, power, and system events to the remote SNMP manager.

ENABLE POWER SUPPLY SYSLOG ALERTS

The System Voltage Range alert sends an alert when the system reboots or the voltage on either power supply leaves or re-enters the fixed voltage range between 11.4V to 12.6V (SNMP) (or 11V to 13V Syslog).

1. Navigate to **Configure > System Alerts > Power**.
2. Click on the **Enabled** button to activate the function.

Note: The **Disabled** button de-activates the power syslog function and power alerts are stopped until activated again

3. Configure the Syslog Alert Severity:
 - a. For **Power Lost** alert, click the drop-down list and select the severity level required (default level is **3 - ERROR**) when power level is outside the pre-set range.
 - b. For **Power Restored** alert, click the drop-down list and select the severity level required (default is **6 - INFO**) after an error condition has been fixed.
4. Click **Apply**.

The **Details Saved** banner confirms your settings.

When an event occurs that causes the voltage range on any power supply to leave or re-enter the configured voltage range, it causes an SNMP alert to be triggered. The alert reports the event type and identity and status of the PSU, as in the following example.

```
Nov 03 06:09:35 om2232 system-alerts[850]: Redundant Supply Active (PSU0 online, PSU1 online)
Nov 03 07:05:02 om2232 system-alerts[850]: Redundant Supply Inactive (PSU0 offline, PSU1 online)
Nov 03 07:05:05 om2232 system-alerts[850]: Redundant Supply Active (PSU0 online, PSU1 online)
```

To view log severity messages locally, use the journal tool command:

```
journalctl -f -u alert-logger -o verbose
```

where: f = follow. Check the alert-logger using the `systemctl status alert-logger` command.

SYSTEM ALERTS - TEMPERATURE

It is essential to ensure that the system is operating within its design temperature as premature aging of the component can occur if the appliance is excessively hot during operation. This can lead to component failure and ultimately result in RMA.

When temperature SNMP alerts are enabled (Alerting), network operators are immediately notified (subject to network connectivity and latency) should the PSU begin operating outside user-defined temperature tolerances.

System generated SNMP Alerts send SNMP traps to a remote SNMP manager which alerts the user of temperature events.

Tip: The Operations Manager can send network, power and system events to the remote SNMP manager.

CONFIGURE SNMP SYSTEM TEMPERATURE ALERTS

Configure > SNMP Alerts > System > System Temperature

The System Temperature Range alert reports the system temperature (measured at **System Temperature 1** and **System Temperature 2** sensors) and sends an alert when the system temperature leaves or enters the user-configured temperature range.

1. Navigate to **Configure > System Alerts > Temperature > System Temperature**.
2. Set the temperature range limiters to the required upper and lower limits.

You can either enter the temperatures, or use the Up/Down arrows.

In this image, if any temperature sensor reports the system temperature (measured at **System Temperature 1** and **System Temperature 2** sensors) to be less than 36 degrees C or greater than 67 degrees C, an SNMP alert is triggered.

Temperature Range

36 - 67 °C

~ 97 - 153 °F

SNMP Alerts

Enabled

Disabled

Tip: The temperature display is automatically converted to Fahrenheit.

3. Click on the SNMP Alerts **Enabled** button to activate the function.

Note: The **Disabled** button de-activates the function and temperature alerts are stopped until activated again.

4. Click **Apply**. The **Details Saved** banner confirms your settings.

SYSTEM ALERTS - NETWORKING (CONNECTION STATUS)

The alert related to this functionality is the Network Connection Status which sends an alert when cell signal strength leaves or re-enters a user-defined range, or, when the network link state changes. A slider adjusts the upper and lower signal strength limits.

CONFIGURE SIGNAL STRENGTH ALERTS

[Configure](#) > [SNMP Alerts](#) > [Networking](#) > [Network Connection Status](#)

To set the Network Connection Status signal strength boundaries:

1. Navigate to the **Configure > System Alerts > Networking** page.
2. Click on the **Enabled** button to activate the function.
3. In the **Signal Strength Range** fields, set limiters to the required upper and lower limits.

Note: The **Disabled** button de-activates the function and signal strength alerts are stopped until activated again.

4. Click **Apply**.

The **Details Saved** banner confirms your settings.

NETWORK CONNECTION STATUS

Be notified when cell signal strength leaves or re-enters the range, or when the network link state changes.

Signal Strength Range

33 - 66 %

SNMP Alerts

Enabled Disabled

Apply

When an event occurs that causes the signal strength to re-enter the user-defined range, an SNMP alert is triggered.

In the above image, if any anomaly occurs that causes the signal strength to drop below 33 or above 66, an SNMP alert is triggered.

NETWORK CONNECTIONS

The **Network Connections** menu provides:

["Network Interfaces" below,](#)

["IPsec Tunnels" on page 123](#)

["Static Routes" on page 128](#)

NETWORK INTERFACES

The interface supports both IPv4 and IPv6 networks. The IP address of the unit can be setup for Static or DHCP. The following settings can be configured for network ports:

- IPv4, IPv6
- Static and/or DHCP
- Enabling or disabling network interfaces
- Ethernet Media types

For detailed information about Network Interface configuration and adding a new connection, see ["Change Network Settings" on page 39](#).

For information about VLAN interfaces, bridges, and bonds, see ["Bonds and Bridges" on page 112](#)

For information about creating or configuring Loopback Interfaces see ["Create or Configure a Loopback Interface" on page 297](#) in the Config CLI Use Cases section of this User Guide.

DUAL SIM

OM2200-L: CONFIGURE > NETWORK CONNECTIONS> Network Interfaces > WWAN0 - Cellular Interface (LTE)

Operations Manager has been available for some time with support for two SIM cards/slots, whereby, it is possible designate which SIM slot is the Active SIM that is normally used by the OM for OOB communications (in Automatic failover mode this SIM is termed the Primary SIM). The secondary SIM is used as a failover SIM. This feature increases the reliability of the OOB solution by providing redundant Out-Of-Band access over a cellular connection.

Note: The terminology changes when SIM Failover policy is switched from **Manual** to **Automatic**. In Manual failover mode the active SIM is designated ACTIVE, whereas in Automatic failover mode the active SIM is designated PRIMARY.

With the Dual SIM feature activated, in the event of a failure of OOB communications through the Active SIM, it is possible to manually de-select the failed SIM and activate the secondary SIM by making *it* the Active SIM. This changeover allows OOB communications to resume through the newly designated Active SIM.

DISPLAY SIM STATUS AND SIGNAL STRENGTH

Note: For information about configuring the **Signal Strength Thresholds** see: "[System Alerts](#)" on page 87

1. Navigate to **Configure > Network Connections > Network Interfaces**.
2. Click on the **Cellular Interface (LTE)** row.


The information bar expands, and the page shows the current status of the active and inactive SIM cards.

Note: If the unit does not have a cell modem -L then the cellular interface is not visible.

Cellular Interface (LTE)


Enabled Disabled No SIM ⚙️

- The active SIM indicates the color of the signal strength based on the selected thresholds in **Configure** → **SNMP Alerts** under the **Networking Signal Strength Alert**.



The signal bar color (not the number of bars) indicates signal strength:

- **Green** if signal is above the higher threshold.
 - **Amber** if signal is between lower and higher threshold.
 - **Red** if signal is below the lower threshold,
 - **Grey** for 0 or not active,
- Click the **Refresh** button to display the current signal strength of the active SIM.



Note: When the **Refresh** button is clicked the signal strength is only updated for the active SIM. If you want to know what the other SIM Signal Strength is, you must activate it, let the modem come back online, which may take three minutes or more.

INSTALLING A NEW SIM CARD

When you install a new SIM card into its slot while the appliance is active (hot swapping), it may take a minute or two for the system to react and stabilize after the SIM card change.

Two SIM card slots are located on the rear face of the device, insert each SIM card(s) into its respective slot (marked 1 and 2) until you feel the card click into place.




SELECT THE ACTIVE SIM (MANUAL FAILOVER MODE)


Switching the active SIM must be done manually. To switch the Active SIM:

1. Navigate to **CONFIGURE > NETWORK CONNECTIONS > Network Interfaces > Cellular Interface (LTE)**.


2. Click the **Settings cog**.

This displays the **MANAGE CELLULAR INTERFACE (LTE)** page and the current status of both SIM slots, including the current carrier name.

 **Cellular Interface (LTE)**



3. On the right, select the **Make Active** button of the new, active SIM and apply the change by selecting **Confirm**.
4. A pop-up alert states that this operation will take a few minutes to complete. Click **Yes** to confirm the change.



Note: During the change-over the current IP address is hidden and then returned when the modem re-connects.

5. If you require, you can monitor the interface during the changeover via the CLI with the command:..

```
watch ip address show dev wwan0
```

You can also set the SIM settings by expanding the menu for each SIM to set the APN.


If no SIM is inserted you can still select a SIM slot. If you insert a SIM it will not force it to become the active SIM.

SELECT THE PRIMARY SIM (AUTOMATIC FAILOVER MODE)

Switching the primary SIM must be done manually. To switch the Primary SIM:

1. Navigate to **CONFIGURE > NETWORK CONNECTIONS > Network Interfaces > Cellular Interface (LTE)**.
2. Click the **Edit** icon.

This displays the **MANAGE CELLULAR INTERFACE (LTE)** page and the current status of both SIM slots.



3. Ensure the cellular interface is enabled by clicking the **Enabled** button.

- Under **Cellular SIM Failover** click the **Enabled** button.

This displays the **Primary** selection buttons.


CELLULAR SIM FAILOVER ?

Enabled

Disabled

▲ Cellular SIM Failover may take a few minutes due to the need to switch firmware.

Primary - SIM CARD 1

 Verizon Wireless
 ICCID: 89148000005844013102
[SIM Settings ^](#)

Primary ✓

APN ?

Username ?

Password ?

Confirm Password ?

IP Type

IPv4v6 ▼

- Click the **Primary** button of the SIM selected to be the primary SIM.
- Select the required **Failback Policy** for the failback SIM and complete the failback policy details:
- Click the **Confirm** button at the bottom of the page.

A green banner displays to confirm that the new settings are saved.

DUAL SIM FAILOVER

OM2200-L: CONFIGURE > NETWORK CONNECTIONS> Network Interfaces > WWAN0 - Cellular Interface (LTE) > Edit

Operations Managers that carry two SIM cards can be configured so that either SIM card slot may be activated. In failover mode, either of the two SIM cards may be designated as the Primary SIM. (see ["Dual SIM" on page 94](#)).

Dual SIM Failover works seamlessly with the existing failover solution to provide another layer of redundancy. This feature allows the software to detect a failure in OOB communications via the Primary SIM and will failover to the Secondary SIM without the requirement for manual operator intervention.

Options within the configuration also allow you to configure the failback settings from Secondary SIM, back to the previous Primary SIM when OOB communications have been restored. See ["Cellular Interface Policy Settings" on page 103](#).


See the image on the following page for a depiction of Primary and Secondary SIM card slots.

In the following image, SIM card 1 has been designated as the Primary SIM and is currently the active SIM, while SIM card 2 is designated as the Secondary SIM which, (in the following scenario), is activated in the event of a failover such as occurs during an OOB communications failure on the Primary SIM.

CELLULAR SIM FAILOVER

Enabled

Disabled



 Cellular SIM Failover may take a few minutes due to the need to switch firmware.

Primary - SIM CARD 1

 Verizon Wireless
 ICCID: 89148000005844013102
[SIM Settings](#) 

Primary 

Secondary - SIM CARD 2

 AT&T Wireless Inc.
 ICCID: 89010303300021797361
[SIM Settings](#) 

Make Primary

FAILOVER MODES

Features of Failover include:


- Select **Enabled** SIM failover.
- Specify SIM failback policy (applicable when the Ethernet connection and primary SIM are both down):
 - **Never** - The node never switches back to the Primary.
 - **Delayed** (specified in minutes) - The node switches back to primary after a pre-defined time has elapsed.
 - **On Disconnect** - See the table "[Cellular Interface Policy Settings](#)" on page 103 for an explanation of the policy.


- SIM failover settings allow you to configure the parameters that affect cellular data usage, for example, quicker failover (consumes more data) vs less frequent tests (consumes less data). The configuration preferences include
 - Ping test for failover from Primary to Secondary and failback from Secondary to Primary.
 - Failover settings are per SIM slot and consist of a failover and failback ping test.

ACTIVATE OR CONFIGURE FAILOVER


OM2200-L: CONFIGURE > NETWORK CONNECTIONS> Network Interfaces > WWAN0 - Cellular Interface (LTE) > Edit


1. Navigate to the Cellular Interface page at: **CONFIGURE > NETWORK CONNECTIONS> Network Interfaces > Cellular Interface (LTE)**.
2. Click the **Edit** link next to the Cellular Interface Enabled/Disabled switch.

 **WWAN0 - Cellular Interface (LTE)**

Enabled Disabled  Edit

IPv4 DHCP	100.65.0.42/30
IPv6 Automatic	Configuration Down

 **WWAN0 - Cellular Interface (5G)**

Enabled Disabled  Edit

IPv4 DHCP	10.210.77.54/30
IPv6 Automatic	Configuration Down

3. Select the **Enabled** failover option.

4. Ensure the correct SIM card is selected as the Primary SIM (see 'Set Primary SIM' in ["Dual SIM" on page 94](#)).
5. Complete the Cellular Interface options in accordance with the following table.
6. Click **Confirm** to activate the failover policy settings.
A green banner confirms the settings are enabled.

CELLULAR INTERFACE POLICY SETTINGS

MANAGE WWAN0 CELLULAR INTERFACE Properties	
Field	Definition
CELLULAR SIM FAILOVER - Enabled.	Switch between the Primary SIM Card and the secondary SIM Card on dis-connection.
Primary SIM Failover	
Failover Probe Address.	Network address to probe in order to determine if connection is active. Note: The probe address accepts IPv4, IPv6 addresses and hostnames.
Test interval (seconds).	The number of seconds between connectivity probe tests.
Pings per test.	The maximum number of times a single ping packet is sent per probe before considering the probe failed.
Consecutive test failures before failover.	The number of times a probe must fail before the connection is considered failed.
Failback Policy	
Never / Delayed / On Dis-connect.	Select the policy to be used to determine Failback recovery from the Secondary SIM Card back to the Primary SIM Card.

Never	No Failback recovery is attempted.
Delayed	Attempted failback after n minutes. The number of minutes after failover to the secondary SIM Card that the connection should failback to the Primary SIM Card.
On Disconnect	Secondary SIM Failback.
	Failback Probe Address ie. The Network address to probe in order to determine if the connection is active.
	Test Interval The number of seconds between connectivity probe tests (this not the same thing as Attempted Failback).
	Pings per Test The maximum number of times a single ping packet is sent per probe before considering the probe failed.
	Consecutive Test Failures (before failover) The number of times a probe must fail before the connection is considered failed.

CELLULAR MODEM FIRMWARE UPGRADE

This Cellular Modem Firmware Upgrade procedure provides an automatic download and upgrade process for carriers, and, a secondary manual upgrade process for users who must use a firmware set that has not been tested by Opengear or use a carrier that is not supported by the standard cellular modem firmware.

Opengear devices use a standard modem, however, due to the variety of carriers that exist, there is a wide variety of firmware packages which are offered by Sierra Wireless (Opengear's modem provider) in order to accommodate these different carriers. When Opengear devices are supplied,

they are provided with the most common set of modem firmware pre-installed; this minimizes difficulty when setting up cellular services on devices. The manual cellular upgrade procedure supports users deploying cellular capable devices to regions that use a carrier that is not supported by the standard cellular modem firmware.

Note: The Cellular Firmware Upgrade procedure is only available through terminal or shell access. The use of automated tools such as cron jobs is not supported and is therefore discouraged.

MODEM FIRMWARE UPGRADE PROCEDURES

CELLULAR AVAILABILITY DURING UPGRADE

The `cell-fw-update` command disables the cellular modem during the upgrade process. This causes a loss of availability of the Out-of-Band (OOB) link which can only be restored when the cellular modem has returned to a working state. The 'defer if failed over' feature provides some protection.

CELL-FW-UPDATE HELP

```
root@om2248-l-tp1-p14:~# cell-fw-update --help
```

```
Usage: /usr/bin/cell-fw-update [options] <actions>
```

Actions:

- m <file> [-m <file>].. Flash modem with firmware <file>(s)
- c <carrier> Flash modem with firmware suitable for <carrier>
- l List carrier IDs suitable for use with -c
- f Write current fingerprint and timestamp to stdout
- u Update file lists from remote server
- d Download/synchronize fw files from remote server
- h Show this usage

Options:

- a Report automated upgrade messages
- b <url> Specify base URL to remote
- v Verbose messages
- C Continue/resume partial downloads
- unsafe Ignore all checksums/signatures and allow downgrades.

This enables existing firmware to be re-flashed when using the qmi-firmware-update back-end

- defer deprecated! Do not permit firmware upgrade if system is currently failed-over.
This is now default behaviour. Use the flag --ignore-defer to bypass this.
- libqmi Force use of libqmi tool qmi-firmware-update. Cannot use with --mbpl
- mbpl Force use of Sierra Wireless MBPL fwdwl-lite. Cannot use with --libqmi
- ignore-defer Bypass the 'failover defer' check to force a modem firmware upgrade

UPDATE LOCAL FILE LIST AND DOWNLOAD LATEST FIRMWARE FILES

This procedure updates the local file list and downloads the latest firmware files.

Note: `cell-fw-update` can be run directly from a CLI shell as root and requires no configuration. You can combine this update action with the following download operation by providing both `-u` and `-d` simultaneously.

```
root@om8148-10g-tp2-p35:~# cell-fw-update -ud
Waiting for clients to stop using the modem...
The modem is now locked

=== INFO ===
The modem is locked by client cellfw
No clients want to use the modem
UIM failover status is disabled
Active UIM slot is 1 (ICCID: 89610180003137049629)
Operator is telstra corp. ltd.
0157863e6fe95988415b264e35ac0b4f687ffbf9 2024-01-18
download e4c83bb1ae1e5be73c3a254fca7e13e38b33e39a SWIX65C_02.13.08.00.cwe
download 31dca80c90d37100b17ac8e49998ce35724c6b90 SWIX65C_02.13.08.00_GENERIC_
030.047_001.nvu
download 5ed78eb2d69d651d73e177c855eaecb02c6df0b0 SWIX65C_02.13.08.00_PTCRB_
030.045_001.nvu
download 91b8c518ddfad508ffe22c0f099465abb8b31d88 carrier-canon.txt
download b8d3a9cb4faabcf6f5e1fa5acb0f4e41ed72f506 carriers.txt
copy a6ddf97fb6b6f8dd0d011d54dcdfe34db64b25ee cell-firmware.txt
copy - localfiles.txt
copy - localdb.txt
copy - SHA1SUMS
```

Note: The `cell-fw-update -u` and `cell-fw-update -d` commands may be run separately.

LIST SUPPORTED CARRIERS

The resulting carriers shown are for example only (local results may vary).

```
root@om2216-1:~# /etc/scripts/cell-fw-update -l
att AT&T
docomo DoCoMo
generic Generic
kddi KDDI
kt Korea Telecom
rogers Rogers
softbank SoftBank
sprint Sprint
telstra Telstra
telus Telus
tmo T-Mobile
uscellular U.S. Cellular
verizon Verizon Wireless
```

AUTOMATIC FIRMWARE UPDATE FOR CURRENT CARRIER

This procedure detects the currently connected carrier and updates the firmware set for that specific carrier. A firmware set consists of the modem's firmware image (.cwe) and a carrier specific PRI firmware image (.nvu). This set is required for modem operation.

```
cell-fw-update -a
```

FIRMWARE UPDATE FOR SPECIFIC CARRIER

Specify the carrier for which you want to update the firmware.

```
cell-fw-update -c <carrier>
```

Note: Use the `cell-fw-update -l` command to list supported carriers.

MANUAL FIRMWARE UPDATE

Specify a firmware set to download to the modem. This allows you to update the modem with a specific firmware set instead of one provided by Opengear FTP. The path to the firmware set specified must be relative from the directory `/mnt/nvram/cellfw/`.

Warning: This operation must be used with great caution as can result in the modem becoming *permanently* unavailable or damaged. Use at your own risk.

```
root@om8148-10g-tp2-p35:~# cell-fw-update --unsafe -m SWIX65C_02.13.08.00.cwe -m
SWIX65C_02.13.08.00_GENERIC_030.047_001.nvu
Waiting for clients to stop using the modem...
The modem is now locked
=== INFO ===
The modem is locked by client cellfw
No clients want to use the modem
UIM failover status is disabled
Active UIM slot is 1 (ICCID: 89610180003137049629)
Operator is telstra corp. ltd.
Application version: 1.0.2307.1
Target image Info:
Carrier :GENERIC
FW Version :02.13.08.00
```

```
Model ID :SWIX65C
Package ID :001
PRI Version:030.047
SKU :9999999
Switching device into download mode ...
Modem Needs FW
Modem Needs PRI
Downloading: /tmp/cell-fw-update.4045/SWIX65C_02.13.08.00.cwe
Downloading: /tmp/cell-fw-update.4045/SWIX65C_02.13.08.00_GENERIC_030.047_001.nvu
All image data was downloaded successfully.
Device is about to reset ...
Waiting for modem to come up in ONLINE mode ...
Modem is now in ONLINE mode ...
FW update status: Successful
FW info from modem:
Model ID : EM7565
FW Version : SWIX65C_02.13.08.00
Carrier Name : GENERIC
Carrier PRI Revision: 030.047_001
Firmware download process completed successfully.
INFO: QDL Port: /dev/wwan0qdl0
INFO: Device Path: /dev/wwan0qmi0
INFO: FW Path: /tmp/cell-fw-update.4045
Waiting for modem to disconnect from the host ...
Modem disconnected from host.
Waiting for modem to come up in BOOT and HOLD mode ...
BOOT and HOLD Mode. Downloading firmware ...
[/dev/wwan0qmi0] Device list of stored images retrieved:
[/dev/wwan0qmi0] Device list of stored images retrieved:
<14>Jan 22 06:05:25 cell-fw-update: The firmware was successfully stored on the
```

```
modem

[/dev/wwan0qmi0] Device list of stored images retrieved:
```

MODEM UPDATE TROUBLESHOOTING GUIDE

The following procedure can be used to determine if the cellular modem is ready and available and may provide recovery if necessary if the upgrade or modem repeatedly fails.

DETERMINE IF MODEM IS READY & AVAILABLE

The service `ModemManager` is an essential dependency for all cellular modem operations. Please ensure it is running.

```
root@om8196-10g:~# systemctl start ModemManager
```

If the modem is running correctly, it should be able to be detected by `ModemManager` within 60 seconds of the service starting.

```
root@om8196-10g:~# mmcli -L
```

If the modem was not detected or is still problematic, the modem must be recovered.

DETERMINE IF THE MODEM IS CURRENTLY BEING UPGRADED

The simplest way to determine if the modem is currently being upgraded is to check the currently running processes and look for `cell-fw-update`. This is done through the following check:

```
ps aux | grep cell-fw
```

The following example shows that an upgrade is running:

```
root@om2216-1:~# ps aux | grep cell
root 122965 0.2 0.0 4780 3992 pts/0 S+ 23:42 0:00 /bin/bash /usr/bin/cell-fw-
update -aud
root 125966 0.0 0.0 3332 1756 pts/1 S+ 23:47 0:00 grep cell
```

The following example shows that there is no upgrade running:

```
root@om2216-1:~# ps aux | grep cell-fw
root 126417 0.0 0.0 3332 1776 pts/1 S+ 23:48 0:00 grep cell-fw
```

BONDS AND BRIDGES

BONDS

Network bonds allow combining two or more network interfaces together into a single logical "bonded" interface for load balancing, redundancy or improved performance depending on the bond mode used.

CREATE A NEW BOND


To create a new bond:

1. Navigate to the **Configure > Network Connections > Network Interfaces** page on the WebUI.
2. Click on the **New Bond** button that is located at the top-right of the window.
3. Select which interface will serve as the primary interface for the new bond.

Note: When the primary interface is selected, its MAC address displays in the MAC address field. This MAC address is inherited by the new bond interface.

4. Complete the new bond details form as appropriate:

New Bond Field	Definition
Description	The editable Description field allows you to add a description of the interface. If the description field is not completed the field defaults to a computed value to describe the interface.
Mode	<p>The mode determines the way in which traffic sent out via the bonded interface is dispersed over the real interfaces. Available modes are:</p> <ul style="list-style-type: none"> • Round Robin Balancing - Packets are sequentially transmitted/received through each interface, one by one. • Active Backup - If the active secondary interface is changed during a failover, the bond interface's MAC address is then changed to match the new active secondary's MAC address. • XOR Balancing - Balances traffic by splitting up outgoing packets between the Ethernet interfaces, using the same one for each specific destination when possible. • Broadcast - All network transmissions are sent on all secondary interfaces. This mode provides fault tolerance. • 802.3ad (Dynamic Link Aggregation) - Aggregated NICs act as one NIC, but also provides failover in the case that a NIC fails. Dynamic Link Aggregation requires a switch that supports IEEE 802.3ad. • Transmit Load Balancing - Outgoing traffic is distributed depending on the current load on each secondary interface. Incoming traffic is received by the current secondary interface. If the receiving secondary fails, another secondary takes over the MAC address of the failed secondary. • Adaptive Load Balancing - Includes transmit load balancing (tlb) and receive load balancing (rlb) for IPv4 traffic and does not require any special switch support.

Poll Interval	The poll interval specifies the MII link monitoring frequency in milliseconds. This determines how often the link state of each secondary is inspected for link failures. A value of zero will disable MII link monitoring.
Network Interface Selection	Click the checkbox of each network interface you want to include in the bridge. Available interfaces include Ethernet and VLAN interfaces that are not part of another bond or bridge.
Primary Interface	Select the interface to use for selecting the MAC address of the aggregate. The new bond inherits the MAC address of the primary interface. On creation, any Network Connections which exist on the Primary Interface will be attached to the Bond/Bridge after it is initially created. When a Bond/Bridge is deleted, any Network Connections which exist on the aggregate interface are handed over to the Primary Interface.
Active Connections	When the Primary Interface is created, the connections inherited by the new bond are listed here. When edited, Active Connections on the aggregate will not be updated if the primary interface is changed.
	Click to edit the details of an existing interface. Updating a bridge will temporarily interrupt network activity on the interface when you click the Update button.

5. Click the **Create** button to finalize the creation of the new bond.

Network connections from non-primary interfaces are deleted when the new bond is created.

EDIT AN EXISTING BOND

To edit an existing bond:

1. Navigate to the **Configure > Network Connections > Network Interfaces** page on the WebUI.
2. Click on the bond that you want to edit, the bond details are expanded.
3. Click on the bond **Edit** button that is located next to the Enable / Disable toggle buttons.
4. Change the bond details as required.
5. Click the **Update** button to finalize the edit process.

Updating the bond temporarily interrupts network activity on this interface.

Note: Editing the primary interface does not update its connections.

BRIDGES


Network bridges allow connecting of multiple network segments together so that they may communicate as a single network.

Operations Manager models with an integrated switch (OM1204-4E, OM1208-8E and OM2224-24E) have a bridge configured by default that includes all switch ports, which can be edited or deleted as required.

Note: Whether creating a new bridge or editing an existing bridge the page is very similar.


CREATE A NEW BRIDGE

To create a new bridge:

1. Navigate to the **Configure > Network Connections > Network Interfaces** page on the WebUI.
2. Click on the **New Bridge**  button that is located at the top-right of the window.
3. Select which interface will serve as the primary interface for the new bridge.

Note: When the primary interface is selected, its MAC address displays in the MAC address field. This MAC address is inherited by the new bridge interface.

4. Complete the new bridge details form as appropriate:

New Bridge Field	Definition
Description	The editable Description field allows you to add a description of the interface. If the description field is not completed the field will default to a computed value to describe the interface.
Enable Spanning Tree Protocol	Enable or disable Spanning Tree Protocol. For more information, see Spanning Tree Protocol .
Network Interface Selection	Click the checkbox of each network interface you want to include in the bridge. Available interfaces include Ethernet and VLAN interfaces that are not part of another bond or bridge. Bond interfaces can be included in a bridge by using the ogcli tool. See Support for Bonds in Bridges in the Knowledge Base.
Primary Interface	Select the interface to use for selecting the MAC address of the aggregate. The new bond inherits the MAC address of the primary interface. On creation, any Network Connections which exist on the Primary Interface will be attached to the Bond/Bridge after it is initially created. When a Bond/Bridge is deleted, any Network Connections which exist on the aggregate interface are handed over to the Primary Interface.
Inherited Connections	When the Primary Interface is selected, the connections inherited by the new bridge are listed here.
	Click to edit the details of an existing interface.

5. Click the **Create** button to finalize the creation of the new bridge.

EDIT AN EXISTING BRIDGE

To edit an existing bridge:

1. Navigate to the **Configure > Network Connections > Network Interfaces** page on the WebUI.
2. Click on the bridge that you want to edit, the bridge details are expanded.
3. Click on the bridge **Edit** button that is located next to the Enable / Disable toggle buttons.
4. Select which interface will serve as the primary interface for the new bridge.
5. Change the bridge details as required.
6. Click the **Update** button to finalize the edit process.

Updating the bridge temporarily interrupt network activity on this interface.

Note: Editing the primary interface does not update its connections.

SPANNING TREE PROTOCOL

Spanning Tree Protocol (STP) allows an Operations Manager to discover and eliminate loops in network bridge links, preventing broadcast radiation and allowing redundancy.

When STP is implemented on switches to monitor the network topology, every link between switches, and in particular redundant links, are cataloged. The spanning-tree algorithm blocks forwarding on redundant links by setting up one preferred link between switches in the LAN. This preferred link is used for all Ethernet frames unless it fails, in which case a non-preferred redundant link is enabled.

Note: STP Limitations

If multiple bridges are created on the same switch, they should not be used on the same network segment as they have the same MAC addresses; therefore, STP will likely not work correctly as they will have the same bridge id.

Rapid Spanning Tree Protocol (RSTP), Multiple Spanning Tree Protocol (MSTP) and other

proprietary protocols are not supported.

The bridge settings relating to STP cannot be changed from the default values shown below:

group_address

forward_delay (default is 15)

hello_time (default is 2)

max_age (default is 20)

priority (default is 32768 (0x8000))


ENABLE STP IN A BRIDGE

To enable STP you can use the UI or CLI. The procedures are:

BRIDGE WITH STP ENABLED - UI

CONFIGURE > NETWORK CONNECTIONS > Network Interfaces > Select the target interface > New Bridge page

1. In the **Network Interfaces** page, click the **Create New Bridge** button.
2. Click to select the **Enable Spanning Tree Protocol** option.



BRIDGE WITH STP ENABLED - OGCLI

```
admin@om2248:~# ogcli get physif system_net_physifs-5  
  bridge_setting.id="system_net_physifs-5"  
  bridge_setting.stp_enabled=true  
  description="Bridge"  
  device="br0"  
  enabled=true  
  id="system_net_physifs-5"  
  media="bridge"  
  name="init_br0"  
  slaves[0]="net2.3"
```


BRIDGE WITH STP DISABLED - OGCLI

```
admin@om2248:~# ogcli update physif system_net_physifs-5 bridge_setting.stp_  
enabled=false  
  bridge_setting.id="system_net_physifs-5"  
  bridge_setting.stp_enabled=false  
  description="Bridge"  
  device="br0"  
  enabled=true  
  id="system_net_physifs-5"  
  media="bridge"  
  name="init_br0"  
  slaves[0]="net2.3"
```


CONFIGURE A VLAN

The OM Series has flexible Ethernet capabilities, including support for VLANs. More specifically, it supports 802.1Q VLAN tagging to allow a trunked connection into an external switch or other device. It also supports the Linux logical "bridge group" feature which is the ability to group physical and virtual interfaces together. This can be used to group switch ports together, and to map physical switch ports into VLANs to create what are commonly referred to as "access ports" for those VLANs.

Picture a VLAN as a network that is usually segmented by function or application. VLANs behave much like physical LANs, but you can group hosts even if they are not physically co-located. A switch port can belong to a VLAN.



VLANs allow you to make separate broadcast domains on a switch. The broadcast domains can associate with one another with the help of a Layer 3 device such as a router. A VLAN is mainly used to form groups among the hosts regardless of where the hosts are physically located. In a bigger network, the configured VLANs with interfaces assigned as access and trunk ports on switches could look like this:



Switch Ports

For models with built-in switch ports, by default these are configured in a single bridge group called "Switch", which effectively puts all the switch ports into one virtual LAN or layer 2 broadcast domain. This default "Switch" bridge group can be deleted, and each of the switch ports is capable of being configured as a separate layer 3 interface with its own IP address. Alternatively, a number of switch ports can be grouped together using a bridge, to make a virtual LAN of any size. A bridge group can also include an 802.1Q VLAN interface (configured on a trunk port), effectively mapping the physical ports into that VLAN as "access ports".

IP Addressing

In order to communicate with an Ethernet interface, VLAN or bridge group, the OM must have a configured IP address on what is called a connection or "conn". This is similar in concept to a layer 3 subinterface or virtual interface on other networking equipment. The connection can be assigned to the bridge itself, or any of the members, including any physical (access) port or the 802.1Q VLAN, which makes the configuration quite flexible. For example, you can have a VLAN trunk with multiple 802.1Q VLANs, and each can be configured with a connection (IP Address information) so the OM appliance can communicate with other hosts on those VLANs. You can


configure switch ports to operate individually, or in bridge groups (to make virtual LANs), and assign these IP addresses using a connection. You can combine these two by creating a bridge group that has an 802.1Q VLAN member and one or more switch ports, which become "access ports" to that VLAN.

Local VLANs

If the requirement is to just to group OM switch ports together into a "local" virtual LAN, but there is no requirement for a trunk, then this does not require a VLAN to be configured on the OM, you just require a bridge group, which behaves like a L2 virtual LAN. Create a new bridge group, assign the OM switch ports, and optionally create a new connection to add an IP address.

Navigate to Configure > Network Connections > Network Interfaces, then click on the New Bridge icon to create a new bridge group. Give this a name, then select the Switch Port(s) that you want to connect into this bridge group (local VLAN). Hit Create and the bridge group is created.

The following example shows VLAN 102 on the NET2 trunk port, with 16.0.0.1 address assigned:



NET2 - 1G Copper/SFP VLAN 102

1 IPv4 connections
0 Automatic 1 Static

0 IPv6 connections
0 Automatic 0 Static

Enabled Disabled Enabled ⚙️ Delete 🗑️

Parent Interface: NET2 - 1G Copper/SFP

IPv4 Static 16.0.0.1/24


Configure OM Switch Ports as VLAN access ports (untagged ports)

To map the OM switch ports as "Access Ports" into a trunked VLAN, the OM uses a Bridge Group to join the switch port(s) to the same Layer 2 bridge domain as the VLAN subinterface, effectively bridging them together.

If the OM switch ports are still in the default "Switch" bridge group, you can delete or leave in place the "Switch" bridge group. Then you can assign some of the switch ports into new bridge group(s).

Go to Configure > Network Connections > Network Interfaces ... then click on the New Bridge icon to create a new bridge group. Give this a name, then select the Switch Port(s) that you want to connect into this bridge group (VLAN), and finally select the VLAN subinterface that you created on the Trunk port, e.g. NET2 - VLAN 22. Hit Create and the bridge group is created.


The following example shows bridge group BR3 with switch ports 5 and 6 bridged into VLAN 101 on the NET2 trunk. Switch ports 5 and 6 are now effectively untagged VLAN ports since the VLAN 101 trunk port NET2 is now in the same bridge group BR3. The subinterface NET2/VLAN101 is a 802.1Q tagged port. Note that the OM has a static IP address of 15.0.0.1 on this bridge group (VLAN).




BR3 - Aggregate

3 Bridged Interfaces
1 IPv4 connections
0 Automatic 1 Static
0 IPv6 connections
0 Automatic 0 Static

Enabled

Disabled

Delete 

Bridged Interfaces	Switch Port 5 Switch Port 6 NET2 - 1G Copper/SFP VLAN 101	
IPv4 Static	15.0.0.1/24	 

IPSEC TUNNELS

The Opengear Operations Manager (OM) can use IPsec to securely connect and route between two or more LANs (sometimes referred to as site to site, LAN-to-LAN, L2L VPN), or as a single client endpoint connecting to a central LAN or endpoint (sometimes referred to as host to site, or host to host).

IPsec does not make a formal distinction between initiator and responder, however the Opengear OM can both initiate tunnels (as the "initiator") and have other devices initiate tunnels to it (as a "responder").


CREATE, ADD OR EDIT IPSEC TUNNELS

On the IPsec Tunnels page, you can create, edit, and delete IPsec tunnels.

To create an IPsec tunnel:

1. Click **CONFIGURE > NETWORK CONNECTIONS > IPsec Tunnels**.

The IPsec Tunnels page with two tunnels previously created.



*If there are no existing tunnels, this **Create Tunnel** button displays:*



2. Click **CREATE TUNNEL**.

This **EDIT IPSEC TUNNEL** page displays.

3. Configure the **Name** and **Status** settings:

- a. In the **Name** section of the page, give your new tunnel a unique name and set the **Status** to **Enabled**.

EDIT IPSEC TUNNEL PSK_TUNNEL

Name ?

psk_tunnel

Status

Enabled Disabled

Initiate from Console Server

Initiator Responder

- b. Set the Console Server to be the **Initiator** or **Responder**.

Note: When **Initiator** is selected, the node actively initiates the tunnel by sending IKE negotiation packets to the remote end.

4. Configure the IKE Settings:

- a. Select an **IKE Protocol** version to use for exchanging keys. IKEv1 provides two modes: **Main** and **Aggressive**.

When using IKEv1, Main Mode is recommended. Aggressive Mode is considered less secure because the hash of the pre-shared key is exchanged unprotected.

Select the IKE protocol version to be used for exchanging keys. IKEv1 provides two modes: Main and Aggressive. When using IKEv1, Main Mode is recommended. Aggressive Mode is considered less secure because the hash of the pre-shared key is exchanged unprotected.

IKE Protocol ?

IKEv2
IKEv1 Main Mode
IKEv1 Aggressive Mode

Hover on the Question mark to view IKE Help information.

- b. Select the **Algorithm Proposal**. This is a set of algorithms used for negotiation when attempting to establish the IPsec tunnel. By default, the node will attempt to negotiate the tunnel using a list of common algorithms which are considered safe. Alternatively, a set of

default proposals that guarantee Perfect Forward Secrecy (PFS) can be selected.

- c. Select **Initiate** to actively initiate the tunnel by sending IKE negotiation packets to the remote end.
 - d. Set up the **Phase 1** and **Phase 2** time interval between the key material refresh of the IKE and Child.
5. Configure the **Authentication**:
- OM Authentication can use PSK or PKI.

- a. **For pre-shared key (PSK) authentication**, enter a pre-shared secret key; both ends of the tunnel must use the same key.

Tip:

To construct ID_USER_FQDN identities, use `user@example.com`

To construct ID_FQDN type identities, use `@host.example.com`

If left blank, the outer local IP address of the tunnel is used as the identity.

- a. Enter a **Local ID** Identity or IP address for the local end of the tunnel. If left blank, the outer-local IP address is used as the source address of the tunnel.
 - b. **For Public Key Infrastructure (PKI) authentication**, upload the certification bundle file or drag and drop the file into the Certificate Bundle field.
6. Configure the **Tunnel Settings**:
- a. Select **Enabled** if enforced UDP encapsulation is required. When enabled, the IKE daemon can simulate the NAT detection payload.
7. Configure the **Addressing**:
- a. Enter the **Local Address** to be used as the source address of the tunnel.
If left blank, IPsec automatically uses a default.
 - b. Enter a **Local Subnet**.
Specify local traffic to be tunneled. When no subnets are specified, only traffic originating from this device is tunneled.

- c. Enter the **Remote Address** or hostname for the remote end of the tunnel.
If left blank, IPsec accepts initiation packets from any address.
 - d. Enter the **Remote Subnet**.
Specify addresses or subnets that are behind the remote end of this tunnel. If no subnet is specified, only traffic originating from the outer remote address is accepted.
8. Configure **Dead Peer Detection**:

Tip: Dead Peer Detection may be used to support long-lived tunnels.

Dead Peer Detection (DPD) is a method used by nodes to verify the current existence and availability of IPsec peers. A node performs this verification by sending encrypted IKE Phase 1 notification payloads (R-U-THERE messages) to a peer and waiting for DPD acknowledgments (R-U-THERE-ACK messages) from the peer.

You can enable DPD and configure the various options to fine-tune the functionality:

DEAD PEER DETECTION

Dead Peer Detection

Disabled

Enabled

Delay ⓘ

60

Seconds

Timeout ⓘ

90

Seconds

Action ⓘ

Restart

- **Delay** - the time interval between polling the peer (default is 60 seconds).
- **Timeout**- the waiting time before deciding that a peer connection is not live (default is 90 seconds).
- **Action** - the action to be performed when a connection is timed-out. (default is Restart).
 - **Restart** immediately attempts to renegotiate the tunnel.

- **Clear** closes the CHILD_SA.
 - **Trap** catches matching traffic.
9. When you have completed the IPsec Tunnel set-up process, ensure the IPsec tunnel status is set to **Enabled**, then, click **Save**.

The new tunnel is now listed on the **CONFIGURE > NETWORK CONNECTIONS > IPsec Tunnels** page.

STATIC ROUTES

Static routes are predefined paths that traffic can be configured to take through the network for purposes such as security, cost or to override the default route.

The list of configured static routes displays in a table with their current status indicated by the status column.

Status	Meaning
Installed	The route is installed in the routing table.
Not Installed	The route may not be currently installed but should update in a moment.
Error	The route failed to be installed.
Failed to fetch status	There is an error with the system and status failed to be obtained. This is a temporary error and should update in a moment.
The network interface is disabled	The static route is bound to an interface which is not enabled.

Status	Meaning
The network interface is disconnected	The static route is bound to an interface which is not connected.
The network interface has no active connections	The route cannot be installed as there are no active connections on this interface.

CONFIGURE STATIC ROUTES

On the **Static Routes** page, you can add, edit, or delete static routes.

Note: Only basic validation is performed when static routes are saved. Check the status column to ensure your route is installed and working correctly.

CREATE A STATIC ROUTE

1. Click the **Add** button to navigate to the creation page.
2. Enter a valid IPv4 or IPv6 destination address or network, followed by the netmask in CIDR notation.
The destination address/network must be unique.
3. Enter the gateway or select an interface for the static route to use.
4. Optionally, provide a metric for the route. Routes with a lower metric value are higher priority.

Destination Address	Default Metric
IPv4	0
IPv6	1024

- Click the **Apply** button to save the changes.
- If the changes are saved successfully you are returned to the Static Routes list page.
 - If there is an error with the configuration and the route fails to install, a red banner displays.
 - If the route installed successfully, a green success banner displays.

The current status of the configured route displays in the table, which may change depending on the status of the network configuration.

EDIT A STATIC ROUTE

- Click the description of the required static route in the list to access the **Edit** page.
- Update the details of the static route.
- Click **Apply** to save the changes.

DELETE A STATIC ROUTE

- Click the description of the required static route in the list to access the **Edit** page.
- Click the **Delete** button at the top-right of the page.
- Click **Yes** to confirm the action.

If the route was removed from the routing table as expected, a green success banner displays.

MANAGE STATIC ROUTES VIA COMMAND LINE

Administrative users can also view the status and perform configuration of static routes via the command line interface.

After you create or modify a route via the command line, you should take note of the route id and confirm that it installed successfully in the routing table.

Description	Command
Display IPv4 installed routes	<pre>ip route</pre>
Display IPv6 installed routes	<pre>ip -6 route</pre>
Display all route information	<pre>ip route show table all</pre>
Show status of configured routes via ogcli	<pre>ogcli get monitor/static_routes/status</pre>
Get static route configuration via ogcli	<pre>ogcli get static_routes</pre>

Description	Command
Create static route via ogcli	<pre>ogcli create static_route << END destination_address="1.1.1.1" destination_netmask=32 gateway_address="1.1.1.1" interface="net1" metric=0 END</pre>
Update static route via ogcli	<pre>ogcli update static_route "1.1.1.1" << END interface="net2" metric=100 END</pre>
Delete static route via ogcli	<pre>ogcli delete static_route "1.1.1.1"</pre>

NETWORK RESILIENCE

Under the NETWORK RESILIENCE menu, you can manage Out-of-Band (OOB) and IP Passthrough settings.

OUT-OF-BAND FAILOVER


Out-Of-Band (OOB) Failover detects network disruption via the probe interface, and automatically activates a cellular or ethernet interface connection to re-establish network access.

OOB failover requires an IPv4 address (in dotted decimal format), or an IPv6 address, or a domain name, which is always reachable and unlikely to change. When OOB failover is enabled, the node regularly pings this address, using the probe interface, to check for network connectivity.


ENABLE OUT-OF-BAND FAILOVER


1. To manage out-of-band Failover, navigate to the **CONFIGURE** > **NETWORK RESILIENCE** > **OOB Failover** page.


FAILOVER SETTINGS

Status 

☒ Enabled
 ☐ Disabled

Probe Interface 



Probe Address 

Probe Interface: this is the interface that is used to test if ping can reach the configured address.

Probe Address: the ipv4 or ipv6 or domain name of the address that is “pinged”.

2. In the **Failover Interface** section, select the failover interface from the drop-down list.

Failover Interface ?



Configurable probe (failover from) and failover (failover to) interfaces are shown:

- **NET1** - the default probe interface.
 - **Cellular** - the default failover interface for cellular-capable models.
 - **NET2** - the default failover interface for non-cellular models.
3. When you have completed the OOB Failover set-up, ensure the OOB Failover status is set to **Enabled**, then, click **Apply**.
A confirmation displays.
 4. On the **Network Interfaces** page, the Failover Interface displays "Configured for OOB Failover" beside the interface name.

 Configured for OOB Failover 

5. When failover is triggered, the interface is marked with the warning: **OOB Failover Active** to an Admin user when logged in.

 Failover Connection Active


Note:

- It may take up to five minutes for a failover to actually occur after the probe stops connecting to the probe address.

- The shortcut button **Enabled/Disabled** is disabled or removed when an interface is in active failover.

DNS QUERIES ON A DORMANT FAILOVER INTERFACE

The Dormant DNS option allows DNS queries on the failover interface to be disabled in normal operation so that DNS queries can be paused.



The option configures how the DNS name servers and search domains configured for the failover interface are used by the system.

- If set to **Yes**, the DNS name servers and search domains configured for the failover interface will always be available to the system for DNS name resolution. Allowing DNS queries while failover has not been triggered make it more likely that DNS requests are made over the cellular interface which increases data usage.
- If set to **No**, the DNS name servers and search domains are made available to the system only when the failover state is active.

To configure the DNS name servers and search domains, see ["DNS Configuration" on page 1](#).

OOB FAILOVER TYPES & FAILOVER BEHAVIOR

OOB Setting	Failover Interface	Mode	Description
Disabled	Enabled	Always up OOB	<p>When OOB Failover is disabled, the default outgoing interface cannot be specified, the default route is selected automatically.</p> <p>Outbound network connections (e.g. VPN client tunnels, SNMP alerts) are established according to the main static routing table, regardless of network state.</p>
Enabled	Disabled	Failover mode	<p>Failover detection is enabled on the selected “probe” interface. The network or cellular interface remains in a down state with no network configuration.</p> <p>When failover is initiated, the network or cellular interface is started and configured. If a default route is installed on the interface, it takes precedence over the default route on the failed “probe” interface. Outbound network traffic (e.g. VPN client tunnels, SNMP alerts) are established or re-established over network or cellular connection during failover.</p> <p>The advantage of this mode is the secondary connection is completely inactive during normal operation which may be advantageous where the goal is to keep the interface off the Internet as much as possible, e.g. a cellular plan with expensive data rates and no carrier-grade NAT.</p>

OOB Setting	Failover Interface	Mode	Description
Enabled	Enabled	Dormant failover	<p>Failover detection is enabled. Only inbound connections on the network or cellular interface are routed back out the network or cellular interface, to enable OOB access from remote networks (e.g. incoming SSH). Otherwise, outbound network connections (e.g. VPN client tunnels, SNMP alerts) are established according to the main static routing table, regardless of network state.</p> <p>When failover is initiated, the default route of the network or cellular interface takes precedence over the failed "probe" interface. Outbound network traffic (e.g. VPN client tunnels, SNMP alerts) are established or re-established over the network or cellular connection during failover.</p> <p>The advantage of this mode is the network or cellular connection is available for inbound out-of-band access during normal operation.</p>

IP PASSTHROUGH

Nodes with dialout support and an Ethernet port can enable a special DHCP service called IP Passthrough. When IP Passthrough is enabled, other devices (e.g. the "passthrough target" or "downstream host") that are plugged into the Ethernet port operate as if they are directly connected to the dialout network.

1. To manage **IP Passthrough**, navigate to the **CONFIGURE > NETWORK RESILIENCE > IP Passthrough** page.
2. Configure the IP Passthrough Settings:

IP PASSTHROUGH

SETTINGS

☐ Enable ⓘ

Interface ⓘ

☒ NET1 - 1G Copper/SFP

☐ NET2 - 1G Copper/SFP

Downstream MAC Address ⓘ


00:00:00:00:00:00

- a. Click the IP Passthrough status checkbox to set the status to **Enabled**
 - b. From the dropdown selector, select the interface type that is used.
 - c. Enter the MAC address of the downstream device that will make the DHCP requests.
The MAC address of the device is offered a DHCP lease. DHCP requests from other MAC addresses are ignored.
3. Configure the IP Passthrough Service Intercepts:

Tip: When IP Passthrough is enabled, access to this node directly via the cellular interface no longer works. You can configure specific ports below which will be redirected to this node instead of the downstream device.

SERVICE INTERCEPTS

When IP Passthrough is enabled above, access to this device directly via the cellular interface will no longer work. You can configure specific ports below which will be redirected to this device instead of the downstream device.

HTTPS Intercept Port 

SSH Intercept Port 



Apply

- a. Enter the port number that is to be used for HTTPS Intercepts.
 - b. Enter a port to be redirected to this node's SSH service.
- Tip:** You can use this port to access the Operations Manager command line interface. If you leave this field blank, the SSH service intercept is disabled.
- c. Under **Access Control**, enter the blocked and allowed addresses.
 4. When you have completed the IP Passthrough Settings and Service Intercept form, ensure the IP Passthrough status is set to **Enabled**, then, click **Apply**.

USER MANAGEMENT

Under the User Management menu, you can create, edit, and delete groups and users, as well as assign users to groups. You can also set up remote user authentication.

GROUPS

Groups are used to grant privileges to users. When a user is a member of a group, defined privileges may be granted to the group by an Administrator. When editing a group, the (authorized) user selects from a list of devices, all of which are under the heading **SERIALLY CONNECTED DEVICES**.

PERMISSION CHANGES IN THE WEB UI

A new feature change called Access Rights was introduced in release 22.11 to replace the previous concept of a user *Role* and instead uses a set of configurable *Access Rights* for each group. Each access right governs access to a particular feature (or set of highly related features), with a user only having access to features for which they have an assigned access right.

Tip: To support the new permissions model several rest API endpoints have been updated for the new functionality. Wherever possible, these changes are backwards compatible. See the release notes for details.

UNDERSTANDING ACCESS RIGHTS

An access right is a permit authorizing access to a feature or collection of related features. Holders of the permit (i.e., the access right) are given access to the feature.

A user gains access rights by the following:

- Access Rights are assigned to Groups.
- Users are members of zero or more Groups.
- A User inherits all Access Rights from all the Groups they are a member of.

Some features may require the user to hold multiple access rights to access the feature through a specific interface. For example, a user requires the “right to use the web UI” and the “right to configure serial ports” to make configuration changes to a serial port through the web UI.

DEFINED ACCESS RIGHTS

There are four *defined* rights (admin, web_ui, pmshell, and port_config) as summarized in the following table.

Access Rights	Description
admin	The admin access right grants a holder access to everything; every feature and every user interface.
web_ui	Permits access for an authenticated user to basic status information via the web interface and rest API. Users can: <ul style="list-style-type: none"> • Make requests to the subset of endpoints that provide this same information. In both cases the user must be authenticated. • See information about their own user and groups. • See serial port status information for the specific ports to which the user is granted access.
pmshellRestricted CLI	Permits access to devices connected to serial ports. Does not give permission to configure all serial ports, only to those that are added to the same group containing the pmshell rights.
Port Config	Permits access to configure serial ports. This access right gives the holder the ability to configure serial ports. This right does not give the holder the ability to access the serial port.

Tip: A right may be combined with another right for a feature to be accessible by a user. For example, web_ui to log in and port_config to configure a serial port. The port_config right by itself is not useful.

ADMIN ACCESS RIGHTS (*ADMIN*)

Any user who was previously an `Administrator` role now inherits the `admin` access right, giving that user the same “can do everything” permission.

Tip: The **Admin Access** toggle switch in the Web UI hides other rights selections as Admin Access overrides all other rights.

WEBUI ACCESS RIGHTS (*WEB_UI*)

Any user who was previously a Console User role now inherits the `web_ui` and `pmsHELL` access rights and there are no functional changes for this user.

Tip: From release 22.11 in the Web UI, the **Rights** checkbox replaces the **Roles** drop-down selection.

The `web_ui` access right grants the user the ability to

- log into the WebUI.
- see a listing of serial ports (The “Access → Serial Ports” menu item).
- edit a restricted set of user configuration such as changing their own password.

PORTMANAGER SHELL ACCESS RIGHTS (*PMSHELL*)

Any user who was previously a Console User role now inherits the `pmsHELL` access rights and there are no functional changes for this user.












The `pmsHELL` access right grants the user access to the serial port web terminals and the ability to use `pmsHELL` over SSH. These rights are applied only to the access ports to which they have been granted rights.

PORT CONFIGURATION ACCESS RIGHTS

The `port_config` access right grants the holder of this right the ability to make configuration changes to the serial ports they have been assigned. Note that a user without the `web_ui` right cannot log in to the WebUI to configure serial ports, so a user must inherit the `web_ui` from at least one group.

ACCESS > SERIAL PORTS VIEW

Users with the `port_config` access right to some serial ports are able to see the **Edit** link on the **Access > Serial Ports** page for those ports only. Non-Admin users with the `port_config` role are able to see any active sessions on a port but are not able to terminate the session.

LOGGING LEVEL		ESCAPE CHARACTER	
Logging Disabled		~	
	Port-3 Port-3, 9600-8-N-1-X2	 Console Server	 0 Sessions  
	Port-4 Port-4, 9600-8-N-1-X2	 Console Server	 0 Sessions  
	Port-5 Port-5, 9600-8-N-1-X2	 Console Server	 0 Sessions

CONFIGURE > SERIAL PORTS VIEW

The Configure Serial Ports page is accessible to users with the `port_config` and `web_ui` access rights appear in the navigation sidebar menu. This page lists ports that the user has both `port_config` and `web_ui` access rights.

Tip: It is possible to edit all details on these ports, however, changing the “mode” of a port disconnects any sessions.

NON-ADMIN USERS

Non-admin users with `port_config` access right are able to perform Serial Port Autodiscovery on the ports that they are able to configure. If autodiscovery is already running, they can see the banner but cannot view the autodiscovery logs or cancel the running job. Non-admin users are not able to configure the Serial Port Autodiscovery Schedule and the icon is hidden, but are able to see which ports are configured of the ports to which they have access.

PROTECTED GROUPS AND USERS

Certain types of groups and users have protected status, meaning that they cannot be changed or deleted. Protected groups comprise the following:

- `root` - The root user is hard-coded member of the Admin group. As such, the root user cannot be deleted.
- `admin` - The Admin group cannot be disabled or changed to a non-admin group.
- `netgrp` - The special 'netgrp' also cannot be deleted. This group is assigned to users from AAA auth that don't have a group assigned from the authentication server.

Tip: For these protected groups no 'Delete' button displays beside them in the Web UI.

UNDERSTANDING SERIAL PORT ACCESS

Serial ports are assigned to a group in the same way as access rights are assigned to a group, however, it is the access rights that are assigned to the same group that determine what a user can actually do with those serial ports. The access rights assigned to one group will only apply to the serial ports assigned to that same group, they do not apply to the serial ports of another group.

For example, a user in a group with `port_config` and `port-01` can configure that port but not access the device (as that requires `pmshell` access rights).

Consider the following two groups, *Accounts Admin* and *Port #03 User*.

Group Name	Accounts Admin	Port #03 User
Access Rights	port_config web_ui	pmsHELL web_ui
Serial Ports	port-01 port-02	port-03

The effective rights for a user in one or both of those groups is shown in the following table. It shows how access rights assigned to one group will only apply to the serial ports assigned to that same group:


The following table shows the effective rights for a user in one or both of those groups, *Accounts Admin* and *Port #03 User*.

Group Membership	Accounts Admin	Port #03 User	Accounts Admin & Port #03 User
Action			
Configure port-01	✓	✗	✓
Configure port-02	✓	✗	✓
Configure port-03	✗	✗	✗
Access port-01	✗	✗	✗
Access port-02	✗	✗	✗

Access port-03			
----------------	--	--	--

Note: Note the highlighted cell; a user with `pmshell` access to `port-03` (from the *Port #03* user group) does not also get `port_config` for that port, even though that access right is inherited from the *Accounts Admin* group. The access rights of a group *only apply to the serial ports in that same group*. This principle is illustrated in the following figure:

The following image shows how access rights assigned to one group only apply to the serial ports assigned to that same group.



CREATE A NEW GROUP

1. Select **CONFIGURE > USER MANAGEMENT > Groups**.

GROUPS

Click to edit a group

Click to add a new group

NAME	DESCRIPTION	LOCAL MEMBERS	STATUS
admin	Provides users with unlimited configuration and management privileges	1	
netgrp	Group for users created automatically via network authentication	0	

	Add a new group.
admin	Click on the group name to edit an existing group.
<div>Status</div> <div> <input type="checkbox"/> Enabled <input checked="" type="checkbox"/> Disabled </div>	In the EDIT GROUP window - Enable/Disable an existing group.
<div>Admin Access </div> <div> <input checked="" type="checkbox"/> Enabled <input type="checkbox"/> Disabled </div>	Grant administrative access rights and full control of this console, and all attached devices, to all users of this group.
	Delete a group (or delete selected groups).

2. Click the **Add New Group** button.
The **CREATE GROUP** page displays.

CREATE GROUP

Status

Enabled

Disabled

Name ⓘ

Description ⓘ

Admin Access ⓘ

Enabled

Disabled

ACCESS RIGHTS

NAME	DESCRIPTION
<input type="checkbox"/> Web UI	Permits access for an authenticated user to basic status information via the web interface and rest API.
<input type="checkbox"/> PM Shell (Restricted CLI)	Permits access to devices connected to serial ports.
<input type="checkbox"/> Missing translation: general.access_rights.rights.port_config	Missing translation: general.access_rights.rights.port_config_description

- Enter a **Group Name**, **Description**, and set **Admin Access** to **Enabled** or **Disabled**. Specific access rights can be selected in the **ACCESS RIGHTS** area.

Note:

- Group Name** is case sensitive. It can contain numbers and some alphanumeric characters. When using remote authentication, characters from a user's remote groups that are not allowed are converted to underscores during authentication. Local groups can be created that take that into account, allowing the authentication to continue.
- If **Admin Access** is Enabled, members of the group will have full access to and control of selected managed devices, and the rights that are selected under **ACCESS RIGHTS** for that group.

- Select the applicable **Access Rights** for the group.
- If the new group is to be activated immediately, set the group Status to **Enabled**.
- Click the **Submit** button to save the group.

After creation, group **Status** and **Admin Access** may be enabled or disabled from the **CONFIGURE > USER MANAGEMENT > Groups > EDIT GROUP** page.

EDIT AN EXISTING GROUP

1. Select **CONFIGURE > USER MANAGEMENT > Groups**.
2. Click on the name of the group to modify and make the required changes.
3. Click **Submit** to save the changes

The **CONFIGURE > User Management > Groups** page also allows Administrators to delete a group. Users who were members of the deleted group lose any access and administrative rights inherited from the group.

Note:

- The netgrp group is inherited as the primary group for all remote AAA users who are not defined locally. By default, netgrp has the Administrator role and is disabled. It must be enabled to take effect for remote AAA users.
- For users that don't have any group, they are still part of netgrp, even if the netgrp membership is not explicitly enabled for the user.

The permissions for the netgrp members is a union of the permissions that have been given in the netgrp AND the permission for the user in AAA (TACACS+, RADIUS, etc).







If your netgrp "role" says "Console User" and you have priv-lvl 13 in TACACS+ (level 15 being the highest), then the union of that is like an Administrator already, so setting "console user" in netgrp does not matter.

LOCAL USERS







The Local Users feature allows a single point for the creation or management of local user accounts. The Local Users feature can use SSH authorized keys to control user access by using their local password; it is a point of control for:

- Authentication and authorization.
- Creating and editing user descriptions.
- Local passwords.

- User roles (admin or console user).
- Accessible ports.

LOCAL USERS			
			
<input type="checkbox"/>	Username	Description	Actions
<input type="checkbox"/>	root	System wide SuperUser account	  

The button action definitions are described in the following table:

	Add a new local user.
	Edit an existing user.
	Enable an existing user.
	Manage SSH Authorized Keys.
	Disable an existing user (or disable selected users).
	Delete a user (or delete selected users).

CREATE A NEW USER WITH PASSWORD

Note: Users are prevented from using the word “default” as their password. The factory default password automatically expires after a factory reset and users must choose a new password. This password policy applies to the WebUI, Config Shell and CLI. users configured

on the system using software versions prior to 23.10 with password “default” are forced to change the user password to something other than “default” after upgrading to 23.10. This password feature update applies to configured boxes with existing users, not just factory defaulted software.

1. Navigate to the **CONFIGURE > USER MANAGEMENT > Local Users** page.
2. Click the **Add User**  button.

The **New User** dialog displays.

3. Enter a **Username**, **Description**, and **Password** that the new user will use.
4. Re-enter the **Password** in the **Confirm Password** field.
5. Select the **Enabled** checkbox.
6. Click **Apply**.

A banner confirms that the data is saved.

CREATE A NEW USER WITH NO PASSWORD (REMOTE AUTHENTICATION)

Note: If a new user is created with no password, this will cause the user to fall-back use remote authentication.

1. Select **CONFIGURE > User Management > Remote Authentication**.
2. Select a **Mode**.
3. Enter the settings and click **Apply**.
4. Select **CONFIGURE > USER MANAGEMENT > Local Users**.
5. Click the **Add User** button.

The **New User** dialog displays.

6. Enter a **Username**, **Description**.
7. Select the **Remote Password Only** checkbox.

8. Select the **Enabled** checkbox.
9. Click **Apply**.

A banner confirms that the data is saved.

MODIFY AN EXISTING USER ACCOUNT WITH PASSWORD


1. Select **CONFIGURE > USER MANAGEMENT > Local Users**
2. Click the **Edit User** button and make the required changes.
3. Click **Save User**.

A banner confirms the changes are saved.

The **Edit Users** dialog allows the user's **Description** to be changed, **Group Memberships** modified, and the user's **Password** to be reset. The username cannot be changed. To disable a user, uncheck the **Enabled** checkbox.


Note: Users of disabled accounts cannot log in to the Operations Manager using either the Web-based interface or via shell-based logins.

MANAGE SSH AUTHORIZED KEYS FOR A USER ACCOUNT

1. Select **CONFIGURE > USER MANAGEMENT > Local Users**
2. Click the **Manage SSH Authorized Keys**  button for that user.

3. Click the **Add Authorized Key**  button to add a new key.

This opens the **NEW AUTHORIZED KEY** page for this user.



4. Enter the key and click **Apply**.
You can also click on **Add Authorized Key** and disable password for SSH for this user from this page.
5. To delete a key, click **CONFIGURE > USER MANAGEMENT > Local Users** and click the **Manage SSH Authorized Key** button for the user.
6. Click the **Delete** button next to the key you want to remove.

DELETE A USER ACCOUNT

1. Select **CONFIGURE > USER MANAGEMENT > Local Users**
2. Click the **Delete User** button in the **Actions** section next to the user you want to delete.
3. Click **Yes** in the **Confirmation** dialog.

REMOTE AUTHENTICATION

The Operations Manager supports three AAA systems. Select the remote authentication mode to be applied (DownLocal, or Local apply for all modes):

- ["Configure RADIUS Authentication " on the next page](#)
- ["Configure TACACS+ Authentication " on page 156](#)
- ["Configure LDAP Authentication " on page 158](#)

Navigate to **CONFIGURE > USER MANAGEMENT > Remote Authentication**. The Remote Authentication Home page displays.

REMOTE AUTHENTICATION

Mode

RADIUS

Policy

RADIUSDownLocal

RADIUSLocal

Timeout

REMOTE AUTHENTICATION SERVERS

ADDRESS	PORT (DEFAULTS TO 1812)
	1812

+ Add authentication server

REMOTE ACCOUNTING SERVERS

ADDRESS	PORT (DEFAULTS TO 1813)
	1813

+ Add accounting server


Server password

Confirm server password

Tip: All fields in the Remote Authentication form have tooltips that provide additional information to assist with completing the form fields.

CONFIGURE RADIUS AUTHENTICATION

- Under **CONFIGURE > User Management > Remote Authentication**, select **RADIUS** from the **Mode** drop-down menu.



- Select the preferred Radius Remote Authentication policy to be applied:
 - **Radius DownLocal:** Users are authenticated through their local account only if the remote AAA server is unreachable or down. If the credentials provided at log in are incorrect or if the account does not exist on the remote server, the user is denied access.
 - **Radius Local:** If remote authentication fails because the user account does not exist on the remote AAA server, the OM attempts to authenticate the user using a local account as per a regular local log in.
- Enter the authentication **Timeout** value to apply.
The timeout value specifies the number of seconds to wait for a response from the server before trying the next server.

Note: The timeout value is global and applied to all authentication methods when you set the value on one authentication method.

- Add the **Address** and optionally the **Port** of the authentication server.
- Add the **Address** and optionally the **Port** of the RADIUS accounting server.

6. Select whether **Message-Authenticator** is required for server responses.

The default setting is **Do not require Message-Authenticator**. If the default setting is left, RADIUS responses may be subject to BlastRADIUS attack.

7. Add and confirm the **Server password**, also known as the RADIUS Secret.
8. Select the preferred **Radius Server Authentication** method to apply.

Note: The method defaults to PAP if not configured. Ensure that the selected method is supported by the remote server.

9. Click **Apply**.

Note: Multiple servers can be added. The RADIUS subsystem will query them in a round-robin fashion.

To provide group membership, RADIUS must be configured to provide a list of group names via the Framed-Filter-Id attribute. The following configuration snippet shows how this can be configured for FreeRADIUS:

```
operator1 Auth-Type := System
```

```
Framed-Filter-ID = ":group_name=west_coast_admin,east_coast_user:"
```

Note: The Framed-Filter-ID attribute must be delimited by the colon character.

CONFIGURE TACACS+ AUTHENTICATION

1. Under **CONFIGURE > USER MANAGEMENT > Remote Authentication**, select TACACS+ from the **Mode** drop-down menu.
2. Select the preferred TACACS+ Remote Authentication policy to be applied:

- **TACACS+ DownLocal:** Users are authenticated through their local account only if the remote AAA server is unreachable or down. If the credentials provided at log in are incorrect or if the account does not exist on the remote server, the user is denied access.
- **TACACS+ Local:** If remote authentication fails because the user account does not exist on the remote AAA server, the OM attempts to authenticate the user using a local account as per a regular local log in.

3. Enter the authentication **Timeout** value to apply.

The timeout value specifies the number of seconds to wait for a response from the server before trying the next server.

Note: The timeout value is global and applied to all authentication methods when you set the value on one authentication method.

4. Add the **Address** and optionally the **Port** of the TACACS+ authentication server to query.
5. Select the **Log in Method**. **PAP** is the default method. However, if the server uses DES-encrypted passwords, select **Login**.
6. Add and confirm the **Server password**, also known as the TACACS+ Secret.
7. Add the **Service**. This determines the set of attributes sent back by the TACACS+ server

Note: Multiple servers can be added. The TACACS+ subsystem queries them in a round-robin fashion.

```
user = operator1 {
    service = raccess {
        groupname = west_coast_admin,east_cost_user
    }
}
```

8. Enable or Disable **Remote Accounting**.

TACACS Accounting is enabled by default, the Remote Auth Server is used as the Accounting server. However, one or more Accounting Servers can be specified.

- To disable Remote Accounting, select **Disable**
- To enable Remote Accounting, select **Enable**.

REMOTE ACCOUNTING

Enable Accounting

Disable Accounting

Accounting logs for CLI and Console Port logins will be sent to the first available Remote Authentication Server.

Apply

9. Click **Apply**.

Note: For Cisco ACS, see [Setting up permissions with Cisco ACS 5 and TACACS+](#) on the Opendgear Help Desk.

CONFIGURE LDAP AUTHENTICATION

- Under **CONFIGURE > User Management > Remote Authentication**, select **LDAP** from the **Mode** drop-down menu.
- Select the preferred LDAP Remote Authentication policy to be applied:
 - LDAP DownLocal:** Users are authenticated through their local account only if the remote AAA server is unreachable or down. If the credentials provided at log in are incorrect or if the account does not exist on the remote server, the user is denied access.
 - LDAP Local:** If remote authentication fails because the user account does not exist on the remote AAA server, the OM will attempt to authenticate the user using a local account as per a regular local log in.

2. Enter the authentication **Timeout** value to apply.

The timeout value specifies the number of seconds to wait for a response from the server before trying the next server.

Note: The timeout value is global and applied to all authentication methods when you set the value on one authentication method.

3. Add the **Address** and optionally the **Port** of the LDAP server to query. See the ["LDAP and LDAPS Port Settings" on page 161](#) topic.
4. Add the **LDAP Base DN** that corresponds to the LDAP system being queried. For example:

`CN=example-user,CN=Users,DC=example-domain,DC=com`

4. Add the **LDAP Bind DN**. This is the distinguished name of a user with privileges on the LDAP system to perform the lookups required for retrieving the username of the users, and a list of the groups they are members of.
5. Input the password for the **LDAP Bind DN** user and confirm the password.
6. Add the **LDAP Username Attribute**. This depends on the underlying LDAP system. Use `sAMAccountName` for Active Directory systems, and `uid` for OpenLDAP based systems.
7. Add the **LDAP Group Membership Attribute**. This is only required for Active Directory and is generally `memberOf`.
8. If required, check **Ignore referrals** option. When checked, LDAP will not follow referrals to other remote authentication servers when logging users in. If multiple remote authentication servers exist on the network, checking this option may improve log in times.

Note: Multiple servers can be added. The LDAP subsystem queries them in a round-robin fashion.

CONFIGURE LDAP OVER SSL

1. Complete the LDAP Authentication configuration as per "[Configure LDAP Authentication](#)" on [page 158](#).
2. At the SSL section of the LDAP page select the required server protocol:

SSL

Server protocol ?


LDAP only (no SSL)

LDAP only (no SSL)

LDAP over SSL preferred

LDAP over SSL only

CA certificate ?


 Drag your file here, or [select a file](#)

PEM format

Note: The default setting is LDAP only.


Selecting 'LDAP over SSL' uses the ldaps://server.

Selecting 'LDAP over SSL preferred' uses both ldaps://server and ldap://server.

3. Provide a CA Certificate by dragging the CA Cert file into the CA certificate drop box.
By default the LDAP server's CA certificate is verified.
4. If a CA certificate is not provided, certificate verification can be disabled by selecting the **Ignore SSL certificate errors** checkbox.

Note: Ignore SSL Certificate Errors also prevents some other SSL-related certificate errors.

A warning displays if no CA Certificate is present and the **Ignore SSL certificate errors** checkbox is not selected. In this case no LDAP server certificates are considered valid:

 If a CA certificate is not provided, no LDAP server certificates will be considered valid.

Note: The CA Certificate filename is correct when the certificate is initially uploaded. The filename is not maintained or stored, if the page is later revisited the filename is always shown as “cacert.pem”.

5. Click **Apply** to load and apply your settings.

LDAP AND LDAPS PORT SETTINGS

The default ports for LDAP and LDAPS are:

LDAP: Port 389

LDAPS: Port 636

REMOTE AUTHENTICATION

Defaults to 389 for LDAP, 636 for LDAP over SSL, if left blank

ADDRESS	PORT ?
<input type="text"/>	<input type="text" value="389"/>

Port selection warning messages:

- If port 389 has been set and LDAP over SSL is enabled, a warning is shown.
- If any port has been set and LDAP over SSL is preferred, a warning is shown.
- Setting LDAP over SSL preferred and port 389 results in both warnings being shown.

See the warning messages below:

Server protocol ?

LDAP over SSL preferred ▼

⚠ Port 389 is not generally used for SSL connections. Please confirm this is correct. Consider clearing the port, allowing the defaults to be used.

⚠ Both LDAP and LDAP over SSL will attempt to use the same port. This may not work as expected. Consider clearing the port, allowing the defaults to be used.

☐ Ignore SSL certificate errors ?

LIMITATIONS FOR LDAPS IMPLEMENTATION

Previously, the port for LDAP servers had a default value. When upgrading, this port is not cleared. When enabling LDAP over SSL, it may be necessary to clear the port so that the LDAP over SSL default port can be used.

LOCAL PASSWORD POLICY

A Password Complexity policy allows network Administrators to implement and enforce a password policy that meets the customers' security standards for local users (including root). This functionality enables Administrators to mandate the setting of complex passwords thus making it difficult for malicious agents to succeed in password attacks.

Enabling this feature:

- Enforces the use of complex passwords to improve security.
- Schedules expiry of passwords to enforce regular password updates.

Note: Password policy such as complexity and expiry can only be configured by an Administrator. Password requirements are applied to all accounts.

Tip: Password policy may be enabled and configured via the WebUI, REST API, and ogcli. The password policy also applies to underlying CLI tools.

SET PASSWORD COMPLEXITY REQUIREMENTS

Note:

- Some password complexity rules are required, other rules are optional. Optional rules can be selected by clicking on the relevant checkbox.

- Users are prevented from using the word “default” as their password. The factory default password automatically expires after a factory reset and users must choose a new password. This password policy applies to the WebUI, Config Shell and CLI. users configured on the system using software versions prior to 23.10 with password “default” are forced to change the user password to something other than “default” after upgrading to 23.10. This password feature update applies to configured boxes with existing users, not just factory defaulted software.
- See also ["Password Policy Implementation Rules" on the next page](#)

To set the password complexity requirements:

1. Navigate to **CONFIGURE > USER MANAGEMENT > Local Password Policy**.
2. Click the **Enforced** button to implement the password complexity policy (the policy is not activated until the **Apply** button is clicked).
3. Enter the information required to form the password complexity rules to comply with your company policy:
 - Password cannot be a palindrome (required).
 - Minimum length (required).
 - Must contain an upper case letter (optional).
 - Must contain a numeric character (optional).
 - Must contain a special character (non-alphanumeric e.g. #,\$,%).
 - Disallow usernames in passwords (optional).

See ["Password Policy Implementation Rules" on the next page](#)

4. Click the **Apply** button to activate the password complexity policy.

SET PASSWORD EXPIRATION INTERVAL

Password Expiration schedules the expiry of passwords to enforce regular password updates. When this feature is applied and a password becomes expired, an expired password prompt displays at login.

See also "[Password Policy Implementation Rules](#)" below

Note: The Password Expiration policy affects local passwords only and does not apply to remote authentication modes.

To set the password expiration interval:

1. Navigate to **CONFIGURE > USER MANAGEMENT > Local Password Policy**.
2. Click the **Enabled** button to implement the password expiration policy (the policy is not activated until the **Apply** button is clicked).
3. Enter a number to represent the required number of days between mandatory password updates.
The default time is 90 days, and the minimum is 1 day.
4. Click the **Apply** button to activate the password interval policy.

PASSWORD POLICY IMPLEMENTATION RULES

Rule	Policy
------	--------

Expiry Rules	The expiry time is measured in number of whole days. When the expiry period is reached users are required to update their password on their next login. The default expiry period is 90 days, and the minimum is one (1) day.
	If there are existing user passwords when the expiry is enabled, the expiry time is applied from when the password was initially set by the user. If a password falls outside the new expiry period, the user is immediately prompted to change the password.
	Local Password policy is only applied to local passwords and does not apply to remote authentication modes.
	When local password policy is enabled it will remain in force until the feature is turned off.
	If the minimum password length is modified and then the password complexity feature is disabled, the minimum length requirement is not updated.
Complexity Rules	<p>The password cannot be a palindrome (this requirement cannot be disabled except by disabling password complexity entirely).</p> <p>(A palindrome is a word or other sequence of characters that reads the same backward as forward, such as <i>madam</i> or <i>racecar</i>).</p>
	The minimum length (enforced) must be at least 8 characters (this requirement cannot be disabled except by disabling password complexity entirely).
	The password should contain at least one upper case alphabetic character (enabled or disabled separately).
	The password must contain at least one numeric character (enabled/disabled separately).
	The password should contain at least one special character (e.g., #,\$,%) (enabled/disabled separately).

	The password cannot contain your username.
	Complexity requirements will apply when a user next tries to update their password.
	An Administrator can force the expiry of a user's password by running the ogcli command: <code>passwd --expire {username}</code> to force a user to change their password.
	The operations <code>ogadduser</code> , <code>ogpasswd</code> and <code>ogsshaddsshkey</code> have been removed. You should instead use ogcli for these operations.

SERVICES

The **CONFIGURE > SERVICES** menu lets you manage services that work with the Operations Manager.

FIPS COMPLIANCE

The Federal Information Processing Standard Publication 140-2 (FIPS 140-2) is a U.S. government computer security standard that is used to approve cryptographic modules. Opengear appliances operating in FIPS mode provide FIPS 140-2 level one compliance by utilizing FIPS validated OpenSSL 3.0.8 cryptographic library while in FIPS mode.

Note: The default provider is 3.0.10, however, the FIPS provider remains on 3.0.8 in release 23.10.4. See the example of list providers later in this topic under the section "[Verify that FIPS is Enabled](#)" on page 168.

CONFIGURE FIPS

Enable FIPS mode at the CLI as follows:

ENABLE FIPS

ENABLE FIPS VIA CONFIG SHELL:

```
root@<device name>:~# config
Welcome to the Opengear interactive config shell. Type ? or help for help.
config: system/fips
config(system/fips): enabled true
config(system/fips): apply
Updating entity system/fips.
```

ENABLE FIPS VIA OGCLI:

```
ogcli update system/fips enabled=true
```

DISABLE FIPS

DISABLE FIPS VIA CONFIG SHELL:

```
root@<device name>:~# config
Welcome to the Opengear interactive config shell. Type ? or help for help.
config: system/fips
config(system/fips): enabled false
config(system/fips): apply
Updating entity system/fips.
```

DISABLE FIPS VIA OGCLI:

```
ogcli update system/fips enabled=false
```

VERIFY THAT FIPS IS ENABLED

1. Check the OpenSSL FIPS providers.

```
root@<device name>:~# openssl list -providers

Providers:

default

  name: OpenSSL Default Provider
  version: 3.0.10
  status: active

fips

  name: OpenSSL FIPS Provider
  version: 3.0.8
  status: active
```

2. Check that the digest algorithms provided by OpenSSL is limited to FIPS compliant ciphers/algorithms.

```
root@<device name>:~# openssl list -digest-algorithms

...

Provided:

{ 2.16.840.1.101.3.4.2.1, SHA-256, SHA2-256, SHA256 } @ default
{ 2.16.840.1.101.3.4.2.10, SHA3-512 } @ default
{ 2.16.840.1.101.3.4.2.8, SHA3-256 } @ default
{ 2.16.840.1.101.3.4.2.7, SHA3-224 } @ default
{ 2.16.840.1.101.3.4.2.2, SHA-384, SHA2-384, SHA384 } @ default
{ 2.16.840.1.101.3.4.2.3, SHA-512, SHA2-512, SHA512 } @ default
{ 2.16.840.1.101.3.4.2.5, SHA-512/224, SHA2-512/224, SHA512-224 } @ default
{ 2.16.840.1.101.3.4.2.12, SHAKE-256, SHAKE256 } @ default
{ 1.3.14.3.2.26, SHA-1, SHA1, SSL3-SHA1 } @ default
{ 2.16.840.1.101.3.4.2.9, SHA3-384 } @ default
{ 2.16.840.1.101.3.4.2.11, SHAKE-128, SHAKE128 } @ default
```



```
{ 2.16.840.1.101.3.4.2.4, SHA-224, SHA2-224, SHA224 } @ default
{ 2.16.840.1.101.3.4.2.6, SHA-512/256, SHA2-512/256, SHA512-256 } @ default
{ KECCAK-KMAC-128, KECCAK-KMAC128 } @ default
{ KECCAK-KMAC-256, KECCAK-KMAC256 } @ default
{ 2.16.840.1.101.3.4.2.1, SHA-256, SHA2-256, SHA256 } @ fips
{ 2.16.840.1.101.3.4.2.10, SHA3-512 } @ fips
{ 2.16.840.1.101.3.4.2.8, SHA3-256 } @ fips
{ 2.16.840.1.101.3.4.2.7, SHA3-224 } @ fips
{ 2.16.840.1.101.3.4.2.2, SHA-384, SHA2-384, SHA384 } @ fips
{ 2.16.840.1.101.3.4.2.3, SHA-512, SHA2-512, SHA512 } @ fips
{ 2.16.840.1.101.3.4.2.5, SHA-512/224, SHA2-512/224, SHA512-224 } @ fips
{ 2.16.840.1.101.3.4.2.12, SHAKE-256, SHAKE256 } @ fips
{ 1.3.14.3.2.26, SHA-1, SHA1, SSL3-SHA1 } @ fips
{ 2.16.840.1.101.3.4.2.9, SHA3-384 } @ fips
{ 2.16.840.1.101.3.4.2.11, SHAKE-128, SHAKE128 } @ fips
{ 2.16.840.1.101.3.4.2.4, SHA-224, SHA2-224, SHA224 } @ fips
{ 2.16.840.1.101.3.4.2.6, SHA-512/256, SHA2-512/256, SHA512-256 } @ fips
{ KECCAK-KMAC-128, KECCAK-KMAC128 } @ fips
{ KECCAK-KMAC-256, KECCAK-KMAC256 } @ fips
```

CONSIDERATIONS FOR USING THE FIPS FEATURE

In organizations where FIPS is required, the following points should be noted:

- OpenSSL 3.0.8 FIPS provider limits the available cryptography ciphers/algorithms only those that have been validated by laboratory to be FIPS compliant.
- Configuration backup should be taken before enabling or disabling FIPS.
- FIPS has the potential to break any service with secure connectivity, including services listed in the following table:

Feature	Affected Process/Service	Impact
Lighthouse enrollment	OpenVPN	OpenVPN is not compliant with FIPS standards; this issue is a recognized problem specifically when OpenSSL 3.x is being used. When OpenVPN addresses this issue, it will also meet FIPS compliance standards. However, for compatibility with Lighthouse enrollment, this feature remains enabled although it is non-compliant.
IPsec	Strongswan	Must be operated in FIPS mode to be FIPS compliant. The other end of the tunnel does not have to be operating FIPS mode to connect.
Remote authentication	freeradius, tacacs, ldap	These are not FIPS compliant.
NTP	chrony	Authenticated NTP servers with MD5 will not connect. Use an algorithm that is FIPS compliant.
SNMP	ogtrapd, snmpd, snmptrapd	Authentication and Encryption should be used as the security policy as V1 and V2 have no encryption. SNMPv3 with MD5 encryption will fail. Use an algorithm that is FIPS compliant. It is recommended that authPriv security policy is used when in FIPS mode for SNMPv3.
LDAP	OpenSSL	LDAP has no encryption, therefore it does not use OpenSSL. For FIPS compliance it is recommended that it is not used.

Feature	Affected Process/Service	Impact
OpenSSL	OpenSSL MD5	When OpenSSL MD5 is not available, pam_tacplus uses its own implementation of MD5. When FIPS is enabled it does not use OpenSSL (but will continue to work). Therefore, it is recommended that it is not used in FIPS mode.
SMF	SMF	Use of the SMF feature will render the device non-compliant for FIPS.
SSH connections	SSH	For SSH connections, a FIPS compliant algorithm must specified as part of the command to connect. See the note below:
NetOps Modules	gre (Secure Provisioning) nom-ipaccess-lhvpn (IP access) nom-ag-lhvpn (Access Gateway)	Opengear NetOps Modules are not functional when FIPS mode is enabled.
Note: SSH requires the cipher to be manually specified when FIPS is enabled. e.g. ssh root@10.0.0.1 -c aes256-gcm@openssh.com		
WireGuard		WireGuard is not FIPS compliant and should not be used in FIPS mode.
Routing protocols		Routing protocols (eg. BGP), should not select an MD5 cipher.

BRUTE FORCE PROTECTION

A brute-force attack is an attempt to discover a password by systematically trying every possible combination of letters, numbers, and symbols until the one correct combination that works.

Brute Force Protection offers an essential defense mechanism by automatically blocking access from offending source IP addresses.

Caution: Brute Force Protection may prevent access to the system during an emergency.

CONFIGURE BRUTE FORCE PROTECTION

Note: Brute Force Protection is enabled by default for SSH and WebUI.

To configure Brute Force Protection:

1. Navigate to **CONFIGURE > SERVICES > Brute Force Protection**.
2. Choose the required settings:

Field	Values	Description
SSH Protection	Enabled / Disabled	Enable Brute Force Protection for SSH login attempts.
HTTPS Protection	Enabled / Disabled	Enable Brute Force Protection for WebUI login attempts.
Maximum failed attempts	Attempts: 3 (minimum) Time period in minutes: 1 (minimum)	The number of failed access attempts permitted within the given time period before preventing access.


Field	Values	Description
Lockout period	60 (minimum)	The number of seconds that an IP address is banned after violating the Brute Force Protection policies.

3. Click **Apply** to save the changes.

VIEWING CURRENT BANS

IP addresses that are currently blocked appear in the CURRENT BANS section of the WebUI, displaying the address and remaining duration of the ban or how long ago the ban was lifted.

Hover over the ban time for more detailed information.



CURRENT BANS

10.0.0.150
The ban was removed a minute ago

10.0.0.151
The ban was removed a minute ago

10.0.0.152
The ban was removed a minute ago

10.0.0.153
The ban was removed a few seconds ago

Banned since:
Tue Sep 14 2021 16:15:50 GMT-0600

MANAGING BRUTE FORCE PROTECTION VIA COMMAND LINE

For more control over Brute Force Protection, administrative users can use the command line to configure the service and remove bans manually.

Description	Command	Notes
Display Brute Force Protection configuration	<pre>ogcli get services/brute_force_protection</pre>	
Update Brute Force Protection configuration	<pre>ogcli replace services/brute_force_protection << END ban_time=180 find_time=1 https_enabled=false max_retry=4 ssh_enabled=true END</pre>	<p>Ban time in seconds.</p> <p>Find time in minutes.</p>
Un-ban an IP address	<pre>fail2ban-client unban <ipaddress></pre>	
Un-ban all current bans	<pre>fail2ban-client unban --all</pre>	
List SSH bans	<pre>fail2ban-client status sshd</pre>	SSH protection must be enabled.
List HTTPs bans	<pre>fail2ban-client status https</pre>	HTTPs protection must be enabled.

Description	Command	Notes
List all bans with ogcli	<pre>ogcli get monitor/brute_force_ protection/bans</pre>	

HTTPS CERTIFICATE

The Operations Manager ships with a private SSL Certificate that encrypts communications between it and the browser.

To examine this certificate or generate a new Certificate Signing Request, select **CONFIGURE > SERVICES > HTTPS Certificate**. The details of the **Current SSL Certificate** are shown on the landing page.

CURRENT SSL CERTIFICATE

Common Name ⓘ

default

The group overseeing this device.

Organizational Unit ⓘ

Organization ⓘ

Locality/City ⓘ

State/Province ⓘ

Country ⓘ

US

Email ⓘ

Key Length (bits) ⓘ

2048

Issue Date ⓘ

Apr 26 20:11:11 2021 GMT

Expiry Date ⓘ

Apr 27 20:11:11 2022 GMT

Tool tips assist with completing the form

Below this listing is a **Certificate Signing Request** form, which can be used to generate a new SSL certificate. Complete the form, then click **Apply**.

CERTIFICATE SIGNING REQUEST

Common Name ⓘ

The group overseeing this device.

Tool tips assist with completing the form content

Organizational Unit ⓘ

Organization ⓘ

Locality/City ⓘ

State/Province ⓘ

Country ⓘ

Email ⓘ

Key Length (bits) ⓘ

Challenge Password ⓘ

Confirm Password ⓘ

Private Key File ⓘ

 No file chosen

NETWORK DISCOVERY PROTOCOLS

The Operations Manager displays LLDP/CDP Neighbors when enabled for a connection. See **CONFIGURE > SERVICES > Network Discovery Protocols** to enable/disable.

The **CONFIGURE > SERVICES > Network Discovery Protocols > LLDP/CDP NEIGHBORS** page allows you to enable this service by clicking the **Enabled** checkbox.

You can set a System Description that overrides the default system description sent by the network discovery protocol daemon. The default description is the kernel name, the node name, the kernel version, the build date, and the architecture.

A value can be entered in the CDP Platform Override to override the CDP platform name. The default name is the kernel name (Linux).

NETWORK DISCOVERY PROTOCOLS

SETTINGS

Enabled
☒

Link Layer Discovery Protocol (LLDP) and Cisco Discovery Protocol (CDP).

System Description Override

Use this setting to override the default system description

This setting overrides the default system description sent by the network discovery protocol daemon. The default description is the kernel name, the node name, the kernel version, the build date and the architecture.

CDP Platform Override

Use this setting to override the default CDP platform name

This setting overrides the CDP platform name. The default name is the kernel name (Linux).

Select one or more checkboxes in the **NETWORK INTERFACES** section of the page and click **Apply**.

NETWORK INTERFACES

Selecting an interface allows LLDP/CDP monitoring for that interface.

NET1 - 1G Copper/SFP

☒

NET2 - 1G Copper/SFP

☐

Apply

ROUTING

The Operations Manager supports Static Routing and Dynamic Routing. Static Routing and OSPF are currently configured via the ogcli interface, however, CLI configuration will not persist after a device reboot. Dynamic Routing can be enabled via the WebUI and configured using standard Free Range Routing interfaces (e.g., vtysh).

Note: Configuration set via vtysh (or other FRR interfaces) must be manually backed up in addition to a standard Opendgear configuration export.

DYNAMIC ROUTING

To enable Dynamic Routing on the OM, navigate to the **CONFIGURE > SERVICES > Routing** page.

Dynamic Routing supports four routing protocols, these are:

- BGP (Border Gateway Protocol)
- OSPF (Open Shortest Path First Protocol) (see ["OSPF Configuration" on the next page](#) later in this topic).
- IS-IS (Intermediate System to System Protocol)
- RIPD (Routing Information Protocol)

Select the preferred routing protocol then click **Apply**.

Note: If no protocol is selected, no route sharing services are run on the OM.

ROUTING

DYNAMIC ROUTING PROTOCOL

☐ BGP (Border Gateway Protocol)
 ☐ OSPF (Open Shortest Path First Protocol)
 ☐ IS-IS (Intermediate System to System Protocol)
 ☐ RIPD (Routing Information Protocol)

Apply

STATIC ROUTING (VIA THE OGCLI)

To enable Static Routing on the OM, open an ogcli terminal by navigating to **ACCESS > Local Terminal**.

STATIC ROUTING OGCLI HELP

For Help on implementing a Static Route protocol via ogcli, enter the command:

```
ogcli help static_routes
```

CREATE STATIC ROUTE - EXAMPLE:

```
ogcli create static_route << 'END'
destination_address="10.1.45.0"
destination_netmask=24
gateway_address="192.168.1.1"
interface="system_net_physifs-1"
metric=100
END
```

STATIC ROUTING ARGUMENTS

Argument	Description
<code>get</code>	Get a list of static routes.
<code>create</code>	Add a static route.
<code>replace</code>	Similar to the "Create Static Route" example given on the previous page. Creates a single static route by specifying its UUID; or a list of static routes. Overwrites existing routes.
<code>delete</code>	Delete all static routes.
<code>merge</code>	Merge the existing configuration list with a new list.

OSPF CONFIGURATION

Open Shortest Path First (OSPF) is a link-state routing protocol used to discover routes on a network. It is used to dynamically adjust routes on the Console Server so that subnets connected to different interfaces can reach each other by routing through the Console Server.

Support for OSPF configuration and WireGuard was added to the REST API and Config Shell at release 23.02.

Caution: Users are discouraged from editing OSPF configuration when it has been marked as managed by a Lighthouse. A warning message displays when an attempt is made to edit any configuration pushed down from Lighthouse through Config Shell. After being warned of the risk users may continue to edit configuration with a **managed_by** field set through Config Shell.

 This zone is managed by **Lighthouse** and cannot be edited.

MANAGED CONFIGURATION ITEMS

Certain items in the configuration can contain an optional **managed_by** field. Configuration items that have the **managed_by** field set are considered to be "managed". The **managed_by** field is set by a managing entity such as lighthouse, when the network plan is being managed by a remote node.

The following features can have managed configuration:

- Firewall Zones
- Firewall Policies
- Routing OSPF
- WireGuard Tunnels

If a firewall zone, policy or WireGuard tunnel is managed, this does not affect sister contexts, for example, if the WireGuard tunnel is managed, any other WireGuard tunnels configured separately by the user are not managed. However, there is only one OSPF configuration file and users must bypass the **managed_by** field in Config Shell in order to edit the configuration.

NEW FIELDS IN REST API & CONFIG SHELL

REST API

The OSPF sub-object now has a number of new fields:

```
"services": {
  "routing": {
    "bgpd": {
      "enabled": true
    },
    "isisd": {
      "enabled": false
    },
    "ripd": {
      "enabled": true
    },
    "ospfd": {
      "enabled": false,
      "router_id": "",
      "redistribute_connected": false,
      "redistribute_static": false,
      "redistribute_kernel": false,
      "interfaces": [],
      "neighbors": [],
      "networks": []
    }
  }
}
```

CONFIG SHELL

The services/routing OSPF context has new fields similar to the REST API:

```
config(services/routing ospfd): show
Entity services/routing field ospfd
  enabled false
  redistribute_connected false
  redistribute_static          false
  router_id                   ""
  interfaces (array)
  neighbors (array)
  networks (array)
```

Field	Condition	Definition
enabled	(true / false)	When set to true, the OSPF service is started.
redistribute_connected	(true / false)	If this option is enabled, any directly connected network routes are broadcast to OSPF neighbours.
redistribute_static	(true / false)	Network routes can be statically defined (in OSPF, not the Linux Kernel) by editing the ospfd.conf file or through vtysh. If this option is enabled, redistribute_routes broadcasts any static routes that are managed by OSPF.
redistribute_kernel	(true / false)	If this option is enabled, network routes that are configured in the Linux kernel via DHCP or static definition are shared with OSPF neighbors.
router_id		The router id (RID) is a 32-bit number which must be expressed as a dotted quad (i.e. in the format A.B.C.D). The RID is used to identify the router. It must be unique within the OSPF network. The highest RID in the network is used to determine which OSPF node is the designated router.

INTERFACES, NEIGHBORS AND NETWORKS.

There are a number of sub-objects under the ospfd context: interfaces, neighbors and networks.

INTERFACES CONTEXT

The services/routing OSPF interfaces context is an array in which each element holds the specific individual interface related parameters for OSPF. Each interface has the following fields:

```
Entity services/routing field ospfd interfaces 0
  auth_method      ""      (required)
  cost              ""
  priority          ""
  name              ""      (required)
  non_broadcast     ""      (required)
  passive           ""      (required)
```

Definitions of interface related parameters for OSPF:

Parameter	Definition
auth_method	<p>The authentication method to use for communications on this interface. Should be one of 'no_auth', 'cleartext' or 'md5'. If authentication is enabled (i.e. not no_auth), one or multiple authentication keys can be configured depending on your authentication method chosen.</p> <ul style="list-style-type: none"> • Cleartext authentication only requires one authentication key. • Md5 authentication can use multiple authentication keys, each of which requires a unique id.
cost	<p>The link cost of the interface used in OSPF route calculations. It is normally auto-calculated, but can be specified manually in the range of 1 to 65535.</p>

priority	The priority of a router on an OSPF interface mainly is used to determine the designated router/backup designated router (DR/BDR) for a network. OSPF forwards all messages to the designated router, reducing the amount of repetitive routing traffic on the network. The priority is in the range of 0 to 255. The default priority for each router is 1 unless specified. Selecting a priority of 0 makes the router unable to become a DR/BDR. The higher the priority, the higher chance a OSPF router has of winning the DR/BDR election.
name	The name of the interface these settings apply to. This should match the name of an interface on the device.
non_broadcast	May be true or false. If true, the interface is marked as non broadcast for OSPF purposes. This would mean OSPF would not use multicast on this interface, and static neighbours would have to be defined.
passive	May be true or false. If true, the interface should be marked as passive for OSPF purposes. This would mean LSAs are not traded on this link.

NEIGHBORS CONTEXT

The services/routing OSPF neighbors context is an array where each element holds details about adjacent static neighbor devices. Neighbors must be specified for non-broadcast networks.

```
config(services/routing ospfd neighbors): add
config(services/routing ospfd neighbors 0): show
Entity services/routing field ospfd neighbors 0
address "" (required)
```

Where `address` is an IPv4 host address of the static neighbor.

NETWORKS CONTEXT

The services/routing OSPF networks context is an array where each element holds IP network configurations to enable the system OSPF service for:

```
config(services/routing ospfd networks): add
config(services/routing ospfd networks 0): show
Entity services/routing field ospfd networks 0
address_with_mask "" (required)
area "" (required)
```

Network Configuration	Definition
address_with_mask	An IPv4 network address with CIDR subnet mask to enable OSPF for (e.g. A.B.C.D/E). No host bits should be set.
area	An OSPF network can be divided into sub-domains or groupings called areas which limit the scope of route information distribution. We specify the area number/id we want the interface to be in. This can be an integer between 0.0.0.0 and 255.255.255.255 or can take a form similar to an IP address A.B.C.D. All routers inside an area must be a part of the same OSPF network and have the same area number/id to become OSPF neighbours.

INTERACTION WITH CONFIGURATION FILES

The first line of `/etc/quagga/ospfd.conf` controls whether the console server configuration system will overwrite the file with new content or keep custom user configuration. This supports customers who want to upload a custom configuration file for OSPF. If the first line contains only the text `! autogen`, the configuration system will overwrite the file, otherwise, the configuration system will have no effect.

To verify the OSPF configuration, the configuration file generated can be found in `/etc/quagga/ospfd.conf`:

```
! autogen
! This configuration file has been autogenerated. Any changes made within
! will be overwritten. To stop this and allow for manual editing, remove
! or change the first line of this file to something other than '! autogen'.
```

```
! The behaviour can be reenabled by restoring the first line to this or by
! completely removing this contents of this file.
!
interface wg-smf-1
ip ospf network non-broadcast
!
interface net1
!
router ospf
ospf router-id 0.0.0.1
log-adjacency-changes
redistribute connected
redistribute static
network 10.0.0.0/24 area 0.0.0.0
network 192.168.41.0/24 area 0.0.0.0
neighbor 10.0.0.1
!
line vty
!
```

CONFIRM OSPF NEIGHBOURS

Use the `vttysh` command line tool to see if OSPF neighbours have been discovered:

```
root@<device name>-q:~# vtysh -c 'show ip ospf neighbor'

Neighbor ID Pri State Dead Time Address Interface RXmtL RqstL DBsmL
- 0 Attempt/DROther 33.007s 10.0.0.1 wg-smf-1:10.0.0.2 0 0 0
```

(Where `wg-smf-1` is a user-named interface).

WIREGUARD CONFIGURATION

WireGuard is an open source encrypted VPN solution; WireGuard configuration support was added to the REST API and Config Shell at release 23.8. WireGuard facilitates communication between two peer devices; in order to communicate with a peer, both devices must have a virtual WireGuard interface configured over the physical or virtual interface they are connected over.

Note: Users who have pre-existing configuration files for WireGuard will not have their configurations overwritten as the configurator only modifies those files if they are initially missing or are prefixed with a disclaimer that manual edits are overwritten.

VIEWING A WIREGUARD CONFIGURATION

WireGuard installs the **wg** tool which can be used to control, configure and monitor WireGuard . Refer to the WireGuard online tools index page: [index : wireguard-tools](#)

Note: Opengear does not own or operate the WireGuard tools web page and is not responsible for its content or maintenance. The link is provided only for the reader's convenience.

CONFIGURE WIREGUARD THROUGH CONFIG SHELL OR REST API

WireGuard is configured through Config Shell or REST API. The minimum configuration of WireGuard is shown in the following:

1. Provide a name for the interface (wg0 in the following example).
2. Set enabled.
3. Set the private_key of your WireGuard interface.
4. Add an address (at least one) for your WireGuard interface (10.0.0.1/24 in this case).
5. Add a peer with the following parameters: endpoint_address, endpoint_port, public_key.

6. Add at least one allowed IP for your peer with `allowed_ips`. This is the WireGuard address(es) (it can also accept an address range) of the other interface to which you are connected.

For example:

```
config: wireguard
config(wireguard): add wg0
config(wireguard wg0): private_key AGiZvFHY+r/dD0rHSKU5ZCrHNdLM0W/h29VxobxWgFo=
config(wireguard wg0): enabled true
config(wireguard wg0): addresses
config(wireguard wg0 addresses): add 10.0.0.1/24
config(wireguard wg0 addresses): up
config(wireguard wg0): peers
config(wireguard wg0 peers): add
config(wireguard wg0 peers 0): public_key
o+quB4sbUAG2hEGSPpMNTnO0YSaQTP7dD+Q4IVjiCW8=
config(wireguard wg0 peers 0): allowed_ips
config(wireguard wg0 peers 0 allowed_ips): add 10.0.0.2/32
config(wireguard wg0 peers 0 allowed_ips): up
config(wireguard wg0 peers 0): endpoint_address 192.168.1.2
config(wireguard wg0 peers 0): endpoint_port 51820
config(wireguard wg0 peers 0): up
config(wireguard wg0 peers): top
```

CONFIG SHELL WIREGUARD CONFIGURATION

The following shows a typical WireGuard configuration in Config Shell:

```
config: show wireguard wg0
Entity wireguard item wg0
  description ""
  enabled true
```

```
mtu 1420
name wg0
port 51820
private_key AGiZvFHY+r/dD0rHSKU5ZCrHNdLM0W/h29VxobxWgFo=
public_key ""
table ""
addresses (array)
  0 10.0.0.1/24
peers (array)
  0 (object)
    endpoint_address 192.168.1.2
    endpoint_port 51820
    keep_alive ""
    public_key o+quB4sbUAG2hEGSPpMNTnO0YSaQTP7dD+Q4IVjiCW8=
    allowed_ips (array)
      0 10.0.0.2/32
post_down_hooks (array)
post_up_hooks (array)
pre_down_hooks (array)
pre_up_hooks (array)
```

REST API WIREGUARD CONFIGURATION

The following shows a typical WireGuard configuration in Config Shell:

```
{
  "wireguards": [
    {
      "enabled": true,
      "post_down_hooks": [],
      "id": "wireguard_tunnels-1",
```

```

    "pre_up_hooks": [],
    "post_up_hooks": [],
    "private_key": "AGiZvFHY+r/dD0rHSKU5ZCrHNdLM0W/h29VxobxWgFo=",
    "name": "wg0",
    "pre_down_hooks": [],
    "addresses": [
        "10.0.0.1/24"
    ],
    "peers": [
        {
            "allowed_ips": [
                "10.0.0.2/32"
            ],
            "public_key":
"o+quB4sbUAG2hEGSPpMNTnO0YSaQTP7dD+Q4IVjiCW8=",
            "endpoint_address": "192.168.1.2",
            "endpoint_port": 51820
        }
    ]
}

```

CONFIGURABLE WIREGUARD FIELDS

The WireGuard <interface-name> context holds the configuration for a WireGuard connection. The following fields can be configured:

WireGuard Field	Description
-----------------	-------------

description	This can be any user text to describe the WireGuard interface.
enabled	Values may be true or false . When enabled, WireGuard is started for this configuration.
mtu	Allows customization of the maximum transmission unit (MTU) for the local WireGuard interface. The range is 1280 - 1472 and if not set, WireGuard will use the internal default of 1420.
name	The name of the WireGuard interface used in the Linux kernel. Names must be unique, max 15 characters and only contain letters, numbers, hyphens or underscores.
port	The port the local instance of WireGuard will listen on. The range is 1 to 65535 and defaults to 51820.
private_key	The private key to use to authenticate the local WireGuard interface. This is obtained by running the wg genkey command.
public_key	The public key that corresponds your private key, which WireGuard peers will authenticate with. This is obtained by running the wg pubkey command.
table	The routing table for the WireGuard routes. Can be a table number, 'off' or 'auto'.

WIREGUARD CONTEXT SUB-OBJECTS

There are a number of sub-objects under the WireGuard context: addresses, peers and hooks.

ADDRESSES

The wireguard <interface-name> addresses context is a list that holds the IPv4 CIDR addresses of the local WireGuard interface. These are statically assigned when the WireGuard interface is brought up.

```
config: wireguard
config(wireguard): add wg0
config(wireguard wg0): addresses
config(wireguard wg0 addresses): add 10.0.0.1/24
```

PEERS

The following list defines the WireGuard settings for WireGuard-capable remote peers. Each peer has the following fields:

```
config(wireguard wg0 peers 0): show
Entity wireguard item wg0 field peers 0
    endpoint_address ""
    endpoint_port ""
    keep_alive ""
    public_key "" (required)
    allowed_ips (array) (required)
```

Peer Field	Description
endpoint_address	A reachable IP address or fully-qualified domain name for the remote peer with a WireGuard interface.
endpoint_port	The port number for which the WireGuard instance is listening on the remote peer.
keep_alive	Equivalent to PersistentKeepalive in the WireGuard config, this specifies how often the WireGuard interface must send a keep alive packet. This helps keep the routing entry alive for scenarios where the peer is behind a NAT.
public_key	The public key that is accepted by the local WireGuard service if offered by a peer for the purpose of mutual authentication during a five step key exchange process.

allowed_ips -	A list which specifies the IP ranges for which a peer routes traffic. For multiple WireGuard interfaces on the same device, the addresses must not overlap. The IP addresses specified here are the addresses of the peer's WireGuard interface(s) - this is where the peer "routes traffic". These are specified as IPv4 addresses in a.b.c.d/<cidr_mask> format.
---------------	--

HOOKS

WireGuard allows for commands to be executed before/after the interface is brought up/down. These can be specified in the following array fields:

Note: Each field is an array of strings that correspond to commands to be executed.

Hook	Description
pre_up_hooks	Run a command before the interface is brought up (optional).
post_up_hooks	Run a command after the interface is brought up (optional).
pre_down_hooks	Run a command before the interface is brought down (optional).
post_down_hooks	Run a command after the interface is brought down (optional).

ADDING A WIREGUARD INTERFACE TO A FIREWALL ZONE

The WireGuard interface can be added to a firewall zone as in the following example:

```
Entity firewall/zone item zone
description "" (required)
label "" (required)
masquerade "" (required)
name zone
permit_all_traffic "" (required)
```

```
address_filters (array)
custom_rules (array)
physifs (array)
port_forwarding_rules (array)
wireguards (array)
```

SSH

To modify the properties of the port used for connecting to serial consoles via SSH, navigate to **CONFIGURE > SERVICES > SSH**.

The following table gives the definitions of the configurable SSH properties.

Parameter	Definition
Serial Port Delimiter	The delimiting character used to separate the username with port selection information. The default delimiter is a plus sign (+). For example, username+port@address.
Port Number for Direct SSH Links	If SSH is configured to be reachable on a non-standard port, the Direct SSH links on the serial ports page will use this port number.
Max Startups Start	The number of unauthenticated connections before they are refused.
Max Startups Rate	This is the percentage of unauthenticated connections refused. This percentage is a probability that increases linearly until the unauthenticated connections reach full.
Max Startups Full	The number of unauthenticated connections allowed.
Unauthenticated Access to Serial Ports	This is the feature Enable/Disable button. For information about Unauthenticated Access to Serial Ports, see "Unauthenticated SSH to Serial Ports" on the next page .

Alternate Base for direct serial port access

Specify an alternate base port for ssh access to ports. The alternate base is in addition to the default base port of 3000.

UNAUTHENTICATED SSH TO SERIAL PORTS

The Unauthenticated SSH Access feature provides the option to access console ports (using TCP high ports) by establishing per-port SSH connection between a console and serial ports at a remote device. This allows a single step log in and avoids the necessity for two log ins to reach a remote end device within secure, closed networks.

Usually, you would have to authenticate on the Opengear appliance, followed by any log in to a device you are connecting to via the serial port.

When unauthenticated access is enabled SSH is available to all serial ports on the device without requiring a password.

Note: Unauthenticated access can be used with or without IP aliases for serial ports.

Caution: For security, **Unauthenticated SSH** should only be used when operating within a trusted, closed network, for example within a lab. There is a security risk in allowing any kind of unauthenticated access to serial ports and any terminals connected to them.

ENABLE UNAUTHENTICATED SSH

Authenticated or Unauthenticated access is determined via a global configuration option.

Unauthenticated access to individual ports is achieved by command such as `ssh -p 300X user@<IP>`.

ENABLE SSH

Note: This feature may be enabled using the default settings without the requirement for configuration.

1. Open the SSH form, **Configure > Services > SSH > SSH (form)**.
2. Complete the SSH form (if this is the first time Unauthenticated SSH has been used), a description of the input data described in the following table.

Property	Definition/Range
Serial Port Delimiter	<p>A character that separates the username and port selection information. The default value is the + character.</p> <p><i>Default is '+', maximum length is 1.</i></p> <p><i>The prohibited characters are '\', '\"', '\'', ',', '=', and '#'.</i></p> <p>Source: schema</p> <p>required ssh_delimiter: string (default = "+"; minimum = 1; maximum = 1; validator = ("ssh_url_delimiter")),</p> <p>Source: validator</p> <pre> if (strlen(v) != 1) valid = 0; else if (v[0] == "\") valid = 0; else if (v[0] == "\"") valid = 0; else if (v[0] == "'") valid = 0; else if (v[0] == ',') valid = 0; else if (v[0] == '=') valid = 0; else if (v[0] == '#') valid = 0; else if (!isprint(v[0])) valid = 0; else { valid = 1; } </pre>

Port Number for Direct SSH Links	This port number is used for direct SSH links on the serial ports page. Set this option if you have configured SSH to be reachable on a non-standard port.
Max Startups Start	The number of connections pending authentication before new connections <i>begin</i> to be refused. <i>Required start: int (minimum = 1; default = 10)</i>
Max Startups Full	The number of connections pending authentication before <i>all</i> new connections are refused. <i>Required full: int (minimum = 1; default = 100)</i>
Max Startups Rate	This is the percentage rate at which new connections are refused after the Max Startups value is reached. The rate is increased to 100% at Max Startup Full. <i>Required rate: int (minimum = 1; maximum = 100; default = 30),</i> <i>The rate at which connections are refused randomly begins at max startup rate and increases linearly until the number of connections pending authentication reach max startups full, in which case 100% of new connections are refused.</i>
Unauthenticated Access to Serial Ports	This is the feature Enable/Disable button.

Alternate Base for direct serial port access	<p>The alternate base port for ssh access to ports in addition to the default base port of 3000. You can set this value to allow access to x + port in addition to 3000 + port. For example, if you set the alternate base to 2000, you can access port 2 with both of the following:</p> <pre>ssh -p2002 root@vom # using alternate base</pre> <pre>ssh -p3002 root@vom # using default base</pre>
--	---

- When required, enable the Unauthenticated SSH feature by clicking the **Enabled** button.

Note: Unauthenticated access to all serial ports is available through SSH on TCP port 3000+ or Serial Port IP aliases.

ENABLE/DISABLE

Enabling or disabling this feature is done in the user interface.

To **enable** the feature click on the **Enabled** button then click the **Apply** button. The feature is enabled immediately and a pop-up will confirm that the feature is enabled.

Note: Clicking the **Apply** button saves any changes you have made to the SSH form. A Details Saved banner confirms that the changes have been saved.

To **disable** the feature click on the **Disabled** button then click the **Apply** button. There is no confirmation pop-up when the feature is disabled.

CONNECTING DIRECTLY TO SERIAL PORTS

For ports that have been configured with the SSH access service, you can connect directly to a port and start a session, bypassing the chooser, by using one of the conventions described in the following:

Convention	Example
Use a network client to connect to the service network Base Port + serial port number.	<pre># SSH to serial port 1 by TCP port ssh -p 3001 -l operator 70.33.235.190</pre> <p>In this example, the SSH base port is TCP port 3000, so SSH to TCP port 3001 directly connects you to serial port 1</p>
SSH to the Opengear node, log in adding +portXX to your username (e.g. root+port01 or operator+port01).	<pre># SSH to serial port 1 by port name ssh -l operator+port01 70.33.235.190</pre>
SSH to the Opengear node, log in adding the +port-label to your username (e.g. root+Router or operator+Router).	<pre># SSH to serial port labelled Router ssh -l operator+Router 70.33.235.190</pre>

Note:

- For additional reading on connecting to serial ports see: [Communicating with serial port connected devices](#).
- Serial ports in the Local Console and Disabled ports modes are not available for SSH connection.


FEATURE PERSIST

If the node has an active console session after closing pmshell, connecting to the node again will resume the session and you are not prompted for the node password.

SYSLOG

Administrative users can specify multiple external servers to which the Syslog can be exported via TCP or UDP. There is a drop-down on each serial port to enable the logging and to define the “scope” of logging.

The Syslog page lists any previously added external syslog servers.



Server Address	Port/Protocol	Port Logs	Minimum Log Severity Level	Description
192.168.123.123	514/UDP	Enabled	6 - Info	-
10.220.1.123	514/UDP	Enabled	6 - Info	SPT Gateway PC (VLAN IP)

ADD A NEW SYSLOG SERVER

Note: The combination of server address, protocol and port should be unique. There can be no duplicates. However, the same server could be used if the other entry is an IPv6 address to the same Syslog server.

Use the following procedure to add a new Syslog Server.

1. Navigate to **CONFIGURE > SERVICES > Syslog**.
2. Click the **Add Syslog Server** button.
The **Add Syslog Server** form opens.
3. In the **Description** field, add a suitable description to help identify the new server.

4. Enter the **Server Address**.
5. Click the **Protocol** switch to select either **UDP** or **TCP**.
6. Enter the correct **Port**. If no port is entered, UDP defaults to port 514 and TCP defaults to 601.
7. From the drop-down list, select the required severity level to be logged, eight levels of log severity are supported.
8. Click **Add** to complete the process.

GLOBAL SERIAL PORT SETTINGS

Global Serial Port Settings will define the Facility used and the Severity of all Syslog serial port activity sent from this node. There are two setting functions, Facility, and Severity. From the drop-down menus, select the preferred Facility and Severity as required.

GLOBAL SERIAL PORT SETTINGS TAB - FIELD DEFINITIONS

[Configure](#) > [Services](#) > [Syslog](#) > [Global Serial Port Settings](#)

Field	Definition
Description	Unique, familiar text description or name given to this syslog server that users will recognize.
Server Address	The IP address of the syslog server you are using for logging.
Protocol	Click to select the required protocol for data transmission to the syslog server.
Port	The Syslog Server IP address.
Minimum Log Severity Level	Log entries with a value equal or greater than the level specified are sent to the server.

Send Serial Port Logs	Click to enable serial port logging.
Add Button	Click to initiate the syslog, wait for confirmation banner.

SYSLOG FACILITY DEFINITIONS

Facility	Definition
Kern	Kernel messages
User	User-level messages
Mail	Mail system
Daemon	System daemons
Auth	Security/authentication messages
Syslog	Messages generated internally by syslogd
lpr	Line printer subsystem
News	Network news subsystem
uucp	UUCP subsystem
Cron	Clock daemon
Authpriv	Security/authentication messages

ftp	FTP daemon
Local	Locally used facilities

SYSLOG SEVERITY DEFINITIONS


Severity	Definition
0- Emergency	System is unusable.
1 - Alert	Action must be taken immediately.
2 - Critical	Critical conditions.
3 - Error	Error conditions.
4 - Warning	Warning conditions.
5 - Notice	Normal but significant conditions.
6 - Info	Informational messages
7- Debug	Debug-level messages

EDIT OR DELETE AN EXISTING SYSLOG SERVER

To edit an existing syslog server, click the hyperlinked **Red Text** server name in the server list (see the Syslog page image above). Make the required changes, then click the **Submit** button.

To delete a server, click the **Delete** icon on the top-right of the **Edit Syslog Server** page.

EDIT SYSLOG SERVER

Delete server


Description

Gateway PC (VLAN IP)

Server Address

10.220.1.123

Protocol

UDP

TCP

Port

514

Minimum Log Severity Level

6 - Info

All messages with a severity level equal or with a greater severity will be sent to the remote server

Send Serial Port Logs

Enabled

Disabled

Cancel

Submit

SESSION SETTINGS

Use **Session Settings** to set timeouts for console sessions where the users have been idle for a specified time. At timeout, the user's Web, CLI or Serial Port sessions are terminated, thus excluding authorized users with physical access to the node that has been left connected.

To set the timeouts for Web, CLI or Serial Port sessions settings, navigate to the **SETTINGS > Services > Session Settings** page.

SESSION SETTINGS

Web Session Timeout

minutes

CLI Session Timeout

minutes

Set to 0 to disable.

Serial Port Session Timeout

minutes

Set to 0 to disable.

Apply

- **Web Session Timeout:** Set the timeout from 1 to 1440 minutes.
- **CLI Session Timeout:** Set the timeout from 1 to 1440 minutes or set it to 0 to disable the timeout. Changes take effect the next time at the next login via the CLI.
- **Serial Port Session Timeout:** Set the timeout from 1 to 1440 minutes or set it to 0 to disable the timeout.

Click the **Apply** button to save the settings.

The new session timeout takes immediate effect on all pmshell sessions, including ones in use.

FILE SERVER

The Operations Manager can be configured to serve files to clients via Trivial File Transfer Protocol (TFTP).

TFTP can be used by nodes on the network to perform a network boot, or to allow backup and restore of configuration files.

Note: Limitations

- The user is responsible for disk space management.
- User permissions cannot be set on files at this time.

ENABLE TFTP SERVICE

Note: The TFTP service is disabled by default.

To enable the TFTP service:

1. Click the **TFTP Enabled** button.



2. Click **Apply** to save the changes.

The TFTP service is now running with a default location of `/mnt/nvram/srv`.

This location is where all files uploaded to the TFTP server is stored.


Note: The disk space usage information displayed on the page indicates the usage of the whole storage volume.

MODIFY FIREWALL ZONES TO ALLOW THE TFTP SERVICE TO BE USED

The TFTP service must be allowed through a firewall zone so that clients may upload and retrieve files.

1. Navigate to the Firewall Management page via **CONFIGURE > FIREWALL > Management**.
2. Expand the required firewall zone and click the **Edit Zone** button.
3. Allow the "tftp" service from the list of Permitted Services.

Permitted Services



- Click **Apply** to save the changes.

On the **File Server** page, the zones with TFTP enabled are now displayed.

ZONES WITH TFTP ENABLED

LAN , WAN

UPDATE THE TFTP SERVICE STORAGE LOCATION

The location used by the TFTP service can be updated using the **ogcli** tool.

Note: The storage location must be an existing directory before running ogcli update.


Caution: Using a storage volume other than **/mnt/nvram** is not recommended. Data may be lost after reboot, or be inaccessible when switching boot slots.

As an administrative user, run:

```
ogcli update services/tftp path=\"<new path>\"
```

SNMP SERVICE

Navigate to the **CONFIGURE > SNMP > SNMP Service** to open the **SNMP Service** page.



SNMP SERVICE

SNMP SERVICE SETTINGS

Enabled
☒ Enabled ☐ Disabled

Port

SNMP Service Port

Enable SNMP v1 & v2c
☒ Enabled ☐ Disabled

Enable SNMP v3
☐ Enabled ☒ Disabled

Protocol
☒ UDP ☐ TCP

SNMP V1 & V2C

Read-Only Community

The Read-Only Community

SNMP Service allows you to specify which SNMP services to enable. When you click on **ENABLED** for **SNMP V1 & V2** or **SNMP V3**, a detail form displays where you can add service specific settings.

You can also specify the **SNMP Service Port** and choose between **UDP** or **TCP** for the **Protocol**.

For **SNMP v3**, you can also set the **Authentication Protocol** to **MD5**, **SHA**, **SHA-224**, **SHA-256**, **SHA-384**, or **SHA-512**.

SNMP ALERT MANAGERS

Navigate to **CONFIGURE > Services > SNMP Alert Managers** to open the **SNMP Alert Managers** page.

See the ["Multiple SNMP Alert Managers" on the next page](#) feature for information about configuring more than one SNMP manager.

To create or configure SNMP Alert Manager, click the **Add New SNMP Alert Manager** button at the top-right of the page.

On this page, you can set the following:

- **Address:** The IPv4 Address or domain name of the computer acting as the SNMP Manager.
- **Version:** The version of SNMP to use. The default is v2c.
- **Port:** The listening port used by the SNMP Manager. The default value is 162.
- **Manager Protocol:** The transport protocol used to deliver traps to the SNMP Manager. The default value is UDP.
- **SNMP Message Type:** The type of SNMP message to send to the SNMP manager. The INFORM option will receive an acknowledgment from the SNMP manager and will retransmit if required. The TRAP option does not expect acknowledgments.
- **Authentication Protocol:** The authentication protocol used for authenticated SNMP v3 messages. Only available when the **Version** is set to v3.

For SNMP V1 & V2C, you can specify a **Community**. This is a group name authorized to send traps by the SNMP manager configuration for SNMP versions 1 and 2c. This must match the information that is setup in the SNMP Manager. Examples of commonly used values are log, execute, net and public.

MULTIPLE SNMP ALERT MANAGERS

The Multiple SNMP Alert Managers feature provides the option to configure more than one SNMP manager. Multiple SNMP Alert Managers can receive, trap and inform events that can be used to trigger remedial action; events can be sent to multiple SNMP Alert Managers. The AR functionality sends traps to all configured SNMP Alert Managers for a reaction of type SNMP. Whether you input an IPv6 address or a domain name, the correct protocol must be selected.

CREATE OR DELETE AN SNMP MANAGER

To create a new SNMP manager:




1. Navigate to **Configure > SNMP > SNMP Alert Managers**.
2. Click the **Add New SNMP Manager** button.

The new **SNMP Alert Manager Form** displays.

3. Complete the fields as appropriate:

Field	Definition
Description	Add a description of the SNMP Alert Manager.
Server Address	<p>Enter the IPv4/IPv6 address or domain name of the computer acting as the SNMP Alert Manager.</p> <p>If you want to use an IPv6 Address, then you must select either UDP6 or TCP6 from the list of Protocols. Whether you input an IPv6 address or a domain name, the correct protocol must be selected.</p>

Port	Enter the listening port used by the SNMP Alert Manager. The default value is 162.
Protocol	<p>Select the transport protocol used to deliver traps or informs (for SNMP v3):</p> <ul style="list-style-type: none"> • UDP - Speeds up transmissions by enabling the transfer of data before an agreement is provided by the receiving party. • TCP - A commonly used protocol used to transmit data from other higher-level protocols that require all transmitted data to arrive. • UDP6 - Similar to UDP but uses IPv6. • TCP6 - Similar to TCP but uses IPv6. <p>If you want to use an IPv6 Address in Server Address, then you must select either UDP6 or TCP6.</p>
Version	<p>The version of SNMP protocol to use. The default value is v2c.</p> <p>For further reading on SNMP versions we suggest:</p> <p>https://en.wikipedia.org/wiki/Simple_Network_Management_Protocol#Protocol_versions</p>
SNMP V1 & V2C Community	A group name authorized to send traps by the SNMP alert manager configuration for SNMP versions 1 and 2c. This must match what is setup in the SNMP alert manager. Examples of commonly used values are log, execute, net and public.

 	Click the Submit button to finalize the New SNMP Manger process.
	Click the bin widget to Delete an SNMP Manager (in the Edit SNMP Manager page).

- Click the **Submit** button.

A banner displays confirming that the new SNMP Manager is successfully created and the new manager displays in the list of SNMP Alert Managers.

Note: For SNMP V3 TRAPS, an Engine ID is provided by default if none is specified. This is generated by the snmpd service and can be found in the SNMPD RUNTIME CONF /var/lib/net-snmp/snmpd.conf. Traps are sent for Alerts added in **Configure > SNMP Alerts**. Traps are also sent to all the configured SNMP Alert Managers for a Playbook SNMP Reaction.

To delete an SNMP manager:

- Click on the IP address of the item to open the **Edit SNMP Manager** page for that SNMP Manager.
- Click on the **Delete SNMP Manager** widget in the top-right of the page.

FIREWALL

In the **CONFIGURE > FIREWALL** menu you can configure:


- "Firewall Guide" on the next page
- "Firewall Management" on page 222
- "Firewall Policies" on page 227
- "Firewall Services" on page 233
- "Adding WireGuard Zones to a Firewall" on page 234

FIREWALL GUIDE

INTRODUCTION

Opengear firmware is equipped with a powerful firewall stack based on leading open source `firewalld` and `nftables` tools. The default firewall rule set is configured with a default-deny policy.

The firewall is based on the concept of configurable Zones. Zones enable operators to create multiple “firewall segments” per node and attach network interface(s), services, filtering policies and filtering rules to the zones.



Note: To access services on the device, a user must have both access through the firewall and the appropriate authorization, e.g., via a local user account or remote AAA.

There are several kinds of rules and policies that may be applied to Zones.

FIREWALL RULES

- Permitted Services Rules allow access to Services for requests arriving on interfaces in the Zone - Services are configurable collections of TCP/UDP port or ports (e.g., TCP port 443 is the device's HTTPS service for WebUI and REST API access). There are pre-defined services, devices also support user-defined services.
- Custom Rules allow the full flexibility of the firewall's rich rule syntax for fine-grained access control and advanced applications.

FIREWALL POLICIES

- Interzone Policies control how Zones may forward traffic between each other - by default Zones may not forward between each other (note that interfaces in the same Zone may always forward between themselves).
- Port Forwarding Rules use destination NAT (DNAT) requests arriving on interfaces in the Zone to an external Target IP/Port, e.g., a web server running on another host
- Additionally, you can apply source NAT (SNAT) to traffic going out of a Zone by checking the Masquerade Traffic option.

EXAMPLE WEBUI CONFIGURATION

The following examples use Permitted Services Rules and Custom Rules features

Note: Some aspects of the WebUI may change in future releases.

EXAMPLE 1: DISALLOW WAN ZONE ACCESS TO HTTPS

The default configuration is to allow HTTPS (i.e. the WebUI & API) on the WAN Zone. To disallow this:

Note: Ensure you are accessing the device via an interface outside the WAN Zone (e.g., NET2 which is the LAN Zone by default) otherwise you may be locked out.

1. Log in to the WebUI as an Administrator user.
2. Select **CONFIGURE > FIREWALL > Management**.
3. Click **WAN** then **Edit Zone**.
4. Scroll down to **Permitted Services**.
5. In the right-hand column, click - to remove **https** service.
6. Any service in the right-hand column allows everyone access to this service from this zone.
7. Click **Apply**.

EXAMPLE 2: PERMIT ACCESS TO WAN ZONE HTTPS FROM A TRUSTED SOURCE NETWORK ONLY

When a service is permitted using a Permitted Services Rule, connections to the service in that Zone are permitted regardless of the originating network the connection is coming from. To disallow connections from all but a trusted source network, use Custom Rules (following examples) instead.

In this example, HTTPS connections from the 10.12.34.0/24 network to the Operation Manager's WAN Zone are permitted, other HTTPS connections on the WAN Zone are disallowed.

Note: Ensure you are accessing the device via an interface outside the WAN Zone (e.g., NET2 which is the LAN Zone by default) or from the trusted source network, otherwise you will lock yourself out.

1. Log in to the WebUI as an Administrator user.
2. Select **CONFIGURE > FIREWALL > Management**.
3. Click **WAN** then **Manage Custom Rules**.

4. Click **Add Custom Rule**.
5. In **Description** enter: *Trusted HTTPS*.
6. In **Rule Content** enter:
`rule family=ipv4 source address=10.12.34.0/24 service name=https accept`

Note: This is supported via firewalld 'rich-rules' option.

7. Click **Apply**.
8. Follow the steps in Example 1 above to remove the HTTPS Permitted Service.

Note: It is not recommended to mix firewall configurations between the UI (WebUI/CLI) and firewalld commands (firewall-cmd) from Linux shell. Commands may be overwritten. Recommended to use either WebUI or CLI for all supported functionality instead of firewall-cmd

CUSTOM RULES (FIREWALLD "RICH-RULES")

This feature enables users to define fine-grained control of services inside a zone. Users can apply custom filter rules to traffic in a firewall zone based on Layer2 Ethernet MAC, L3 IP fields, layer 4 ports, pre-defined services. Actions to permit, deny, drop the defined packets can be included in the rule. Logging facility is also provided via custom rules.

The following sections provide examples and many sample templates that users can directly use in WebUI or CLI in the rich-rules field/section

CUSTOM RULES EXAMPLES:

Example 1: Filter (drop) specific IPv4 source address

```
rule family="ipv4" source address="34.34.36.36" drop
```

Example 2: Permit specific source subnet and list of address

```
rule family="ipv4" source address="34.34.36.0/24" accept
```

Example 3: Permit Specific Service (HTTPS) from a specific source subnet:

```
rule family="ipv4" source address="10.0.0.0/16" service name="https" accept
```

Example 4: Drop Specific Service (HTTP)

```
rule family="ipv4" service name="http" drop
```

Example 5: Permit specific source subnet and log connection attempts

```
rule family="ipv4" source address="10.0.0.0/16" accept log
```

Example 6: Permit IPv6 packets with source address, TCP port number 4000. Log the packets

```
rule family="ipv6" source address="1:2:3:4:6::" port port=4000 protocol=tcp accept  
log
```

Example 7: Permit IPv6 packets with source address, only TCP protocol, from all TCP ports. Log the packets

```
rule family="ipv6" source address="1:2:3:4:6::" protocol value="tcp" accept log
```

USEFUL TEMPLATES FOR USE IN WEBUI OR CLI

In WebUI:

EDIT FIREWALL ZONE - BR

ZONE SETUP

MANAGE PORT FORWARDING

MANAGE CUSTOM RULES

All rules will be wrapped as follows:

```
firewall-cmd --permanent --zone=br --add-rich-rule=RULE_CONTENT
```

Description

Rule Content ?

Allow-34-Net

rule family="ipv4" source address="34.34.36.0/24" accept

In ogcli:

```
ogcli replace firewall/zones << 'END'
firewall_zones[0].custom_rules[0].description="allow rule"
firewall_zones[0].custom_rules[0].rule_content="rule family='ipv4' source
address='192.168.67.101/32' service name='telnet' accept"
...
END
```

SAMPLE RICH RULES TEMPLATES

```
1. rule family="ipv4" source address="<user-to-fill>" accept|drop|reject
```

```
2. rule family="ipv4" destination address="<user-to-fill>" accept|drop|reject
```

```
3. rule family="ipv4" destination address="<user-to-fill>" accept|drop|reject
```

```
4. rule family="ipv4" source address="<user-to-fill>" accept|drop|reject
```

```
5. rule family="ipv4" source address="<user-to-fill>" destination address="<user-to-fill>"
accept|reject|drop log
```

```
6. rule family="ipv4" source address="<user-to-fill>" service name="<user-to-fill>"
accept|reject|drop
```

```
7. rule family="ipv4" source address="<user-to-fill>" destination address="<user-to-fill>"
accept|reject|drop log
```

```
8. rule family="ipv4" source address="<user-to-fill>" destination address="<user-to-fill>"
accept|reject|drop log
```

```
9. rule family="ipv4" source address="<user-to-fill>" port port=<usr-to-fill>
protocol=tcp|udp accept|reject|drop
```

```
10. rule family="ipv4" source address="<user-to-fill>" protocol value="tcp|udp"
accept|reject|drop
```

Note: Ordering of rules is important. See this public article: [Firewalld Rich Rules Explained](#).

In the Template:

- Choose one of the actions accept|reject|drop [Drop action does not send any response back to source, reject does].
- For protocol value, tcp and udp examples are given in template, but many other choices are available.
- For values, source address as example, replace <user-to-fill> with the address. Address can be with or without subnet.

FIREWALL MANAGEMENT

Navigate to the Firewall Management page, **CONFIGURE > FIREWALL > Management**, from here you can:

- Add a new firewall zone.
- Add a firewall service.
- Edit a firewall zone - manage the zone setup.
- Manage port forwarding.
- Manage custom rules for firewalls.

FIREWALL MANAGEMENT

Traffic will be dropped unless the service is added to a zone.

Add a firewall service

Add a firewall zone

LAN

NET2 - 1G Copper/SFP

WAN

NET1 - 1G Copper/SFP

Edit Zone Manage Port Forwarding Manage Custom Rules

Untrusted connections from the Wide Area Network

SERVICES IN ZONE PORT FORWARDING CUSTOM RULES

ALLOWED IP ADDRESSES	SERVICES
0.0.0.0/0	ssh, https, dhcpv6-client, tftp-client, ssh_serial01, ssh_serial02, ssh_serial03, ssh_serial04, ssh_serial05, ssh_serial06, ssh_serial07, ssh_serial08, ssh_serial09, ssh_serial10, ssh_serial11, ssh_serial12, ssh_serial13, ssh_serial14, ssh_serial15, ssh_serial16, ssh_serial17, ssh_serial18, ssh_serial19, ssh_serial20, ssh_serial21, ssh_serial22, ssh_serial23, ssh_serial24, ssh_serial25, ssh_serial26

Firewall Management main page.

FIREWALL ZONE SETTINGS

To change firewall management settings navigate to **CONFIGURE > FIREWALL > Management**.

Note: The application of any custom rules will result in **Permit All Traffic** being enabled in a zone.

ZONE SETUP

You can inspect details of any zone by clicking the **Expand** icon to the right of the zone. When expanded, you can click **Edit Zone** to change settings for a particular zone.


The **Edit Zone** page has three tabs. The **ZONE SETUP** page allows you to:

- Modify the Name of the zone.
- Add a Description for this zone.
- Permit all Traffic.
- Masquerade Traffic.
- Select Physical Interfaces.
- Manage Permitted Services by clicking on Plus or Minus next to each.

Tip: You can use the **Filter Interfaces** and **Filter Available Services** text boxes to limit the list content that displays.

MANAGE PORT FORWARDING

The **MANAGE PORT FORWARDING** tab allows you to add, edit, and delete forwarding rules for the particular zone you are editing.



EDIT FIREWALL ZONE - LAN

Manage Port Forwarding tab

ZONE SETUP | **MANAGE PORT FORWARDING** | MANAGE CUSTOM RULES

Protocol	Original port(s) ⓘ	Target port	Target IP
TCP			

Delete a rule

⊕ Add forwarding rule

Add a new rule

MANAGE CUSTOM RULES

Note: The application of any custom rules will result in **Permit All Traffic** being enabled in a zone.

The third tab, **MANAGE CUSTOM RULES**, allows you to add, edit, and delete custom firewall rules for the zone you are editing. These custom rules continue to exist after reboots, upgrades, and power cycles.

These rules are prioritized by the order they are added.

EDIT FIREWALL ZONE - LAN

ZONE SETUP

MANAGE PORT FORWARDING

MANAGE CUSTOM RULES

ⓘ All rules will be wrapped as follows:

```
firewall-cmd --permanent --zone=lan --add-rich-rule=RULE CONTENT
```

Description

Optional description

Rule Content ⓘ

Firewall rule - see above note on rule formatting|

⊕ Add custom rule

Cancel

Apply

To add a new custom rule:

1. Click **Add custom rule**.
2. Enter an optional description for this rule.
3. Enter the rule content, custom rule content formatted with firewall-cmd syntax.
4. Click **Apply**.

Note: All rules are wrapped as follows:


```
firewall-cmd --permanent --zone=lan --add-rich-rule=RULE CONTENT
```


FIREWALL SOURCE ADDRESS FILTERING

Source address filtering provides an interface by which users can permit access to services (for example, SSH, HTTPS, SNMP) on a device from specific source addresses.

This feature removes generic or global permitted services within firewall zones, and instead allows users to permit a service on a specified source address (or address range) within the firewall zone. Source address filters configured in a zone apply to all the interfaces within that zone.




To access the feature, navigate to the **Configure > Firewall > Management** page through the WebUI then select the current source address filter configuration under the **services in zone** tab for each zone.



To add a source address filter for a zone, select the **edit zone** option under the required zone, which opens the **edit zone page** where source address filters can be configured.

LAN

 NET2 - 1G Copper/SFP

 [Edit Zone](#)  [Manage Port Forwarding](#)  [Manage Custom Rules](#)

Trusted connections from the Local Area Network

SERVICES IN ZONE

PORT FORWARDING

CUSTOM RULES

You can choose to enable permit all traffic, which will permit all traffic in the zone (unless there is a custom rule configured overwriting this behavior).

ZONE BEHAVIOR

Permit All Traffic 

Enabled

Disabled

If the permit all traffic option is disabled, you will have the option to configure permitted services for any allowed source address. Permitted services can be added or removed from each source address filter under the "Services" field.

Source address filters can be added, duplicated or deleted by using the buttons below and to the right of the filter. Any new changes to the source address filters can be seen under the **services in zone** tab for each zone on the main firewall management page.

FIREWALL SOURCE ADDRESS BULK SERVICES

PERMITTED SERVICES

The firewall source ip field allows you to assign permitted services to specified source ip addresses in bulk rather than requiring individual rich rules to add each specific service. This change allows you to easily target specific IP Addresses with permitted services. Enter the target

IP address, select services from the drop-down list and click **Apply**.

PERMITTED SERVICES

Allowed Source IP Address

(IPv4/IPv6) ⓘ

Services

Allowed Source IP Address	Services	
insert IP address	<div> <div>×</div> collectd <div>×</div> RH-Satellite-6-capsule <div>×</div> amqp <div>×</div> apcupsd </div>	<div>+</div> <div>×</div>
0.0.0.0/0	<div> <div>×</div> RH-Satellite-6-capsule <div>×</div> amqp <div>×</div> apcupsd </div>	<div>+</div> <div>×</div>

⊕ Add a new rule

Cancel

Apply

FIREWALL POLICIES

Firewall egress filtering may be used to allow or deny traffic leaving a device. This feature allows you to create firewall egress rules, which govern outgoing traffic leaving the device.

Firewall egress filtering extends the firewall/policies endpoint, allowing customization over both incoming (ingress) and outgoing (egress) traffic, thus allowing greater control of the device's security.

The feature allows you to:

- Change the default behavior of a firewall policy so it can accept or deny traffic moving between zones.
- Create, edit and delete firewall policy rules which allow or block specific service traffic based on IP addresses.
- Configure firewall policy rules through ogcli, Config Shell or the WebUI.
- Display and inspect rules in a single location in the WebUI.

- Create symbolic zones HOST and ANY which allow the creation of catch-all firewall policies affecting traffic incoming and outgoing all zones.

CREATING EGRESS POLICIES IN THE WEBUI

New policies or edits of existing policies are done from the Firewall Policies page. Navigate to **Configure > Firewall > Policies**, there is now an overview for firewall policies created on the device, as well as an overview page showing firewall policy rules created. To view firewall policy rules, click the drop-down arrow to the right of any policy row.

FIREWALL POLICIES

POLICIES
RULE OVERVIEW

Add Policy

+

Incoming

Priority
-1

Ingress
ANY

Egress
HOST

Default Action
ACCEPT

^

Edit

This is the policy governing incoming traffic

SERVICES	SOURCE ADDRESS	DESTINATION ADDRESS	LOG PREFIX	ACTION	RULE PRIORITY
http	0.0.0.0/0			REJECT	0
radius	0.0.0.0/0			DROP	0

Outgoing

Priority
-1

Ingress
HOST

Egress
ANY

Default Action
ACCEPT

^

Edit

This is the policy governing outgoing traffic

SERVICES	SOURCE ADDRESS	DESTINATION ADDRESS	LOG PREFIX	ACTION	RULE PRIORITY
No rules have been configured					

EGRESS POLICY DETAILS

New policies are created by first clicking on the **Add Policy** button at the top-right of the **Firewall Policies** page of the WebUI. New policies can have a user-defined default action, either ACCEPT, CONTINUE, DROP, or REJECT, which describes how traffic moving through the ingress and egress zones is treated. The ingress and egress zones may be configured as custom zones on the

device through the firewall/zone endpoint, or can be symbolic (ANY/HOST) which represent traffic on all interfaces and the host device itself respectively. These default actions are described in the following table.

Default Action	Outcome
ACCEPT	All packets flowing between ingress and egress zones are accepted by default.
REJECT	Rejects every packet (a message warns that the connection was rejected and that packets will not be allowed through): <code>ssh: connect to host 10.236.3.7 port 22: Connection refused</code>
DROP	Drops every packet (users do not get a message, the connection hangs).
CONTINUE	Ongoing packets are subject to rules in following policies and zones.

CREATE A NEW FIREWALL POLICY

1. Click on the **Add Policy** button at the top-right of the **Firewall Policies** page of the WebUI.
2. Complete the **Name**, **Description**, **Default Action** and **Policy Priority** inputs of the New Policy.

Note: Policy Priority - Policies with negative values are applied before any filtering rules in zones. Policies with positive values are applied after filtering rules in zones. A priority of 0 (zero) cannot be applied.

3. Select the required Ingress and or Egress zones.
4. Click on the **Add New Rule** button and complete the information; Source and Destination address, also Log Prefix are optional.
5. Click **Apply**. The new rule is instated.

EDITING POLICIES OR RULES

Rules associated with a policy can be edited. When saving their changes after editing, you are prompted to double check their changes using the **Confirm Action** window, which presents an overview of the policy changes.

CONFIRM ACTION
×

Editing Firewall Policy can interrupt your access to the device.

Are you sure you want to make the following changes:

Changes to the base policy

FIELD	EXISTING VALUE	NEW VALUE
Name	Incoming	Incoming
Description		This is the policy governing incoming traffic

Changes to rule list

RULE INDEX	FIELD	EXISTING VALUE	NEW VALUE
1	Action	accept	reject
1	Services	all-tcp-udp	http

Cancel
Confirm

Note: Editing a firewall policy or rule may interrupt access to the device.

CONFIGURE EGRESS POLICIES IN THE CONFIG SHELL

Firewall policies may be created through Config Shell as shown in the following example:

```

config: firewall/policy
config(firewall/policy): add incoming
config(firewall/policy incoming): default_action accept
config(firewall/policy incoming): egress_zones
config(firewall/policy incoming egress_zones): add host
config(firewall/policy incoming egress_zones): up
config(firewall/policy incoming): ingress_zones
config(firewall/policy incoming ingress_zones): add any
config(firewall/policy incoming ingress_zones): up
config(firewall/policy incoming): show
Entity firewall/policy item incoming
    default_action accept *
    description ""
    name incoming
    priority -1
    egress_zones (array)
        0 host *
    ingress_zones (array)
        0 any *
    rules (array)

```

Policy Configurable Fields

default_action	The default action that is applied to packets that don't match any rule.
priority	The priority of the policy dictates when it is applied compared to other policies and zones. Policies with negative priorities are applied before rules in zones; policies with positive priorities are applied after. A priority of 0 is reserved for Rules and is not used for policies. The default value is -1.

egress_zones	Traffic directed to the egress zones is subject to this policy. This was pre-existing but has been expanded to include options for ANY/HOST.
ingress_zones	Traffic originating from the ingress zones is subject to this policy. This was pre-existing but has been expanded to include options for ANY/HOST.
rules	A list of rules that specify what happens to specific packets as they pass through the firewall policy.

CREATE RULES UNDER A POLICY - CONFIG SHELL

The rules that apply to a firewall policy may be created through Config Shell; as shown in the following example:

```
config(firewall/policy incoming): rules
config(firewall/policy incoming rules): add
config(firewall/policy incoming rules 0): show
Entity firewall/policy item incoming field rules 0
    action "" (required)
    destination_address ""
    log_prefix ""
    priority 0
    source_address ""
    services (array)
```

Rule Configurable Fields

action	The action to apply to matching packets.
destination_address	The destination address to which this rule applies.

log_prefix	This sets the prefix of the info level log that is sent when this rule is hit. If it is empty, no logs are sent.
priority	The priority given to the selected rule. Rules with negative priorities are applied first. The default value is 0.
source_address	The source address to which this rule will apply. For multiple source addresses, a separate rule must be created for each address.

LOGGING AND DEBUGGING FIREWALL POLICIES

Some logging and debugging tools are provided for resolving firewall policy issues:

- List all firewall policies configured on the device: `firewall-cmd --list-all-policies`.
- Check the xml files which contain the firewall policy configuration information, under the `/etc/firewalld/policies/` directory.
- Check the journal for firewall related messages: `journalctl -xeu firewalld`



Note: `firewalld` is used to create firewall rules, `firewalld` is discussed in [Interzone Policies](#) and in "Firewall Guide" on page 215.

FIREWALL SERVICES

The Firewall Services page of the WebUI provides a list of existing, predefined Firewall services and provides a means of creating, defining and editing services.

SERVICES



<input type="checkbox"/>	NAME	LABEL	PORTS	ACTIONS
<input type="checkbox"/>	NewService	Raw TCP Access to serial port 99	1111/tcp	 

PREDEFINED FIREWALL SERVICES

NAME	LABEL	PORTS
raw_tcp_serial99	Raw TCP Access to serial port 99	4099/tcp
ssh_serial99	SSH to serial port 99	3099/tcp
telnet_serial99	Telnet to serial port 99	2099/tcp

ADDING WIREGUARD ZONES TO A FIREWALL


The WireGuard interface can be added to a firewall zone as in the following example:

```
Entity firewall/zone item zone
description "" (required)
label "" (required)
masquerade "" (required)
name zone
permit_all_traffic "" (required)
address_filters (array)
custom_rules (array)
physifs (array)
port_forwarding_rules (array)
wireguards (array)
```

SYSTEM

The **CONFIGURE > SYSTEM** menu lets you change the Operations Manager hostname, perform system upgrades, and reset the system.

Click on the **System** link at the top-right of the OM window to check current system details.




ADMINISTRATION

To set the hostname, add a contact email, or set a location for the Operations Manager:

1. Click **CONFIGURE > SYSTEM > Administration**.

The **ADMINISTRATION** page displays.



The screenshot shows the ADMINISTRATION page with a SETTINGS section. It contains three input fields: Hostname (SPT-OM2248), Contact (support@opengear.com), and Location (Unspecified (Configure under System Administration)). Each field has a description below it: 'Hostname for the system', 'Administration contact for the system', and 'Location for the system'. An Apply button is located at the bottom right.

2. Edit the settings as required:

Field	Description
Hostname	Enter a host name for the system.
Contact	Enter an administration contact email for the system.
Location	Enter a location for the system.

3. Click **Apply**.

The new settings are saved.

DATE AND TIME SETTING

It is important to set the local Date and Time in your Opengear device as soon as it is configured. Features such as Syslog and NFS logging use the system time for time-stamping log entries, while certificate generation depends on a correct Timestamp to check the validity period of the certificate.

Your Opengear device can synchronize its system time with a remote Network Time Protocol (NTP) server. NTP uses Coordinated Universal Time (UTC) for all time synchronizations so it is not affected by different time zones.

You must specify your local time zone so the system clock shows correct local time. The Date & Time section of the navigation bar provides a means to:

- Set the time zone.
- Manually set the correct time and date.
- Set the date and time by NTP Server.

TIME SETTING BY NTP

Configuring an NTP server ensures the Opengear device clock is kept accurate (when Internet connection has been established).

When defining an NTP server you can choose to supply an Authentication Key and Authentication Key Identifier or not to use Authentication. If NTP Authentication keys are in use, the NTP server must be verified using the Authentication Key and Authentication Key Index before synchronizing time with the server.

1. Navigate to the **CONFIGURE > DATE & TIME > Time Settings** page.

TIME SETTINGS

Current System Time: 03:26 Feb 10, 2025

Time Zone ?

UTC ▼

NTP

Manual

✓ Synchronized at Mon Feb 10 03:24:05 2025 UTC to 68A7D7C3 (104-167-215-195.ipv4.berrybyte.net)

REMOTE NTP SERVER LIST

NTP Server Address ?

pool.ntp.org

Authentication required

Yes

No

NTP Server Address ?

Authentication required

Yes

No

⊕ Add NTP Server

Apply NTP Settings

2. Select the Operations Manager's time zone from the **Time Zone** drop-down list.
A filter is provided to make selection easier.
3. Select the **NTP** option.
4. Enter the NTP server address and select whether Authentication is required.
5. Click on **Add NTP Server** if another NTP server is required and complete the address for the second NTP server.
6. Click **Apply NTP Settings**.

TIME SETTING MANUALLY

1. Navigate to the **CONFIGURE > DATE & TIME > Time Settings** page.

TIME SETTINGS

Current System Time: 03:23 Feb 10, 2025

Time Zone ?

UTC

NTP
Manual

CONFIGURE DATE AND TIME

Date and Time: 10/02/2025 03:20 AM

Apply Date and Time

February 2025

↑
↓

Mo	Tu	We	Th	Fr	Sa	Su	03	20	AM
27	28	29	30	31	1	2	04	21	PM
3	4	5	6	7	8	9	05	22	
10	11	12	13	14	15	16	06	23	
17	18	19	20	21	22	23	07	24	
24	25	26	27	28	1	2	08	25	
3	4	5	6	7	8	9	09	26	

Clear
Today

2. Select the Operations Manager's time zone from the **Time Zone** drop-down list.
A filter is provided to make selection easier.
3. Select the **Manual** option.
4. Under Configure Date and Time, click on the calendar icon to open the Date and Time Picker.
5. Either select the date and time manually or simply click **Today** to set the current date/time.
6. Click **Apply Date and Time**.

FACTORY RESET

You can perform a factory reset at the UI by pressing the **Factory Reset** button (CONFIGURE > SYSTEM > Factory Reset) or at the external **Erase** button, or from the CLI. All three methods are covered in this topic. During a factory reset the device is reset to the factory default.

Note: During the reset process, the software driven LEDs on the front of the device (Power, Heartbeat, Network Activity, Serial Activity, Cellular) may take several seconds to appear ON. The LEDs are as described in the LED Status table. Note that the Power LED may appear to be OFF during part of the reboot process; this is a normal stage of the reboot process.

See "[Device Status LEDs](#)" on page 26 for notes about device LED status.

RESET FROM THE WEBUI

To return the Operations Manager to its factory settings:


1. Log in to the Web UI as a user with Admin privileges.
2. Navigate to **CONFIGURE > SYSTEM > Factory Reset**.
3. Read the Factory Reset warning notice.

Warning: This will delete all configuration data from the system and reset all options to the factory defaults. Any custom data or scripts on the node are lost. Please check the box below to confirm you want to proceed.

4. If you still want to proceed with the reset, select the **Proceed with the factory reset** checkbox.
5. Click **Reset**.

Warning: This operation performs the same operation as the hard factory erase button. This resets the appliance to its factory default settings. Any modified configuration information is erased. You are prompted to log in and must enter the default administration username and administration password (Username: root Password: default). You are required to change this password during the first log in.

6. CONFIRM the message "Factory reset initiated. System will reboot in ten seconds." displays.
7. CONFIRM the appliance is undergoing a system reboot.
8. The 'Power' and 'Heartbeat' LEDs display orange briefly, then go off after approximately five seconds.
9. Wait for LEDs to indicate the device has rebooted normally (see LED Status below).
10. Log in to WebUI or CLI. Use the default password for initial login, then, change password in accordance with the local password policy.



RESET AT THE EXTERNAL ERASE BUTTON


1. Press the external physical **Erase** button on the device once.

Note: On most devices the button is at the front panel, near the LEDs. On the OM1200 the button is on the rear, near the power inlet).

2. CONFIRM all LEDs come on.
3. Press the physical **Erase** button on the device a second time within five seconds.

Note: If the **ERASE** button is not depressed within five seconds of the LEDs turning on, the appliance resumes normal operation.

4. The 'Power' and 'Heartbeat' LEDs display orange briefly, then go off after approximately five seconds.
5. Wait for LEDs to indicate the device has rebooted normally (intermittently flashing heartbeat changes to green, see LED Status below).
6. Log in to WebUI or CLI. Use the default password for initial login, then, change password in accordance with the local password policy.



RESET FROM THE CLI TERMINAL

1. Log in at the CLI terminal, then enter:

```
root@om2248-l-tp1-p14:~# factory_reset
```

2. Confirm: Factory reset system? [yes/no]:
3. Follow the procedure from step 2 in the 'Erase button' procedure above.

REBOOT

To reboot the Operations Manager:

1. Navigate to **CONFIGURE > SYSTEM > Reboot**.
2. Select **Proceed with the reboot**,
3. Click **Reboot**.

REBOOT

WARNING

Please check the box below to confirm you wish to proceed. The appliance will reboot and will be unreachable for several minutes.

☒ Proceed with the reboot

Reboot

For detailed information about device behavior that may occur during a factory reset procedure, see ["Factory Reset" on page 240](#).

EXPORT/RESTORE CONFIGURATION

EXPORT CONFIGURATION


The current system configuration can be downloaded as a plain text file. It contains all configuration performed via the WebUI and the ogcli tool. It does not contain log files, user scripts, docker containers, service configuration or other files stored via other means.

The exported configuration may be useful for:

- Disaster recovery.
 - issues with system upgrades.
 - unexpected configuration changes.
- Replacing devices after RMA.
- Configuration templating.

EXPORT CONFIGURATION VIA WEBUI

CONFIGURE > SYSTEM > Export / Restore Configuration



To export the system configuration, click the **Download** button and save this file. Sensitive data such as passwords and tokens are obfuscated in the configuration export.

Note: The default filename includes the system hostname and a timestamp. For example, `om2248_20210910_config.txt` `em8000_20210910_config.txt`

EXPORT CONFIGURATION VIA OGCLI

The system configuration can also be exported using the ogcli tool.

As an administrative user, run the following command:

```
ogcli export <file_path>
```

CONTROL THE EXPORT OF SENSITIVE DATA

The display of sensitive data during export via ogcli can be controlled by modifying the ogcli command:

- To display secrets in cleartext, run:

```
ogcli --secrets=cleartext export <file_path>
```

- To display obfuscated secrets, run:

```
ogcli --secrets=obfuscate export <file_path>
```

- To display secrets masked with *********, run:

```
ogcli --secrets=mask export <file_path>
```

Caution: Configuration exported with **--secrets=mask** cannot be used to import configuration.

RESTORE CONFIGURATION

An exported system configuration can be imported to the node using the WebUI or ogcli tool.

Note:

- If the configuration was exported using **--secrets=mask**, it cannot be used for configuration import.
- It may take up to ten minutes to import a config file with a large amount of configuration.

RESTORE CONFIGURATION VIA WEBUI

Importing configuration using the WebUI will use the restore strategy. Restoring configuration will override all settings on the node.

Only configuration from the same version and model can be restored.

To restore the system configuration:

1. Click the **Restore** tab

EXPORT / RESTORE CONFIGURATION

EXPORT
RESTORE

RESTORE CONFIGURATION

Configuration Backup File ?

↑

Drag your file here, or select a file

Config file only

2. Select the configuration file to import.
3. Review the configuration by clicking the arrow to display the file content.

RESTORE CONFIGURATION

Configuration Backup File ?

REVIEW UPLOAD

om2248_20210910_config.txt

▼

Cancel
Upload File

4. Click the **Upload File** button to start the import process.
A green banner displays when the configuration import is successful.

IMPORT CONFIGURATION VIA OGCLI

The system configuration can also be imported using the ogcli tool. Either the import or restore strategies can be used.

IMPORT CONFIGURATION

Configuration that is imported using the `ogcli import` command is merged with the current system configuration, preserving the current values, and adding missing entries from the exported configuration where required.

As an administrative user, run the following command:

```
ogcli import <file_path>
```

RESTORE CONFIGURATION

Configuration that is imported using the `ogcli restore` command will replace the current system configuration. The resulting system configuration will reflect what is in the exported configuration.

Note: Restoring a configuration file may take up to three minutes for large files.

As an administrative user, run the following command:

```
ogcli restore <file_path>
```

AUTOMATED ROLLBACK TO WORKING CONFIGURATION

'Config Rollback' provides an automated rollback mechanism that ensures a device will automatically revert to its last known working configuration in case of a failed restore. Automated Rollback is the default configuration of this feature and cannot be overridden or configured for manual operation.

Rollback maintains operational stability, ensuring the system does not become partially upgraded due to some error during upgrade. The ability to roll back to a previously safe configuration minimizes downtime and service disruption, making it a vital addition to the system's resilience.

Rollback behavior in the event of a detected restore failure:

The system automatically detects a configuration update failure. On detection of a failure, the system automatically initiates a rollback to the last known working configuration without user intervention until a known working configuration is successfully installed.

```
root@om2248:~# ogcli restore restore.txt
:   restoring data

restore failed with the following error(s):
Error(s) detected during REPLACE operation on services/snmp_alert_managers
Adding record 1 from the list of supplied records has failed
Error: 'bad_address' is not a valid network address
Error: Push command failed

:   rolling back config
rollback successful
```

UPDATING THE IMPORT/RESTORE FILE

The import/restore file must follow a very specific format; deviation from format should be avoided. Comments and blank lines are allowed but any commands not starting with either ogcli or config must be in proper heredoc format, see the following example (note the <<'END' format, this is the only heredoc marker allowed).

Note: Inline comments will not work.

```
config replace system/session_timeout <<'END'

cli_timeout=0

serial_port_timeout=0

webui_timeout=20

END
```


ROLLBACK CAPABILITIES

- When the system initiates a rollback, it logs to syslog, prints a message in the CLI, and displays a pop up “toast” notification in the WebUI.
- This system is resilient to network issues; when Rollback is started it continues without the user being connected to the network.
- If a user sends a ctrl-c signal during restore/import the system also begins a rollback.
- If a user sends a ctrl-c signal during the rollback it is ignored. This is to ensure that the system does not enter a bad state.
- Users cannot start another restore/rollback if there is already one running on the system, a warning is issued.

ROLLBACK LIMITATIONS

- Config diff and Rollback can be used by any user with Administrator permission and access to the shell. It is initiated via the WebUI or command line.
- Only one import/restore and rollback is permitted on the box at any time.
- Rollback cannot be initiated without a failing import/restore.
- Rollback cannot be initiated to a specific version.
- Rollback does not support manual intervention and when rollback is initiated it cannot be stopped.
- Rollback cannot be initiated after import/restore is complete.

LIGHTHOUSE NODE BACKUP

Configuration export can be scheduled to be performed periodically using the Lighthouse Node Backup feature.

For more details, consult the Lighthouse User Guide:

<https://opengear.com/support/documentation/>

SYSTEM UPGRADE

You can perform a system upgrade when new firmware is released. After specifying the location of the firmware and beginning the upgrade process, the system is unavailable for several minutes and then reboots. Unlike a factory reset, users, and other configuration data is maintained after the upgrade.

SYSTEM UPGRADE

SYSTEM UPGRADE

During the upgrade, the appliance will reboot and will be unreachable for several minutes.
System images must have the extension *.raucb*.

Upgrade Method

Fetch image from HTTP/HTTPS Server

Fetch image from HTTP/HTTPS Server

Upload image

ADVANCED OPTIONS

Upgrade Options

Only use at the request of Support

Perform Upgrade

PERFORM A SYSTEM UPGRADE

1. Navigate to the **CONFIGURE > System > System Upgrade** page.
2. Select the **Upgrade Method**, either **Fetch image from HTTP/HTTPS Server** or **Upload Image**.

Note: See <https://opengear.com/support/device-updates/> for firmware updates.

UPGRADE VIA FETCH FROM SERVER

If upgrading via **Fetch image from HTTP/HTTPS Server**:

1. Enter the URL for the system image in the **Image URL** text-entry field.
2. Click **Perform Upgrade**.

UPGRADE VIA UPLOAD

If upgrading via **Upload Image**:

1. Click the **Choose file** button.
2. Navigate to the directory containing the file.
3. Select the file and press **Return**.
4. Click **Perform Upgrade**.

Note: The **Advanced Options** section should only be used if a system upgrade is being performed as part of an Opengear Support call.

When the upgrade has started, the **System Upgrade** page displays feedback as to the state of the process.

ADVANCED OPTIONS

The Operations Manager supports a number of command line interface (CLI) options and REST API.

address : Primary Lighthouse address to enroll with

api_port : Optional port to use for the primary address when requesting enrollment

password : LH global or bundle enrollment password

bundle : Name of LH enrollment bundle

COMMUNICATING WITH THE CELLULAR OR POTS MODEM

Interfacing with the cellular modem is only available via CLI.

Usage	
mmcli [OPTION?]	Control and monitor the ModemManager.

Option	Description
-h, --help	Show help options
--help-all	Show all help options
--help-manager	Show manager options
--help-common	Show common options
--help-modem	Show modem options

Option	Description
<code>--help-3gpp</code>	Show 3GPP related options
<code>--help-cdma</code>	Show CDMA related options
<code>--help-simple</code>	Show Simple options
<code>--help-location</code>	Show Location options
<code>--help-messaging</code>	Show Messaging options
<code>--help-voice</code>	Show Voice options
<code>--help-time</code>	Show Time options
<code>--help-firmware</code>	Show Firmware options
<code>--help-signal</code>	Show Signal options
<code>--help-oma</code>	Show OMA options
<code>--help-sim</code>	Show SIM options
<code>--help-bearer</code>	Show bearer options
<code>--help-sms</code>	Show SMS options
<code>--help-call</code>	Show call options

Application Options	Description
<code>-v, --verbose</code>	Run action with verbose logs
<code>-V, --version</code>	Print version
<code>-a, --async</code>	Use asynchronous methods
<code>--timeout=[SECONDS]</code>	Timeout for the operation

2 (UTRAN)	3G
7 (E-UTRAN)	4G
	5G SA
13 (E-UTRA-NR dual connectivity)	5G NSA

INTERNAL MODEM (POTS)

The OM2200-10G-M-DDC-L is fitted with an internal POTS modem. The POTS modem can be used to obtain CLI access to the OM, which allows users to dial into a device and obtain a command prompt by using the modem. The modem is configured at the **WebUI**, **Config Shell** or **CLI**. Configuration is discussed later in this topic.

The modem is connected via the RJ15 cable at the RJ15 port at the rear, when connecting the cable you will hear or feel a click when it is correctly inserted.

The POTS modem supports the following modes:

- **Dial-In Only** - In this mode the device will not dial-out to other modems.
- **Management Console Only** - On successful connection, only a console (login prompt and shell access) is active. The modem is not a network interface, it will not carry IP traffic.

CONFIGURING THE POTS MODEM (OM2200-10G-M-L)

POTS modem entities are detected and added to the config when the device is booted and therefore cannot be added or deleted later.

The internal POTS modem has the following configurable options:

Configuration	Modem Behavior
dialin mode enabled or disabled	The modem will listen for connections and automatically answer, providing a serial console to the requester.
Baud rate	The baud rate to use between the modem and the internal serial port.
Custom AT Command Sequence	This is a single-line, multi-command string to use to initialize the modem with specific behavior.

CONFIGURATION VIA THE WEBUI

Configure > Network Connections > Network Interfaces

POTS Modem configuration listed at the above table are accessible from the **Network Interfaces** page. The configuration options appear below the other network interfaces in the list, the modem can be enabled in “dialin” mode or disabled. Clicking the **Edit** link navigates to the modem detail page if further configuration is required.



Internal Dial-up Modem

Dial-in

Enabled

Disabled

Edit

POTS CONFIGURATION VIA THE CONFIG SHELL

The 'pots_modems' entity can be modified by Config Shell. POTS modem entities cannot be added or deleted after the boot sequence because they are detected and added to the config when the device is booted.

CONFIG SHELL COMMAND EXAMPLES

The fields listed in the configurable options table can be configured via the Config Shell:

Required Action	Command Example
Show the POTS modem configuration	<code>show pots_modem modem01</code>
Enable the POTS modem	<code>edit pots_modem modem01 mode dialin</code>
Disable the POTS modem	<code>edit pots_modem modem01 mode disabled</code>
Set the modem baud rate	<code>edit pots_modem modem01 baud 38400</code>
Set an AT command sequence	<code>edit pots_modem modem01 command_sequence 'AT+CGI-I=09'</code>
Clear the AT command sequence	<code>edit pots_modem modem01 command_sequence ''</code>

Note: Supported POTS modem baud rates are 2400, 4800, 9600, 19200, or 38400.

CUSTOM AT COMMAND SEQUENCE

The command sequence is a single-line, multi-command string to use to initialize the modem with specific behavior. It looks like a standard AT command, for example: `AT+MSv32`.

- The initial AT can be entered or omitted.
- Multiple commands can be entered separated by semicolons ';' eg. `AT+MSv32;&v`
- There is no requirement to add the prefix AT for subsequent commands after the semicolon.
- Some commands expect a value to be entered and require an = to be present eg. `AT+GCI=09`
- Spaces are not allowed in the command sequence.

Example Custom AT Commands

Intended Action	Command Example
Change the speed of the modem to v92 or v32.	<code>AT+MSv92</code> <code>AT+MSv32</code>
Set the country code to AU	<code>AT+GCI=09</code>

POTS CONFIGURATION VIA THE CLI

CLI access to the (OM2200-10G-M-L) can be obtained using a POTS (aka dialup modem) connection. Connection requires a terminal program that can interact with a dialup modem and support VT102 terminal emulation. On Linux, 'tip' is commonly used. On windows, PuTTY is available.

When a dialup connection with the (OM2200-10G-M-L) is established, a login prompt presented and you can proceed exactly as if connected to the management console using a direct connection.

Note: If the modem session is ended, the console session will also end. Users are required to login again after starting a new modem call.

LOGGING

- At modem start-up, the following log is printed to syslog:

```
Jul 26 02:37:22 (OM2200-10G-M-L) systemd[1]: Started Serial Getty on
modem01.
```

- Mgetty logs are redirected to rsyslog, which include the logging of what is received and sent from the pots modem.

No other modem logs are output.

CONFIG CLI GUIDE

The Config Command Line Interface(CLI) provides users with an interactive and familiar environment similar to other networking devices that users may be familiar with. The result is a user-experience that feels like an Interactive CLI .

Advantages of the Config CLI are:

- Interactive CLI makes everyday operations such as configuration changes and troubleshooting activities easier for users.
- Items can be created or updated without being applied immediately.
- Items that are not applied are indicated by an asterisk (*) beside them when viewing information..
- Tab complete is supported for many commands.
- Built-in context sensitive help.
- Has a structured, tabular view when displaying lists of data.

NAVIGATION IN CONFIG CLI

STARTING A SESSION IN CONFIG CLI

Start the Config Shell by typing `config` at a bash prompt. The bash prompt is presented to root and Administrator users when they log in via SSH or on the management or local console.

EXITING A CONFIG CLI SESSION

You can exit the Interactive CLI by in any of the following ways:

- Type `exit` to end the session.
- Send an EOF (Control+D).
- Send an INT (Control+C).

Note: The session is prevented from exiting if there are un-committed changes, this condition is indicated by a message. However, you can force an exit by immediately executing an exit command again, any un-committed changes are discarded.

NAVIGATING THE CONFIG CLI

The Config CLI operates using a hierarchy . Due to the variety of endpoints, there are several ways to get to a place where you may want to make changes.

- Starting at the root, enter endpoint names to descend down to lower endpoints.
- Similarly, type 'up' to ascend towards the root or type 'top' to reset to the root context.

Note: Every endpoint name is an operation that descends into that endpoint.

When using the config CLI, it is possible to navigate 'downwards' through multiple contexts with a single command line.

HIERARCHICAL IDENTIFIERS

This section outlines the identifiers required to navigate the CLI.

Identifier	Description
Singleton endpoints	These require only the endpoint name to be uniquely identified.
List/Item endpoints	The first level is the endpoint name, the second level is the item identifier (the identifier is the same identifier used by ogcli).
Multiple identifiers	A single endpoint (ssh/authorized_keys) requires an extra identifier. In this case, the hierarchy is: ssh/authorized_keys > userid > [key_id]
Nested fields	The interactive CLI treats nested fields as additional hierarchy levels. This applies both to arrays and maps. For arrays of complex values, each value shall also be a hierarchy level.

UNDERSTANDING FIELDS, ENTITIES AND CONTEXTS

The Config CLI allows you to configure the device settings through a number of required fields, which provide the settings for the device.

These fields are grouped in *entities* that describe a small set of functionality, for example, there is a 'user' entity which is used to access user settings. Entities can contain sub-entities as well as simple fields.

HOW CONTEXT OPERATES IN THE CONFIG CLI

Description

The *context* is the current entity that is the focus of the Config Shell. When the shell is first started, the context is a special parent context from which sub-entities can be seen. Within the Config Shell, a number of commands are available, depending on the current context.

When Config Shell is started the context is at the “top context” which lists all the entities when the `show` command is used. If the name of an entity is typed, then the context moves 'down' into that entity. When simple commands such as `show`, `help` or `apply` are used, they will act on the current context. The context can be moved down further by typing the name of an item.

Entities can contain sub-entities as well as simple fields. For example, there is a ‘user’ entity which is used to access user settings. Fields are grouped within entities that describe a small set of functionality.

Navigating Using Context

You select a context by typing the name of the target entity and pressing Enter/Return; the new context is shown in the prompt between brackets. In the following example, the ‘user’ context is accessed and then the ‘john’ sub-entity is accessed causing the context to become ‘user john’.

The ‘show’ command is used to list the entities and fields that descend from the current context.

```
config: user
config(user): show
Item names for entity user
  john matt myuser netgrp root
config(user): john
config(user john):
Entity user item john
  description
  enabled true
  no_password    false
  password
  ssh_password_enabled true
  groups (array)
config(user john):
```

The following example will navigate the context to the root user object without first having to navigate to the user context:

```
config: user root
config(user root):
```

Sub-objects are supported. In the following example, `power_supply_voltage_alert` and `syslog` are nested sub-objects of the `monitoring/alerts/power` entity:

```
config: monitoring/alerts/power power_supply_voltage_alert syslog
config(monitoring/alerts/power power_supply_voltage_alert syslog):
```

GLOBAL & ENTITY-CONTEXT COMMANDS

GLOBAL CONTEXT COMMANDS

The following table lists commands available on any context:

Global Command	Description
<code>help</code> (or <code>'?'</code>)	Show help which is context sensitive. It will list some special details about the current context, the list of sub entities (or fields) and a list of available commands.
<code>help <entity></code>	Displays short-form help for the specific entity.
<code>show</code>	Lists the available entities and fields.
<code><entity></code>	Inputting the name of an entity changes the context to focus on the named entity.
<code>exit</code>	Exit the command shell.

ENTITY CONTEXT COMMANDS

In addition to the global context commands, when an entity context is selected then further, entity context, commands become available.

Entity Command	Description
<code><field></code>	Show the value of a field.
<code>help <entity></code>	Displays short-form help for the specific entity.
<code><field> <value></code>	Set the value of a field.
<code>delete</code>	Deletes the current entity. This is available when the context entity is an item in a list.
<code>add</code>	Append a sub-entity or field to the current entity. This is only available when the context entity is a list.

CONFIG CLI ENTITIES

The Config Shell allows the user to configure a number of fields which are the settings for the device. These fields are grouped in entities that describe a small set of functionality. For example, there is a ‘user’ entity which is used to access user settings. Entities can contain sub-entities as well as simple fields.

When in the shell, a number of commands are available depending on the current context. The context is the current entity that is the focus of the Config Shell. When the shell is first started, the context is a special parent context from which sub-entities can be seen.

When a context is selected by typing the name of the entity, it is shown in the prompt between brackets. e.g. In the following snippet, the ‘user’ context is accessed and then the ‘john’ sub-entity is accessed causing the context to become ‘user john’. The ‘show’ command is used to list the entities and fields that descend from the current context.

SUPPORTED ENTITIES

Entity	Definition
access_right	An access right is a permit that grants the holder access to a feature or collection of related features.
auth	Configure remote authentication, authorization, accounting (AAA) servers.
auto_response/beacon	Read and manipulate the Auto-Response beacons on the NetOps Console Server appliance.
auto_response/reaction	Read and manipulate the Auto-Response reactions on the NetOps Console Server appliance.
auto_response/status	Read the AutoResponse Status on the NetOps Console Server appliance.
auto_response/status/beacon-module	Read the AutoResponse Status of Beacon Modules on the NetOps Console Server appliance.
cellfw/info	Retrieve cellular modem version and related information.
cellmodem	Retrieve information about the cell modem.
cellmodem/sim	Cell modem SIM status.
conn	Read and manipulate the network connections on the NetOps Console Server appliance.

diff	config diff performs a comparison of the active configuration and an input configuration file, which is the product of the ogcli export <template-file> operation. Config diff shows additions, removals and changes clearly in the a streamlined format with only functional differences between the input and running configurations. See also ogcli diff.
failover/settings	failover/settings endpoint is to check and update failover settings. When failover is enabled, this device will consume from 1MB to 1.6 MB of bandwidth per day on the probe_physif connection. If the probe addresses are unreachable, this device will take from 108 to 156 seconds to enter the failover state.
failover/status	failover/status endpoint is to check current failover status.
firewall/policy	A collection of policies defined for the NetOps Console Server appliance's firewall. A policy specifies which zones traffic is allowed to route between.
firewall/predefined_service	A collection of predefined services for the NetOps Console Server appliance's firewall. A service is a named grouping of one or more TCP or UDP ports for a particular networking protocol. For example, the 'https' service refers to TCP port 443. This collection contains predefined services for common protocols and doesn't include the services added by the Administrator.
firewall/service	A collection of custom services defined for the NetOps Console Server appliance's firewall. A service is a named grouping of one or more TCP or UDP ports for a particular networking protocol. For example, the 'https' service refers to TCP port 443. The appliance includes many predefined services for common protocols (see /firewall/predefined_services). This collection contains only custom services which have been defined by the Administrator.
firewall/zone	Collection of zones defined for the NetOps Console Server appliance's firewall. A zone includes 1 or more interfaces.
group	Retrieve or update user group information.
ip_passthrough	IP Passthrough endpoints are for retrieving / changing IP Passthrough settings.

ip_passthrough/status	The IP Passthrough status endpoint provides information about what part of the IP Passthrough connection process the device is currently at and information about the connected downstream device.
ipsec_tunnel	Read and manipulate the IPsec tunnels on the NetOps Console Server appliance.
lighthouse_enrollment	View and control enrollment to a lighthouse.
local_password_policy	Configure the password policy for local users. This includes expiry and complexity settings.
logs/portlog	None
logs/portlog_settings	Check and update port log settings.
managementport	Used for working with local management console information.
monitor/brute_force_protection/ban	Used for monitoring addresses banned by Brute Force Protection.
monitor/lldp/chassis	Get the current status of the network discovery (LLDP/CDP) protocols on this device.
monitor/lldp/neighbor	Get the list of neighboring devices (peers) that have been discovered by the LLDP protocol.
monitor/static_routes/status	Used for monitoring the status of static routes. Only IPv4 static routes are supported.
monitoring/alerts/networking	Retrieve and configure Networking Alert Group settings.

monitoring/alerts/power	Retrieve and configure Power Alert Group settings.
monitoring/alerts/system	Retrieve and configure System Alert Group settings.
pdu	Configure, monitor and control PDUs connected to the device.
pdus/drivers	Read the PDU driver list.
physif	Read and manipulate the network physical interfaces on the NetOps Console Server appliance.
port	Configuring and viewing ports information.
port_session	None.
ports/ auto_discover/schedule	Manage Port Auto-Discovery Scheduling.
ports/status_port	Provides information about the serial pin status and Tx & Rx counters for each of this device's serial ports.
system/admin_info	Retrieve or change the appliance system's information (hostname, contact and location).
services/ brute_force_protection	Provides access to the Brute Force Protection configuration on the system. When this service is enabled, the system watches for multiple failed login attempts and temporarily bans the offending IP Address for the configured amount of time.
services/lldp	Provides access to the Network Discovery Protocols (LLDP/CDP) configuration.
services/ntp	Provides access to the NTP client configuration on the system.

services/routing	Retrieve and configure routing services on the NetOps Console Server appliance.
services/ snmp_alert_manager	SNMP Alert Managers are used to receive and log SNMP TRAP and INFORM messages sent by the NetOps Console Server. To receive SNMP alerts generated by the system at least one SNMP Alert Manager must be configured.
services/snmpd	Simple Network Management Protocol (SNMP) is an Internet Standard protocol for collecting and organizing information about managed devices on IP networks and for modifying that information to change device behaviour. This entity allows configuration of the SNMP service.
services/ssh	Configure the Secure Shell Protocol (SSH) service.
services/syslog_server	Provides access to the remote syslog server configuration.
services/tftp	Trivial File Transfer Protocol (TFTP) is a service that allows files to be transferred to or from the NetOps Console Server appliance. This entity provides access to the TFTP server configuration on the system.
single_session	Can be enabled on a given port to prevent multiple users from connecting to that port or limit the port to a single concurrent connection.
ssh/authorized_key	Configure the SSH authorized keys for a specific user.
static_route	Configuring and viewing static routes.
system/admin_info	Retrieve or change the NetOps Console Server appliance system's information (hostname, contact and location).
system/banner	Retrieve or change the appliance system's banner text.
system/cell_reliability_test	None.

system/cellular_logging	Cellular logging provides the ability to capture the RRC connection messages from the EM7565 cellular module. This entity allows configuration of cellular logging and is only to be used during compliance testing.
system/cloud_connect	Retrieve or change the appliance system's cloud connect configuration.
system/diskspace	Retrieve the system's Disk Space usage.
system/info	Retrieve basic system information.
system/model_name	Retrieve the appliance's Model Name.
system/serial_number	Retrieve the appliance's Serial Number.
system/session_timeout	Retrieve or change the appliance session timeouts.
system/ssh_port	The SSH port used in Direct SSH links.
system/ system_authorized_key	Configure the SSH authorized keys for all users.
system/time	Retrieve and update the NetOps Console Server's time.
system/timezone	Retrieve and update the system's timezone.
system/version	Retrieve the appliance's most recent firmware and REST API version.
user	Retrieve and update user information.

CONFIG CLI COMMANDS

Command	Definition
add	Add a new item for an entity.
apply	Apply changes on just the current entity.
changes	View a list of config areas with unapplied changes.
delete	Delete an item for an entity.
diff	Show additions, removals, changes and functional differences between the input and running configurations. See also <code>ogcli diff</code> .
discard	Discard changes on just the current entity.
edit	Making changes to configuration options without navigating through the hierarchy.
exit	Leave config mode without applying changes.
help / ?	Display the available options for the configuration section. Can be used in combination with a command or configuration option to access help documentation.
import/export	Copy a config file from a specific network location to the console server and run the file. The import/export commands operate in bash, ie. outside of config CLI. You must exit config to operate the import/export features.
show	Display information relevant to the configuration section, highlighting changes.
up/exit/ ..	Allows users to traverse the configuration hierarchy.

ADD

Description

The `add` command will add a new item for an entity. The `add` command requires a unique value to identify the record. This is used for the entity's label field.

The **add** command can be used:

- Anywhere within the command structure to begin the process of progressively adding an element.
- As part of a single line command where an element is added and simple fields are set.

Parameters

`entity` - the entity to which the new item is added.

`label` - a unique value to identify the record.

`field` - optional field to set for the item.

`value` - optional value corresponding to the field.

Syntax

```
add <entity> <optional-entity> <label> <optional-field> <optional-value>
```

Example

```
add user aconsoleuser description "I am a console user"
```

APPLY

Description

The `apply` command allows users to stage configuration changes by allowing proposed changes to be held in memory, separate from active configuration until they are applied.

This may be considered from a user perspective like this:

"When I am adding users and realize that groups are missing, I can take a pause and add the groups without having to discard my work so far."

or

"When I am in the process of creating a new firewall zone but there is required service missing, I can go off and add the service and come back without losing changes."

Users can choose to apply changes in the following manner:

- Isolated changes that are specific to sections of configuration.
- Across all configurations.

Parameters

When no parameters are provided, the command applies the changes in the current item context. For example, if the current context is `user consoleuser`, any changes to the `consoleuser` are saved. If the `apply` command is used outside of an item context, this results in an error.

`apply all` - When the 'all' parameter is added, the command applies all changes to all items that have been changed in this session.

Syntax

```
apply [all]
```

Examples

Apply changes to a single item

These commands change a user. Then the `apply` command is used while still in the "user myuser" item context so only changes to this user are applied:

```
config: user myuser
config(user myuser): password secret123 description "This is my user"
config(user myuser): apply
```


APPLY ALL CHANGES

These commands add a new group and then change a port setting. At the end, the apply all command saves both the group and port items.

```
config: add group mygroup
config: group mygroup
config(group mygroup): access_rights
config(group mygroup access_rights): add pmsHELL
config(group mygroup access_rights): up
config(group mygroup): ports
config(group mygroup ports): add port01
config(group mygroup ports): top
config: port port01
config(port port01): label "Port for my group"
config(port port01): top
config: apply all
```

APPLY CHANGES TO SPECIFIC SECTIONS OF CONFIGURATION

From within a specific section of hierarchy. For example:

```
config users johnsmith
apply
```

This will apply any changes made specifically within the user's configuration section.

Apply changes from a different section in the hierarchy:

For example, if changes have been made in

```
config users johnsmith
```

but the user has moved elsewhere in the hierarchy, the command:

```
apply users johnsmith
```

will apply any changes made specifically within the user's configuration section.

Alternatively, a user might choose to apply all changes in the user list using the following command:

```
apply users
```

Using `apply` across all configurations

```
apply
```

```
apply all
```

CHANGES

Description

The `changes` command allows users to view a list of config areas with unapplied changes.

This displays as a list, ordered alphabetically. Users should be able to copy and paste items from the list and use it in conjunction with the `show` command to view details.

Parameters

none

Syntax

`changes`

Examples

The following example shows changes made to multiple users and a port:

```
config: edit user root description "New description"
config: add user newuser description "New User"
config: edit port port01 baudrate 115200
config: changes
Entity user item root (edit)
  description New description
Entity user item newuser (add)
  description New User
Entity port item port01 (edit)
  baudrate 115200
```

DELETE

Description

The `delete` command is used to delete an item or entity or remove a config section or sub-section. The command requires a unique value to identify the record. This is used for the entity's label field.

Similar to the `add` command, `delete` makes the change in a temporary state and affects configuration only when applied.

The `delete` command can be used on:

- Existing configuration
- Unapplied changes

When used on unapplied changes, this behaves in the same way as the `discard` command.

Parameters

`entity` - the entity from which to delete the item.

`Item-label` - the label identifying the item to delete.

Syntax

```
delete <entity> <optional-entity> <item-label>
```

Example

```
delete user aconsoleuser
config:
```

Removing an element

From the users context:

```
delete "username"
```

Single line command

```
delete user "username"
apply
```

Either of the above examples will result in exiting the context of an item being deleted.

Refer to the `apply` command for how this behaves.

DIFF

Description

The `config diff` feature provides the ability to compare the current running configuration of a device with a previously exported configuration template generated with `ogcli export`.

The `config diff` tool functions by performing an export of the current configuration of the system, and comparing it with a previous exported file, showing only the changes in a streamlined diff output containing the functional changes only.

Note: The `config diff` tool performs the diff functionality in the same way as `ogcli diff`, and can be used interchangeably using export files in either format. See **config diff** in the ["Opengear CLI Guide" on page 323](#).

Diff tool behavior

- Diff shows additions, removals and changes clearly in the a streamlined format with only functional differences between the input and running configurations.
- If any section, list item or sub-property is out of order between the input configuration and the running configuration, it is not shown in the diff unless the values have actually changed.
- If the input configuration file is missing properties or sections of configuration, it shows the differences between running configuration and the default values for those properties.
- If any property or configuration section is missing from input configuration, and the running configuration is identical to the system defaults, it is omitted from the diff output.
- If diff function detects no differences between the current configuration and configuration template files match, a return code of 0 and no output is shown.

Syntax

```
diff <proposed_configuration_file>
```

Usage Examples

1. Active configuration matches input file:

No differences between input file and active configuration.

```
root@om2224-24e-10g:~# ogcli diff ogcli1.txt
root@om2224-24e-10g:~#
```

2. Configuration differs from template:

Differences displayed between input file and active configuration.

```
root@om2224-24e-10g:~# ogcli diff hostname.txt
ogcli --secrets=obfuscate --check-before-replace replace system/admin_info <<'END'
- hostname="hostname-a"
+ hostname="hostname-b"
END
```

3. Configuration differs from template with defaults:

Differences between active configuration and default configuration because the input file was empty.

```
root@om2224-24e-10g:~# ogcli diff empty.txt
ogcli --secrets=obfuscate --check-before-replace replace system/admin_info <<'END'
- hostname="hostname-a"
END
root@om2224-24e-10g:~#
```

4. Configuration matches template with defaults:

No differences between active configuration and default configuration with empty input file.

```
config shell exited
root@om2224-24e-10g:~# ogcli diff empty.txt
root@om2224-24e-10g:~#
```

Positional arguments

<input_file> Diff active configuration against <input_file>.

Options

-h, --help show this help message and exit.

If more detailed help is required, use `config diff --help`.

--secrets The **--secrets** flag can be used to control how sensitive fields are displayed in the diff output. By default, sensitive fields are obfuscated. If the proposed config file was exported with **--secrets=cleartext** or **--secrets=mask** then the same value must be used when running `ogcli diff`, for example, `ogcli --secrets=cleartext diff <input file>` If the input file contains a different **--secrets** parameter than that provided, an error is returned.

DISCARD

Description

The discard command is used to remove unapplied changes.

This can be used to discard specific or configuration wide changes including:

- Updates to configuration items.
- Additions not applied.
- Items designated for deletion.

Parameters

`discard` - when used on its own discard the current item when in an item context, otherwise it is an error.

`discard all` - when used with the 'all' command, then any changes staged in the current session are dropped.

Syntax

```
discard [all]
```

Examples

The following commands create a user and then discard the user (it is never saved).

Note: The context changes to exit the 'myuser' item since it no longer exists.

```
config: add user myuser
```

```
config: user myuser
```

```
config(user myuser): discard
```

Discard changes

`config(user):`

The following commands discard changes to an existing item. The item isn't removed in this case since it has been applied previously. The description field will revert back to whatever it was before.

```
config: user root
config(user root): description "Root user"
config(user root): discard
```

The following commands discard changes to multiple entities, the group and port entities. Both are reverted:

```
config: edit group admin description "New group description"
config: edit port port01 label "New label"
config: discard all
```

Discard all changes

```
discard *
```

This will result in a confirmation being displayed.

DISCARD GROUPS OF CHANGES

```
discard auth user "username"
```

- If “username” is an addition that has not been applied, it will result in the added user being discarded. In this case the user is prompted to confirm before the command is implemented.
- If “username” is an existing user with unapplied configuration changes, this results in any changes there being discarded. A confirmation is required.
- If “username” is an existing user but with no changes, the user is informed that there are no configuration changes to discard.

DISCARD SPECIFIC CHANGES

```
port port01
discard
```


- If the entity has unapplied changes it is discarded.
- If there are no unapplied changes an information message displays.

Confirmation

Discarding changes at a section, or configuration wide level gives a warning that multiple changes will be discarded.

EDIT

Description

The edit command is used when making changes to configuration options without navigating through the hierarchy.

Parameters

`entity` - the entity to be edited.

`item-label` - unique value that identifies the item.

`record field` - the field to set for the item.

`value` - the value corresponding to the field.

Syntax

`edit <entity> <optional-entity> <item-label> <field>`

`<value>`

Examples

Consider the following change to a port label:

```
config
port
port_01
label "Office-switch"
```

Alternatively, consider making the change from the root of configuration mode.

```
config
edit port port_01 label "Office-switch"
```

EXIT

Description

The `exit` command can be run at any level in the configuration structure and will allow you to leave config mode. If there are unapplied changes, you are informed and asked to confirm if you want to proceed.

Parameters

There are no parameters applicable to the exit command.

Syntax

```
exit
```

Example

```
exit
```

HELP (OR ?)

Description

Note: Config mode will accept either `help` or a question mark `?` input.

Can be used in the following ways:

- A standalone command to view available options for the configuration section.
- In combination with a command to access help documentation.
- In combination with a configuration option to access help documentation and examples.

Parameters

The `help` command shows help for the current context.

`command` - shows help for the command.

`field` - shows help for the field.

Syntax

```
help <command or field>
```

```
<command or field> ?
```

Examples

The following will print help for the “port port01” context:

```
config(port port01): help
```

or

```
config(port port01): ?
```

The following will print help for the baudrate field when in the “port port01” context:

```
config(port port01): help baudrate
```

or

```
config(port port01): baudrate ?
```

HELP COMMAND USED STANDALONE

When used by itself, `help` or `?` returns a list of available commands or configuration options.

HELP USED IN CONJUNCTION WITH A COMMAND

```
apply ?
```

When used in conjunction with a command, `help` displays available sub-options.

For example, when running the `apply` command from the root config level, the `help` command notifies you that changes will traverse the configuration structure, however, when running the `help` command from within a configuration section, changes will apply to configuration options contained within.

```
add user ?
```

Displays help content including syntax and config items (mandatory and optional).

HELP USED WITH A CONFIGURATION OPTION

In the context of this example, the user is running the command from within the port configuration section and is wanting to get information on the available options.

```
pinout ?
```

This displays a list of available options.

```
label ?
```

This displays the expected format and a sample.

IMPORT/EXPORT

Description

Note: The import / export and associated commands operate in bash, ie. outside of config CLI. You must exit config to operate the import/export features.

The Import / Export feature allows you to export the current configuration to a file and import or restore the configuration from that file. An import will add configuration to the current configuration and restore will replace the current configuration with the contents of the configuration file.

Import

Running the import command (within bash, not in config:) will allow you to import a configuration script from an external source file. You should point the console server to a config file on specific network location. The file is copied to the console server and run. Depending on how it has been set up, the changes can be automatically applied after the config file is run.

Export

Running the export command (within bash, not in config:) will allow you to generate a configuration script based on the existing configuration on the console server.

This command can be run at any level in the hierarchy and used to export either:

- The configuration across the node
- Configuration specific to the users's location in the hierarchy.

```
export all current config
```

This displays all config on the console server before it has been applied for copying.

```
export all saved config
```

This displays all saved config on the console server for copying.

```
export current config
```

This displays the config from the users's current position in the navigation hierarchy.

Parameters

Import and export are run from outside of the Config Shell. The `config` command is invoked from bash with different parameters to cause it to import or export the configuration without entering the Config Shell.

filename - The name of the file to import from or export to. If omitted then `stdin` or `stdout` is used.

Syntax

```
config export <optional filename>
```

```
config import <optional filename>
```

Examples

```
config export /tmp/console_server.config
```

```
config import /tmp/console_server.config
```

Positional arguments

{export,import,restore,merge,replace,get}

Positional Argument	Description
export	Export the current configuration.
import	Import config from a file.
restore	Restore config from a file.

merge	Merge a provided list with existing config.
replace	Replace a list or item.
get	Display an entity's associated values.
Options	
-h, --help	Show this help message and exit.
--show-config	Display the entire configuration and exit.
-d	Increase debugging (up to 3 times).
-j	Export in json format.
--entities	Display entities and exit.

Exporting to a file

Note: The import/export and associated commands operate in bash, ie. outside of config CLI. You must exit config to operate the import/export features.

SHOW

Description

The `show` command displays information relevant to the configuration section, including the highlighting of changes. The context in which the command is run determines what displays.

At `config root`, the `show` command displays system information.

Within a config section, for example from **config > auth > user**, this displays a flat list of available users.

Parameters

show	Used on its own, this displays the fields of the current context. When used in the top context, it shows the list of all entities. When used in an entity context, it shows the list of items in that entity. When used in an item context, it shows the fields and values of the current item.
entity	The entity to display, or to show details of.
item	The item to display or show details of.
field	The field to show the value of.

Syntax

show <optional entity> <optional item> <optional field>

Context

Examples using context

The following examples show how the output of the show command changes in accordance with context as it may be used at the config, physif, net1 contexts:

show - at the config context:


```
config: show
```

```
Entities
```

```
=====
```

access_right	pbus/drivers
auth	physif
auto_response/beacon	port
auto_response/reaction	port_session
auto_response/status	ports/auto_discover/schedule
auto_response/status/beacon-module	ports/status_port
cellfw/info	services/brute_force_protection
cellmodem	services/lldp
cellmodem/sim	services/ntp
conn	services/routing
failover/settings	services/snmp_alert_manager
failover/status	services/snmpd
firewall/policy	services/ssh
firewall/predefined_service	services/syslog_server
firewall/service	services/tftp
firewall/zone	ssh/authorized_key
group	static_route
ip_passthrough	system/admin_info
ip_passthrough/status	system/banner
ipsec_tunnel	system/cell_reliability_test
lighthouse_enrollment	system/cellular_logging
local_password_policy	system/cloud_connect
logs/portlog	system/diskspace
logs/portlog_settings	system/info
managementport	system/model_name
monitor/brute_force_protection/ban	system/serial_number
monitor/lldp/chassis	system/session_timeout
monitor/lldp/neighbor	system/ssh_port
monitor/static_routes/status	system/system_authorized_key
monitoring/alerts/networking	system/time
monitoring/alerts/power	system/timezone
monitoring/alerts/system	system/version
pdu	user

```
config:
```

show - at the physif context:

```
config: physif
```

```
config(physif): show
```

```
Item names for entity physif
```

```
net1
```

```
net2
```

```
config(physif):
```

show - at the net1 context:

```
config(physif): net1
config(physif net1): show
Entity physif item net1
  description NET1 - 1G Copper/SFP
  enabled      true
  mtu          1500
  dns (object)
    nameservers (array)
    search_domains (array)
  ethernet_setting (object)
    link_speed auto

config(physif net1):
```

Examples using parameters

The following examples show the output of the show command when used with different parameters:

```
config: show physif
Item names for entity physif
  net1
  net2

config: show physif net1
Entity physif item net1
  description NET1 - 1G Copper/SFP
  enabled      true
  mtu          1500
  dns (object)
    nameservers (array)
    search_domains (array)
  ethernet_setting (object)
    link_speed auto

config:
```

```
config: show physif net1 description
NET1 - 1G Copper/SFP
config:
```

Config

You can view the content of all configuration in JSON format.

You can also view the config of a specific section of the hierarchy you are in.

```
show-config
```

Directed Usage

You will also be able to look into a config sections using the show command. For example:

```
show auth user
```

This displays a flat list of users.

```
show auth user "username"
```

This displays the configuration for the user specified.

UP / EXIT / ..

Description

These commands allow users to traverse the configuration hierarchy.

```
up
```

The position will move one level up in the hierarchy.

If used at the root configuration level, it should point trigger the exit command.

Parameters

No parameters.

Syntax

```
up
```

```
exit
```

Examples

If, as in this example, the context is a specific port, then the ports entity can be accessed by using the `up` command then moving into another port:

```
config: port port01
config(port port01): up
config(port): port02
config(port port02):
```

CONFIG CLI USE CASE EXAMPLES

ADDING A USER

The following is a fully worked example showing the adding of a new user.

Note: In the following examples, some commentary has been added, the commentary is denoted with a `//` prefix. Where sessions continue onto the next page, this is shown with the comment `// session continues here:`

```
# config

Welcome to the Opengear interactive config shell. Type ? or help for help.

// Move to the user entity
```

```
config: user
```

```
config(user): help add
```

```
Add a new item for entity user.
```

The add command requires a unique value to identify the record.

This will be used for the username field.

Description for the item:

```
Retrieve and update information for a specific user.
```

```
// Create the new user
```

```
config(user): add matt
```

```
config(user matt): show
```

```
Entity user item matt
```

```
description
```

```
// Session continues here:
```

```
enabled true
```

```
no_password      false
```

```
password (required)
```

```
ssh_password_enabled true
```

```
username matt
```

```
groups (array)
```

```
// Fill out some fields
```

```
config(user matt): password topsecretpassword
```

```
config(user matt): description scrum master
```

```
config(user matt): show
```

```
Entity user item matt
```

```
description scrum master *
enabled true

password topsecretpassword *
ssh_password_enabled true
username matt
groups (array)

// Edit the groups

config(user matt): groups
config(user matt groups): show
Entity user item matt field groups
config(user matt groups): add // Tab completion to show available values
admin myuser netgrp
config(user matt groups): add admin
config(user matt groups): up // Exit the groups list
// Session continues here:
// Show and apply

config(user matt): show
Entity user item matt
description scrum master *
enabled true
password topsecretpassword *
ssh_password_enabled true
username matt
groups (array)
0 admin *
config(user matt): apply
Creating entity user item matt.
config(user matt):
```

CONFIGURING A PORT

```

config: port

config(port): help

You are here: entity port

Description for the entity:

    Configuring and viewing ports information

Names (type <name> or help <name>)

=====

USB-A USB-E USB-front-lower port03 port07 port11 port15 port19 port23
USB-B USB-F USB-front-upper port04 port08 port12 port16 port20 port24
USB-C USB-G port01          port05 port09 port13 port17 port21
USB-D USB-H port02 port06    port10 port14 port18 port22

Commands (type help <command>)

=====

exit help show up

config(port): port01

config(port port01): baudrate // tab completion

110 1200 150 19200 230400 300 4800 57600 75

115200 134 1800 200 2400 38400 50 600 9600

config(port port01): baudrate 57600

config(port port01): label Router

config(port port01): control_code

config(port port01 control_code): break a

config(port port01 control_code): up

config(port port01): show

// Session continues here:

```

```
Entity port item port01

  baudrate 57600 *

  databits      8

  escape_char   ~

  label Router  *

  logging_level disabled

  mode          consoleServer

  parity        none

  pinout        X2

  stopbits      1

  control_code  (object)

    break a *

    chooser

    pmhelp

    portlog

    power

    quit

  ip_alias (array)

config(port port01): apply
Updating entity port item port01.
config(port port01):
```

CONFIGURE A SINGLE SESSION ON A PORT

The feature is enabled by typing `single_session true`, then apply the change.

```
config(port port01): single_session true
config(port port01): apply
Updating entity port item port01.
config(port port01): show
Entity port item port01
```



```

        baudrate 9600

...

single_session true

...

ip_alias (array)

```

CREATE OR CONFIGURE A LOOPBACK INTERFACE

Loopbacks are not physical interfaces and as such cannot be attached to a firewall zone; firewall zone or policy rules must be created for whatever interface you are connecting over. Service translations can be created through the `firewall/service_translation` endpoint to change the source address of outbound packets to the loopback address.

To create a loopback, navigate to the `physifs` endpoint and set the media to `loopback`:

CREATE A LOOPBACK IN CONFIG SHELL

```

config: physif
config(physif): add loop
config(physif loop): media loopback
config(physif loop): enabled true
config(physif loop): apply
Creating entity physif item loop.

```

CREATE A LOOPBACK IN OGCLI

```

ogcli create physif << 'END'
device="loop"
enabled=true
media="loopback"
END

```

ADD AN ADDRESS TO A LOOPBACK INTERFACE

To add an address to a loopback interface, navigate to the `conns` endpoint and attach an `ipv4` or `ipv6` static address to the loopback (`dhcp` and `ipv6_automatic` are invalid for loopbacks):

ADD AN ADDRESS IN CONFIG SHELL

```
config: conn
config(conn): add new
config(conn new): mode static
config(conn new): physif loop
config(conn new): ipv4_static_settings
config(conn new ipv4_static_settings): address 10.0.0.1
config(conn new ipv4_static_settings): netmask 255.255.255.0
config(conn new ipv4_static_settings): apply
Creating entity conn item new.
```

ADD AN ADDRESS IN OGCLI

```
ogcli create conn << 'END'
mode="static"
physif="loop"
ipv4_static_settings.address="10.0.0.1"
ipv4_static_settings.netmask="255.255.255.255"
END
```

In the above example the `physif` is set to `loop`. Do not set the `broadcast_address` and `gateway_address` for loopback interfaces.

CREATE SOURCE NAT RULES

Note: When referring to service translation rules, we refer to translating the source ip of traffic to a required source ip address. To change the source address of outbound packets for a particular service, a `service_translation` rule must be added, see the following

example:

The following rule contains a list of outbound services along with the changed source address for the service packets. Navigating to the `firewall/service_translation` endpoint, you can add a new translation rule by using the `add` command. **Note:** Only services which use tcp or udp protocols are valid.

```
config(firewall/service_translation 10.0.0.1): show
Entity firewall/service_translation item 10.0.0.1
  address 10.0.0.1
  services (array)
    0 ssh
    1 https
```

If a service translation rule contains an address that does not exist on the box, a warning message is shown when creating the rule; however, it will not prevent these rules being created. See the following:

```
config(firewall/service_translation): add 10.0.0.2
WARNING: The IP entered does not exist as a known IPv4 or IPv6 address.
If this is expected, you can safely ignore this message.
```

If required, source NAT may be used for all tcp and udp traffic leaving the box by adding the service `all-tcp-udp` to the service list:

```
config(firewall/service_translation 10.0.0.1): show
Entity firewall/service_translation item 10.0.0.1
  address 10.0.0.1
  services (array)
    0 all-tcp-udp
```

Note:

- There **must** be either a static or dynamic route to the loopback address from which you are connecting to the device.
- Source NAT is not used for packets on the cell interface `wwan0`. A VPN can be set up over the cell interface if the loopback address is used over cell; dynamic routing must be configured over the VPN to share the route to the loopback address.

REST API

The `firewall/service_translation` endpoint is used to create nftables rules which configure source NATs for outgoing service traffic. This replaces the outgoing IP address of a service packet with the address given in the `service_translation`. This is done for all services within the service translation rule.

```
"service_translation" : {
  "address": "A.B.C.D"
  "services": []
}
```

The address can be ipv4 or ipv6 (no netmask required), and does not have to exist on the box (a warning is presented if the address does not exist).

The list of services is a list of strings of service names. The outbound services must already be defined on the box, either as a predefined `firewalld` service or as a custom user service.

LOGGING AND DEBUGGING

You can ping the loopback address like any other interface. You must have a static or dynamic route to the loopback in order to reach it.

- Use the command `ip a` to display logging information.
- Conman logs information about creating or deleting loopback interfaces, and connections attached to loopback interfaces, in `/var/log/message`.
- When creating loopback interfaces, the generated files should be directed to `/etc/config/conman.conf`.
- Use the command `tcpdump` on interfaces connected to the device to see source NAT traffic.
- Source NAT rules can be found under `/etc/nftables/og-service-snat/og-service-snat.conf`, or use the command `nft list ruleset` to check for rules under the service SNAT tables.

CONFIGURE NET1 STATIC IPV4

```
conn default-conn-1 ipv4_static_settings
    address 192.168.2.54
    gateway 192.168.2.1
top
```

CONFIGURE NET2 STATIC IPV4

```
add conn net2-static-1 mode static physif net2
conn net2-static-1 ipv4_static_settings
    address 192.168.3.58
    gateway 192.168.3.1
    netmask 255.255.255.0
top
```

CONFIGURE NET3 STATIC IPV4 FOR OM2224-24E UNITS

```
add conn net3-static-1 mode static physif net3
conn net3-static-1 ipv4_static_settings
    address 192.168.4.58
    gateway 192.168.4.1
    netmask 255.255.255.0
top
```

CONFIGURE WIREGUARD THROUGH CONFIG SHELL

WireGuard is configured through Config Shell (or REST API). The minimum configuration of WireGuard is shown in the following:

1. Provide a name for the interface (wg0 in the following example).
2. Set enabled.
3. Set the private_key of your WireGuard interface.
4. Add an address (at least one) for your WireGuard interface (10.0.0.1/24 in this case).
5. Add a peer with the following parameters: endpoint_address, endpoint_port, public_key.
6. Add an allowed_ip for your peer. At least one - this is the WireGuard address(es) (as it can also accept an address range) of the other interface to which you are connected.

For example:

```
config: wireguard
config(wireguard): add wg0
config(wireguard wg0): private_key AGiZvFHY+r/dD0rHSKU5ZCrHNdLM0W/h29VxobxWgFo=
config(wireguard wg0): enabled true
config(wireguard wg0): addresses
config(wireguard wg0 addresses): add 10.0.0.1/24
config(wireguard wg0 addresses): up
```

```
config(wireguard wg0): peers
config(wireguard wg0 peers): add
config(wireguard wg0 peers 0): public_key
o+quB4sbUAG2hEGSPpMNTnO0YSaQTP7dD+Q4IVjiCW8=
config(wireguard wg0 peers 0): allowed_ips
config(wireguard wg0 peers 0 allowed_ips): add 10.0.0.2/32
config(wireguard wg0 peers 0 allowed_ips): up
config(wireguard wg0 peers 0): endpoint_address 192.168.1.2
config(wireguard wg0 peers 0): endpoint_port 51820
config(wireguard wg0 peers 0): up
config(wireguard wg0 peers): top
```

ROOT USER PASSWORD - CLEARTEXT

```
edit user root password newpassword
```

ROOT USER PASSWORD = PASSWORD VIA SHA256

```
openssl passwd -5 password
```

Note: This operation is not available in Config Shell.

DEFINE PASSWORD COMPLEXITY RULES

```
edit local_password_policy
  password_complexity_enabled true
  password_expiry_interval_enabled true
edit local_password_policy
  password_disallow_username true
  password_must_contain_number true
  password_must_contain_special true
  password_must_contain_upper_case true
```

HOSTNAME

```
edit system/admin_info hostname "OM2216-1-lab"
```

CONTACT INFO

```
edit system/admin_info
  contact "fred.bloggs@opengear.com"
  hostname "om2216-1.lab"
  location "Happy Valley Lab"
```

TIME ZONE AND NTP

```
edit system/timezone timezone "America/New_York"

edit services/ntp enabled true
services/ntp servers
```



```
add
  value "74.207.242.234"
top
```

CREATE ADMIN USER

```
add user admin
  description "admin"
  enabled true
  no_password false
  password "password"
  user admin groups
  add "admin"
top
```

CREATE BREAKGLASS USER (BELONGS TO NETGRP)

```
add user breakglass
  description "breakglass" enabled true
  no_password false
  password "password"
  user breakglass groups
  add "netgrp"
top
```

ENABLE NETGRP - SET TO CONSOLEUSER

```
edit group netgrp enabled true
group netgrp ports
  add port01
add port02
  add port03
  add port04
top
group netgrp access_rights
  add web_ui
  add pmsHELL
  delete admin
top
```

CHANGE SSH DELIMITTER TO : DEFAULT IS +

```
edit services/ssh ssh_url_delimiter ":"
```

CHANGE PORT LABELS

```
edit port port01 label "cisco1"
edit port port02 label "cisco2"
edit port port03 label "cisco3"
edit port port04 label "cisco4"
```

ENABLE TACACS - SET MODE TO REMOTELocal

```
edit auth mode "tacacs"  
edit auth tacacsMethod "pap" tacacs  
Password "tac_tests"  
policy "remotelocal"  
tacacsService "raccess"  
auth tacacsAuthenticationServers  
  add  
    hostname "192.168.2.220"  
    port 49  
top
```

ENABLE LLDP ON NET1 & NET2

```
edit services/lldp enabled true  
services/lldp physifs  
  add "net1"  
  add "net2"  
top
```

ENABLE TFTP

```
edit services/tftp enabled true
```

ENABLE BOOT MESSAGES

Displays on local console port.

```
edit managementport ttyS0 kerneldebug true
```

DEFINE SESSION TIMEOUTS

```
edit system/session_timeout cli_timeout 100 serial_port_timeout 100 webui_timeout 100
```

Note: The inactivity timer starts only after you exit Config Shell, ie. it begins the count when you have left config and are at the bash command prompt.

DEFINE MOTD

Enter banner text within quotations.

```
edit system/banner banner ""
```

ENABLE SIMM 1 ENABLE AND ADD APN

```
edit physif wwan0 enabled true
physif wwan0 cellular_setting
    apn hologram
top
```

ENABLE SIMM 1 COMPLETE END POINTS

```
edit physif wwan0 enabled true
physif wwan0 cellular_setting
    active_sim 1
    apn hologram
    iptype IPv4v6
    sim_failback_disconnect_mode ping
    sim_failback_policy never
    sim_failover_disconnect_mode ping
    sim_failover_policy never
top
physif wwan0 cellular_setting sims 0
    fail_probe_address 8.8.8.8
    fail_probe_count 3
    fail_probe_interval 600
    fail_probe_threshold 1
    failback_delay 60
    iptype "IPv4v6"
    slot 1
top
physif wwan0 cellular_setting sims 1
    fail_probe_address 8.8.8.8
    fail_probe_count 3
    fail_probe_interval 600
    fail_probe_threshold 1
    failback_delay 60
    iptype IPv4v6
    slot 2
top
```

ENABLE FAILOVER

```
edit failover/settings enabled true probe_address 192.168.2.1 probe_physif net1
```

ADD A SYSLOG SERVER

```
services/syslog_server
  add server1
  address 192.168.34.113
  protocol TCP
  port 610
  description "my syslog server"
top
```

Add Five Syslog Servers

Note: Due to page width limitations, in the following example, some command lines break over two lines.

```
add services/syslog_server server0 address 192.168.34.112 min_severity notice port 514
port_logging_enabled true protocol UDP
add services/syslog_server server1 address 192.168.34.113 min_severity notice port 514
port_logging_enabled true protocol UDP
add services/syslog_server server2 address 192.168.34.114 min_severity notice port 514
port_logging_enabled true protocol UDP
add services/syslog_server server3 address 192.168.34.116 min_severity info port 514 port_
logging_enabled true protocol UDP
add services/syslog_server server4 address 192.168.128.1 description "lighthouse-remote-
syslog" min_severity info port 514 port_logging_enabled true protocol UDP
```

SET PORT LOGGING REMOTE SYSLOG SETTINGS

```
edit logs/portlog_settings facility daemon severity infoEnable system monitor snmp
traps
```

ENABLE SYSTEM MONITOR SNMP TRAPS

```
monitoring/alerts/power power_supply_voltage_alert
    millivolt_lower 11000
    millivolt_upper 13000
    snmp
        enabled true
    up
top
monitoring/alerts/networking cell_signal_strength_alert
    enabled true
    threshold_lower 33
    threshold_upper 66
top
monitoring/alerts/system
    authentication_alert
        enabled true
    up
    config_change_alert
        enabled true
    up
    temperature_alert
        enabled true
        threshold_lower 35
```

```
threshold_upper 67
up
top
```

ENABLE SNMP V2 SERVICE FOR POLLING

```
edit services/snmpd enable_legacy_versions true
enable_secure_snmp false enabled true port 161 protocol UDP
edit services/snmpd rocommunity "TkcxJAAAABBFdsigaxdDf7whb3sxKQKnjtCuuy/0COC6rE3lUu9ghg=="
```

ENABLE 2 SNMP TRAPS AND TRAP SERVERS

Note: Due to page width limitations, in the following example, some command lines break over two lines.

```
add services/snmp_alert_manager "snmp trap server 1" address 10.1.1.199 port
162 protocol UDP version v2c
services/snmp_alert_manager "snmp trap server 1"
community "TkcxJAAAABBFdsigaxdDf7whb3sxKQKnjtCuuy/0COC6rE3lUu9ghg==" msg_type TRAP
top
apply all

services/snmp_alert_manager 10.1.1.199:162/UDP
name "snmp trap server 1" privacy_password secret auth_password secret
top
apply all
```


CREATE A STATIC ROUTE

Note: Due to page width limitations, in the following example, some command lines break over two lines.

```
add static_route "static route test" destination_address 10.0.0.0 destination_netmask 8
interface net2
```

EDIT LAN (NET2) FIREWALL ZONE

(allow only source address traffic)

```
firewall/zone lan custom_rules
add
    description "source_net4-1"
    rule_content "rule family=ipv4 source address=192.168.3.0/24 accept"
up
add
    description "source_net4-2"
    rule_content "rule family=ipv4 source address=10.202.198.0/27 accept"
up
top
```

EDIT WAN (NET1) FIREWALL ZONE

(allow only source address traffic)

```
firewall/zone wan custom_rules
add
    description "source_net4-1"
    rule_content "rule family=ipv4 source address=192.168.2.0/24 accept"
```

```
up
add
    description "source_net4-2"
    rule_content "rule family=ipv4 source address=192.168.4.0/24 accept"
up
top
```

CUSTOM_RULE EXAMPLE FOR PORT AND PROTOCOL

```
add firewall/service myports label "My Serial Ports"
firewall/service myports
    add
        port 3001
        protocol tcp
    up
    apply
top
firewall/zone wan address_filters
    add
        source_address 10.10.2.0/19
        services
            add myports
    up
up
top
```

ENROLL INTO LIGHTHOUSE

```
add lighthouse_enrollment lh1 address 2.21.99.188 bundle om2216-1 token password
```

HOW CHANGES ARE APPLIED OR DISCARDED

When fields and entities are changed, the changes are not immediately applied to the system configuration but remain in a staged status. Items that are staged are indicated by an '*' (asterisk) when the 'show' command is used. In addition, the 'changes' command can be used to show what fields have been changed.

In the following example, the user 'john' has been changed to alter the description. The 'show' command indicates the changed field with an '*'. The changes command lists the changed field.

```
config(user john): description "Admin"
config(user john): show
Entity user item john
  description Admin * enabled true
  no_password false password false
  password
  ssh_password_enabled true
  groups (array)
```

APPLYING OR DISCARDING CHANGES

When fields and entities have been changed, they are not yet applied to the system configuration but are kept staged. Items that are staged are indicated with an '*' when the 'show' command is used. In addition, the 'changes' command can be used to show what fields have been changed.

When any changes have been made to a single or multiple entities, the following commands become available. These commands are described in detail in the Config CLI Commands section:

Command	Description
---------	-------------

changes	Show staged changes on all entities.
apply	Apply changes only on the current entity.
discard	Discard changes only on the current entity.
apply all	Apply changes on all entities.
discard all	Discard changes on all entities.

Example

In the following example, the user 'john' has been changed to alter the description. The 'show' command indicates the changed field with an asterisk '*'. The changes command lists the changed field.

```
config(user john): description "Scrum Master"
config(user john): show
Entity user item john
description Scrum Master *
enabled true
no_password false
password
ssh_password_enabled true
groups (array)
config(user john): changes
Entity user item john (edit)
description Scrum Master
config(user john):
```

MULTI-FIELD UPDATES

DESCRIPTION

Within Config Shell, it is possible to update multiple fields with one command line. This is restricted to 'flat' fields within the current context ie arrays and sub-objects cannot currently be updated all in one command line.

For example, the following port fields can all be changed in a single command: `baudrate`, `databits`, `escape_char`, `label`, `logging_level`, `mode`, `parity`, `pinout` and `stopbits`. Other complex fields such as `control_code` and `ip_alias` cannot be modified from the port item context in one commands (multiple commands are required).

EXAMPLE

The following command sets the `baudrate`, `escape_char` and `label` fields.

```
config(port port01): baudrate 115200 escape_char ! label "My Router"
```

The changes are staged in Config Shell. Use the `apply` command to save the changes to config.

To further update the `control_codes` and `ip_aliases`, multiple commands are required as follows:

```
config(port port01): control_code
config(port port01 control_code): break b chooser c
config(port port01 control_code): up
config(port port01): ip_alias
config(port port01 ip_alias): add
config(port port01 ip_alias 1): interface net1 ipaddress 10.83.0.6/24
config(port port01 ip_alias 1): up
config(port port01 ip_alias): up
config(port port01): changes
Entity port item port01 (edit)
```

```
control_code (object)
    break b
    chooser c
ip_alias (array)
    1 (object)
        interface net1
        ipaddress 10.83.0.6/24
config(port port01):
```

If certain fields are hidden and only visible by first configuring other fields, these hidden fields must be set in another line. For example, the `kernel_debug` field is only revealed by setting the field `mode` of a port to `localConsole`, so this is configured on the next line:

```
config: port port03
config(port port03): mode localConsole baudrate 115200 databits 7 label aaa
logging_level eventsOnly parity even
config(port port03): kernel_debug true
```

ERROR MESSAGES

If there is an error while processing a multiple-fields command, the staged values in configuration will not be changed. If there were no staged changes on the item, then no staged changes will appear. If there were already staged changes, then those staged changes will not be affected.

In the following example, the user description was previously changed to “my user”

```
config(user consoleuser): show
Entity user item consoleuser
    description my user *
    enabled true
    no_password false
    password ""
```

```
ssh_password_enabled true
groups (array)
  0 consoleuser
```

If a bad field name or value is supplied on the command line, then the existing staged value is retained. The bad field name is highlighted using a ^ marker.

```
config(user consoleuser): description "My console user" invalid true
                                                                    ^

Invalid input detected at '^' marker.
config(user consoleuser):
```

If the field is missing a value, a different error message displays:

```
config(user consoleuser): description "My console user" enabled
Incomplete command.
config(user consoleuser): show
Entity user item consoleuser
  description my user *
  enabled true
  no_password false
  password ""
  ssh_password_enabled true
  groups (array)
    0 consoleuser
```

The bad value for the field is indicated by an error message hinting the expected type of the value:

```
config(user consoleuser): description "My console user" enabled bad
Value bad for field enabled cannot be parsed as a boolean.
config(user consoleuser): show
Entity user item consoleuser
```

```
description my user *  
enabled true  
no_password false  
password ""  
ssh_password_enabled true  
groups (array)  
    0 consoleuser
```

Changes to previous functionality:

With the new `show` command, some previous syntax has changed. Just typing a field name is now an error condition. Previously this would be equivalent to the `show` command.

```
config: user root  
config(user root): description  
Incomplete command.  
config(user root):
```

ERROR MESSAGES

When an error is made in the command line an error message which identifies the error is returned. For example, if the first token of the command is mistyped, the `unknown command` message displays.

```
config: usear root  
There is no command usear root.  
Type 'help' to see the available commands.  
config:  
config: aaaaa  
There is no command aaaaa.  
Type 'help' to see the available commands.  
config:
```


If only the first few tokens of the command can be parsed, an error message with a ^ marker displays showing which part of the command cannot be parsed. If a context navigation is mistyped on the command line, then the context remains unchanged. It does not partially navigate through multiple contexts. In the following example, the context remains at the top context because `roopt` is not a valid item context in the user entity context.

```
config: user roopt
      ^
invalid input detected at '^' marker.
config:
```

STRING VALUES IN CONFIG COMMANDS

DESCRIPTION

The syntax for the use of string values has changed. It was previously possible to enter values containing spaces without using quotes. Multiple fields can now be assigned in one command line, quotes are required to keep field values together.

EXAMPLE

The following example shows setting multiple fields where the field value for the description has spaces. The first attempt doesn't work because the second part of the description is interpreted as a field name. The second attempt is the correct syntax:

Note: In the example the syntax error in the first line is highlighted in **bold** for clarity; the correct syntax is highlighted in bold in line four.

```
config(user consoleuser): description My console user enabled true
There is no command description My console user enabled true.
Type 'help' to see the available commands.
```

```
config(user consoleuser): description "My console user" enabled true
config(user consoleuser): changes
Entity user item consoleuser (edit)
    description My console user
    enabled true
config(user consoleuser):
```

If the value itself must contain quotes, there is a triple quote form for entering string values:

```
config(user consoleuser): description ""My "console" user"" enabled true
config(user consoleuser): changes
Entity user item consoleuser (edit)
    description My "console" user
    enabled true
```

The triple quoted string is used for entering multi-line strings:

```
config(system/banner): banner """
This is a banner that has
multiple lines.
"""
config(system/banner):
```

ERROR MESSAGES

If the multi-line command string cannot be tokenised, an error message displays in the following form:

```
config(system/banner): banner """
aaa
"""
```

```
Invalid input. Tokens must be separated by whitespace.  
Check your input and try again.  
config(system/banner):
```

OPENGear CLI GUIDE

The **ogcli** command line tool is used for getting and setting configuration, and for retrieving device state and information. The purpose of ogcli is perform a single operation and exit. Operations are performed on a single entity, a list of entities, or all entities. Entities in ogcli are collections of related information items that represent device state, information or configuration.

For a list of operations supported by ogcli, see the ["ogcli Operations"](#) section.

Note: ogcli is not an interactive shell, it runs a single command and exits.

GETTING STARTED WITH OGCLI

The best way to get started with ogcli is to use the help command. Refer to the following table to access help topics within ogcli.

For detailed information about ogcli and how it works, view the ogcli help topic by running this command:

```
ogcli help ogcli
```

ACCESS OGCLI HELP AND USAGE INFORMATION

Help Command	Displays...
ogcli help	Basic ogcli help and usage information.
ogcli help help	Detailed information about the help command.
ogcli help operations	The full list of operations and a brief description of each.
ogcli help entities	The full list of entities and a brief description of each.
ogcli help syntax	How to get information into and out of ogcli.
ogcli help ogcli	More detailed information about the ogcli tool.
ogcli help usage	Common ogcli usage examples.
ogcli help secrets	Detailed information about controlling the display of secrets in ogcli.
ogcli help <operation>	A description and example usage of a specific ogcli operation.
ogcli help <entity>	A description of a specific entity and the operations it supports.
ogcli help <entity> <operation>	An example of how to perform a specific operation on a specific entity.

BASIC SYNTAX

The ogcli tool is always called with an operation, with most operations also taking one or more arguments specifying an entity for the operation to act on.

```
ogcli <operation> [argument] [argument]
```

OGCLI OPERATIONS

Operation	Description
create	Create an item.
export	Export the system configuration.
diff	Show additions, removals, changes and functional differences between the input and running configurations. See also <code>config diff</code> .
get	Retrieve a list or single item.
help	Display ogcli help.
import	Import system configuration, merging with current system configuration.
merge	Merge a provided list with existing config.
replace	Replace a list or single item.

Operation	Description
restore	Import system configuration, replacing the current system configuration.
update	Update an item, supports partial edits.

SUPPLYING DATA TO OGCLI

For operations that modify an entity (e.g. 'update') the new information can be passed as inline positional arguments, but this quickly becomes cumbersome when setting a large number of fields. Information can instead be supplied through stdin by piping the contents of a file, or with Here Document (heredoc) style. The heredoc style is the most flexible format and is used extensively in ogcli examples.

HERE DOCUMENT

A here document (heredoc) is a form of input redirection that allows entering multiple lines of input to a command. The syntax of writing heredoc takes the following form:

```
ogcli [command] << 'DELIMITER'
    HEREDOC
    DELIMITER
```

- The first line starts with the ogcli command, followed by the special redirection operator << and a delimiting identifier. Any word can be used as the delimiter, commonly 'EOF' or 'END'.
- The HEREDOC block can contain multiple lines of strings, variables, commands or any other type of input. Each line can specify one field to update.
- The last line ends with the delimiting identifier used above, indicating the end of input.

```
ogcli update user <username> << 'END'
description="operator"
enabled=false
END
```

INLINE ARGUMENTS

Field data can be entered inline with the `ogcli` command as arguments, with each field separated by a space.

```
ogcli update user <username> enabled=false description=\"operator\"
```

PIPES AND STANDARD INPUT

The data can also be entered via `stdin` by piping the data to the `ogcli` command.

```
echo 'enabled=true description="operator"' | ogcli update user <username>
```

Alternatively, you can provide a file via input redirection with `<`.

```
echo 'enabled=true description="operator"' > partial_record
```

```
ogcli update user <username> < partial_record
```

QUOTING STRING VALUES

All string fields require the argument to be specified with double quotes `"`. The shell can consume double quotes, so care must be taken when specifying strings to ensure the quotes are passed to `ogcli` as input.

1. Double quotes in heredoc do not have to be escaped.

```
ogcli update physif <device-identifier> << 'END'
description="test network"
END
```

2. Double quotes within single quotes do not have to be escaped.

```
ogcli update physif user <username> 'description="test user"'
```

3. Double quotes not within single quotes have to be escaped.

```
ogcli update physif user <username> description=\"test user\"
```

TAB COMPLETION

ogcli includes tab completion to assist with typing commands. When entering the start of a command, press the **<tab>** key to complete the phrase to the nearest match.

If there are multiple matches, all options are displayed for your reference.

```
root@om1208-8e:~# ogcli get cel
cellmodem                                system/cell_reliability_test
cellfw/info                             cellmodem/sims                system/cellular_logging
```

DISPLAYING SECRETS IN OGCLI

Fields containing sensitive information are called **secrets**, which are handled specially by **ogcli** to obfuscate their values when they are displayed or exported.

Passwords and private keys are examples of secret fields.

The obfuscation process provides protection against "casual observation" only and offers no cryptographic security. The **obfusc** tool can be used to obtain the clear text version of any obfuscated secret generated by any Operations Manager.

For more information, view the secrets help topic by running:


```
ogcli help secrets
```

The default behavior is for secrets to be passed to ogcli in clear text, and exported or displayed in obfuscated form.

For example, setting the password:

```
ogcli update services/snmpd auth_password=\"my secret\"
```

Retrieving the password (note, the output is abridged):

```
# ogcli get services/snmpd
auth_password="TkcxJAAAABBSB3xoFWWhPA6B7sDrzq3HwaTOAO/jsURqFa0qa7hc3TA=="
```

This behavior can be overridden to display sensitive fields in clear text, obfuscated form, or masked form using the **--secrets** option. The clear text and obfuscated forms are also accepted when supplying a sensitive field.

```
# ogcli --secrets=cleartext get snmpd
auth_password="my_secret"
```

```
# ogcli --secrets=obfuscate get snmpd
auth_password="my secret"
```

```
# ogcli --secrets=mask get snmpd
auth_password="*****"
```

If an export is performed with the **--secrets=mask** option it is impossible to subsequently import the configuration, because the secrets have been removed.

COMMON CONFIGURATION EXAMPLES

These examples contain a variety of notations and usage patterns to help illustrate the flexibility of ogcli. The examples can be copied and pasted into the CLI.

Replace Message of the Day (MOTD) Displayed at login

```
ogcli replace banner banner=\"updated message\"
```

Retrieve User Record

```
ogcli get user <username>
```

Update Item with Field Where Value is a String

```
ogcli update user <username> description=\"operator\"
```

Update Item with Field Where Value is Not a String

For example, a numeric or boolean value

```
ogcli update user <username> enabled=true
```

Export System Configuration

```
ogcli export <file_path>
```

Import System Configuration

```
ogcli import <file_path>
```

Restore System Configuration

```
ogcli restore <file_path>
```

COMPARE CURRENT CONFIGURATION WITH A PROPOSED CONFIGURATION

The updated `ogcli diff` tool enables Opengear users to compare a proposed configuration with an existing configuration so that they may understand any prospective changes to the config.

The diff function performs a comparison of active configuration and an input configuration file, which must be in the format an export file produced by either a `config export <template-file>` or an `ogcli export <template-file>` operation. Any manual changes to this export file must include config or ogcli commands in a multi-line format using the 'END' heredoc marker as produced by an export. One line config or ogcli commands will not be accepted.

USING THE DIFF TOOL

The diff tool can be used by any user with Administrator permission via the command line.

```
ogcli diff <input file>
```

or using config:

```
config diff <input file>
```

Note: `config diff` and `ogcli diff`, and can be used interchangeably using export files in either format.

If there are no differences between the active configuration and the input configuration file, the diff tool will not print any output, and the operation will have an exit code of 0.

```
root@om2248:~# ogcli export config_file
root@om2248:~# ogcli diff config_file
root@om2248:~# echo $?
0
```

The diff function will show any additions, removals and changes clearly in a streamlined format with only functional differences between the input and running configurations. Any additions that are made to the active configuration are marked with a (+). For example, the `new_user` user does not exist in the active configuration, but is present in the input file supplied. If the input file was imported, this user would be added.

```
ogcli --secrets=obfuscate merge users <<'END'
+ users[1].enabled=true
+ users[1].groups[0]="admin"
+ users[1].no_password=false
+ users[1].ssh_password_enabled=true
+ users[1].username="new_user"
END
```

If the `new_user` user exists in the active configuration, but does not exist in the input file, this user is removed if the input file was imported or restored. Removals are marked with a (-) symbol.

```
ogcli --secrets=obfuscate merge users <<'END'
- users[1].enabled=true
- users[1].groups[0]="admin"
- users[1].no_password=false
```

```
- users[1].ssh_password_enabled=true
- users[1].username="new_user"

END
```

Changes in configuration between an item which exists in both the active configuration and the input file will also be displayed. The existing configuration is marked with a (-) and the incoming change as a (+). In the following example, the `new_user` user belongs to the `netgrp` group on the device. However, if the input file is imported, it belongs only to the `Admin` group.

```
ogcli --secrets=obfuscate merge users <<'END'

- users[1].groups[0]="netgrp"
- users[1].groups[1]="admin"
+ users[1].groups[0]="admin"

END
```

If any differences are found, the operation will have an exit code of 1. If there are any errors, the diff tool will have an exit code of 2.

Comparison to Default Values

If the input configuration file is missing properties or sections of configuration, the diff function will instead consider the differences between active configuration and the default values for those properties. Missing sections or properties from the input file will only be displayed in the diff tool output if the active configuration is different from the default system values. If any property or configuration section is missing from input configuration, and the running configuration is identical to the system defaults, it is omitted from the diff output.

How Secrets are Handled

The `--secrets` flag can be used to control how sensitive fields are displayed in the diff output. By default, sensitive fields are obfuscated. If the proposed config file was exported with `--secrets=cleartext` or `--secrets=mask` then the same value must be used when running `ogcli diff`.

```
root@om2248:~# ogcli --secrets=cleartext export config_file
root@om2248:~# ogcli --secrets=cleartext diff config_file
```

If the input file contains a different `--secrets` parameter than is passed to `ogcli diff` or `config diff`, an error is returned:

```
root@om2248:~# config --secrets=cleartext export config_file
oot@om2248:~# config --secrets=cleartext diff config_file
root@om2248:~# config --secrets=mask diff config_file
The secrets flag provided doesn't match the flag in the proposed config for
physifs.
This error can be ignored with the --ignore-secrets-mismatch flag.
Type ogcli diff --help for more information.
```

This behaviour is the same for `config`:

```
root@om2248:~# config --secrets=cleartext export config_file
oot@om2248:~# config --secrets=cleartext diff config_file
root@om2248:~# config --secrets=mask diff config_file
The secrets flag provided doesn't match the flag in the proposed config for
physifs.
This error can be ignored with the --ignore-secrets-mismatch flag.
Type ogcli diff --help for more information.
```

The `--ignore-secrets-mismatch` flag can be used to ignore a difference in the `--secrets` parameter:

```
root@om2248:~# ogcli diff --ignore-secrets-mismatch config_file
```

Diff Tool Help

Basic help for `ogcli diff` can be accessed with `ogcli diff -h`. Similarly, help for `config diff` can be accessed with `config diff -h`. Detailed help for both diff tools can be accessed by `ogcli help diff`.

Limitations

JSON template files are no longer supported with `config diff`.

`ogcli diff` only supports input configurations generated by the same product SKU and software version.

Comments can be included between `ogcli` or `config` commands in the export file, but not within the commands or an error is thrown. Comments must start with `#`. These are ignored by the diff tool.

See also ["diff" on page 276](#)

Enable Local Console Boot Messages

```
ogcli get managementports
```

```
ogcli update managementport mgmtPorts-1 kerneldebug=true
```

Create New User

```
ogcli create user << 'END'
  description="superuser"
  enabled=true
  groups[0]="admin"
  password="test123"
  username="superuser123"
END
```

Change Root Password

```
ogcli update user root password=\"oursecret\"
```

Create New Administrative User

```
ogcli create user << 'END'
  username="adal"
  description="Ada Lovelace"
  enabled=true
  no_password=false
  groups[0]="groups-1"
  password="oursecret"
END
```

Manually Set Date and Time

```
ogcli update system/timezone timezone=\"America/New_York\"
```



```
ogcli update system/time time=\"15:30 Mar 27, 2020\"
```

Enable NTP Service

```
ogcli update services/ntp << 'END'
enabled=true
servers[0].value="0.au.pool.ntp.org"
END
```

Update System Hostname

```
ogcli update hostname hostname=\"system-hostname\"
```

Adjust Session Timeouts

```
ogcli update system/cli_session_timeout timeout=180
```

```
ogcli update system/webui_session_timeout timeout=180
```

Setup Remote Authentication with TACACS+

```
ogcli update auth << 'END'
mode="tacacs"
tacacsAuthenticationServers[0].hostname="192.168.250.21"
tacacsMethod="pap"
tacacsPassword="tackey"
END
```

Setup Remote Authentication with Radius

```
ogcli update auth << 'END'
  mode="radius"
  radiusAuthenticationServers[0].hostname="192.168.250.21"
  radiusAccountingServers[0].hostname="192.168.250.21"
  radiusPassword="radkey"
END
```

Create User Group with Limited Access to Serial Ports

```
ogcli create group << 'END'
  description="Console Operators"
  groupname="operators"
  role="ConsoleUser"
  mode="scoped"
  ports[0]="ports-10"
  ports[1]="ports-11"
  ports[2]="ports-12"
END
```

View and Configure Network Connections

```
ogcli get conns
```

```
ogcli get conn system_net_conns-1
```

```
ogcli update conn system_net_conns-1 ipv4_static_settings.address=\"192.168.0.3\"
```

```
ogcli create conn << 'END'
  description="2nd IPv4 Static Address Example"
  mode="static"
  ipv4_static_settings.address="192.168.33.33"
  ipv4_static_settings.netmask="255.255.255.0"
  ipv4_static_settings.gateway="192.168.33.254"
  physif="net1"
END
```

CONFIGURE A DNS

DNS settings such as Name Servers and Search Domains can be configured for each network interface, which will override the DHCP provided settings.

Name servers allow the system to resolve hostnames to IP addresses to communicate with remote systems. Search domains allow the system to resolve partially qualified domain names (PQDN) by appending entries from the listed search domains to form a fully qualified domain name (FQDN).

When adding an interface to a Bond or Bridge, it will use the DNS configuration of the aggregate interface.

Note: Interfaces must have at least one network connection to be able to perform DNS resolution.

Configure a DNS via the Command Line

Description	Command
Display configured DNS settings for an interface	<pre>ogcli get physif "net1"</pre>
Update DNS settings for an interface	<pre>ogcli update physif "net1" << END dns.nameservers[0]="1.1.1.1" dns.nameservers[1]="1.0.0.1" dns.search_domains[0]="example.net" dns.search_domains[1]="example.com" END</pre>
Check unbound service status	<pre>systemctl status unbound.service</pre>
List forward-zones in use	<pre>unbound-control list_forwards</pre>

Configure Serial Ports

```
ogcli get ports
```

```
ogcli get ports | grep label
```

```
ogcli get port ports-1
```

```
ogcli update port "port05" << 'END'
mode="consoleServer"
label="Router"
pinout="X2"
baudrate="9600"
databits="8"
parity="none"
stopbits="1"
escape_char="~"
ip_alias[0].ipaddress="192.168.33.35/24"
ip_alias[0].interface="net1"
logging_level="eventsOnly"
END
```

Enable Cellular Modem Interface

```
ogcli get physifs
```

```
ogcli update physif wwan0 << 'END'
enabled=true
physif.cellular_setting.apn="broadband"
physif.cellular_setting.iptype="IPv4v6"
END
```

Disable Cellular Modem Interface

```
ogcli update physif physif wwan0 enabled=false
```

ADVANCED PORTMANAGER PMSHELL GUIDE

The Portmanager program allows you to access any serial port on the console server using `pmshell` commands.

- Routes network connection to serial ports.
- Checks permissions.
- Monitors and logs all the data flowing to/from the ports.
- Allows you to run power commands if the serial port is associated with a PDU outlet.

RUNNING PMSHELL

`pmshell` provides an environment that allows you to access and interact with serial ports via a number of command sequences. It lets you navigate between ports using the chooser command (`~m`). For example, you can use `pmshell` to connect to port 8 via the portmanager via the following command line sequence.

```
# pmshell -l port08
```

PMSHELL COMMANDS

When running `pmshell` there are a number of command sequences that you can use that begin with the `~` key.

Note: If you are connected to `pmshell` via SSH, you must add an additional `~` escape sequence.

Options	Name	Result
~c		The Single Session feature can be enabled or disabled by editing the single_session field in a given port. When a user port level administration access is logged in via pmshell, the port configuration menu can be accessed via any port by pressing the escape character (~ by default) followed by c (~c).
~b	break	Generates a BREAK on the serial port (if you're doing this over ssh, type "~b").
~h	portlog	Generates a history on the serial port. Displays the traffic logs for the port - must have port logging enabled.
~.	quit	Quits pmshell.
~p	power	Opens the power menu for the port. The port must be configured for a PDU.
~u		Opens the list of user sessions, select by number to disconnect.
~m	chooser	Connects to the port menu - go back to the serial port selection menu.
~?	pmhelp	Displays help message.

CUSTOM CONTROL CODES FOR SERIAL PORTS

Custom control codes can be defined for ease of use per port or can be applied to all ports. For example, users could define a different Power Menu control code for every port, while having a single control code for View History that applies to all ports.

Custom control codes can be used by any user with access to the serial port. In order to run the shortcuts, the user presses the CTRL key + the keycode.

Note: Only Admin users can specify short-cut control codes.

CONFIGURE CUSTOM CONTROL CODES

Admin users can configure control codes for any of the `pmshell` commands through the REST API, `ogcli` and the new interactive Config Shell.

Control code limitations are as follows:

- Cannot set multiple control codes for a port to use the same keycode
- The available key codes are a-z, excluding 'i' and 'm' as these can be triggered by commonly used keys TAB and BACKSPACE.

To disable a certain control code for an individual port, set the port's control code to an empty string.

CONFIGURE CONTROL CODES FOR A SPECIFIED PORT (CLI EXAMPLES)

Control Codes Action	CLI Examples
Set control codes for a given port. In this example, the user sets multiple control codes for port 2	<p>Note: <code>ogcli update port port02 << 'END'</code></p> <pre>control_code.break="b" control_code.chooser="c" control_code.pmhelp="h" control_code.portlog="l" control_code.power="p" control_code.quit="q" END</pre>

Clear all control codes for a given port, in this example, port 2

Note: ogcli update port port02 << 'END'
control_code.break=""
control_code.chooser=""
control_code.pmhelp=""
control_code.portlog=""
control_code.power=""
control_code.quit=""
END

CONFIGURE A CONTROL CODE VALUE FOR ALL PORTS

To set a particular control code to one value across all serial ports, Admin users can use the script `set-serial-control-codes` from the CLI as follows:

```
set-serial-control-codes CONTROL_CODE KEY
```

where:

- **CONTROL_CODE** - Must be one of the following values: `break`, `chooser`, `pmhelp`, `portlog`, `power` or `quit`.
- **KEY** - Must be a single lower case letter a-z excluding 'i' and 'm' or an empty string designated by "" which is used to clear the control code.

CONTROL CODES FOR ALL PORTS VIA CLI (EXAMPLES)

Control Codes Action	CLI Examples
Set chooser control code to CTRL-a on all ports	Note: <code>set-serial-control-codes chooser a</code>
Clear chooser control code on all ports	Note: <code>set-serial-control-codes chooser ''</code>

DOCKER

Docker is a tool designed to make it easier to create, deploy, and run applications by distributing them in containers. Developers can use containers to package up an application with all of the parts it requires, like libraries and dependencies, and then ship it out as one package. Docker is running by default on the Operations Manager. You can access commands by typing `docker` in the Local Terminal or SSH.

For more information on Docker, enter `docker --help`.

CRON

Cron service can be used for scheduled cron jobs runs. Daemon can be managed via the `/etc/init.d/crond` interface, and cron tables managed via `crontab`. Crontab supports:

Usage	
<code>crontab [options] file</code>	
<code>crontab [options]</code>	
<code>crontab -n [hostname]</code>	

Option	Description
<code>-u <user></code>	Define user.
<code>-e</code>	Edit user's crontab.

Option	Description
-l	List user's crontab.
-r	Delete user's crontab.
-i	Prompt before deleting.
-n <host>	Set host in cluster to run users' crontabs.
-c	Get host in cluster to run users' crontabs.
-x <mask>	Enable debugging.

To perform start/stop/restart on crond service:

```
/etc/init.d/crond start
```

Cron doesn't have to be restarted when crontab file is modified, it examines the modification time on all crontabs and reload those which have changed.

To verify the current crond status:

```
/etc/init.d/crond status
```

To check current cron jobs running with the following command to list all crontabs:

```
crontab -l
```

To edit or create a custom crontab file:

```
crontab -e
```

This opens a personal cron configuration file. Each line can be defined as one command to run. The following format is used:

minute hour day-of-month month day-of-week command

For example, append the following entry to run a script every day at 3 am:

```
0 3 * * * /etc/config/backup.sh
```

Save and close the file.

INITIAL PROVISIONING VIA USB KEY

Also known as “ZTP over USB”, this feature allows provisioning an unconfigured (factory erased) unit from a USB storage device like a thumb drive.

The USB device must contain a filesystem recognized by the OM (currently FAT32 or ext4) with a file named `manifest.og` in the root directory. This file specifies which provisioning steps are done. An article with a partial description of the file format is available here: [Automated enrollment using USB](#).

The USB device can be inserted any time (before or after power is applied to the unit) and as long as the unit is unconfigured, the ZTP over USB process is triggered. Here “unconfigured” has the same meaning as for ZTP: no changes made to the `ogconfig` data store.

Note: Setting the root password on first login counts as a config change.

The following `manifest.og` keys are implemented. This provides image installation, Lighthouse enrollment, and arbitrary script execution:

`manifest.og` contains `<key>=<value>` pairs. Recognized keys are:

`image` : Firmware image file name on the USB device's filesystem that is flashed after boot when the image is validated

`script` : Configuration script to run

`address` : Primary Lighthouse address to enroll with

`api_port` : Optional port to use for the primary address when requesting enrollment

`password` : LH global or bundle enrollment password












`bundle` : Name of LH enrollment bundle



EULA AND GPL

The current Opengear End-User License Agreement and the GPL can be found at <http://opengear.com/eula>.

UI BUTTON DEFINITIONS

The following table provides a definition of the button icons used in the UI.

Button Icon	Definition
	Edit buttons
	Add item (eg. SNMP Manager)
 	VLAN interface or create VLAN interface.
 	Bonded interfaces or create new bond
 	Bridged interfaces or create new bridge
	Standard network interface
	Cellular interface
	Interface with bridge

Button Icon	Definition
	Interface with bond
	Bin widget. Delete selected object.